Cable Machine



Category: **Beauty, Wellness & Fitness** Type: **Full SOP** Priority: **High** 1 labs

Covers these lab items: Cable machine

What it is used for

A cable machine is a fitness station that uses adjustable resistance through cables and pulleys for controlled strength exercises. Set the load and attachments correctly, maintain stable posture, and inspect the cable system before use to reduce the risk of injury or equipment failure.

Main parts

- Machine frame and base
- Weight stack or resistance mechanism
- Cable and pulley assemblies
- Weight selector pin or resistance control
- Handles, bars, and exercise attachments
- Seat, adjustment points, and safety stops, if fitted

Before you start

1. Confirm that the machine and intended exercise are suitable for the user's fitness level and any applicable restrictions.
2. Inspect the frame, base, cables, pulleys, selector pin, attachments, and adjustment locks for damage or wear.
3. Check that cable strands are intact and there are no frays, kinks, or loose connections.
4. Ensure the machine is stable, surrounding floor is dry, and there is sufficient clearance for the exercise.
5. Select a suitable starting resistance and verify that the selector pin is fully inserted.
6. Use suitable exercise clothing and footwear, and remove jewellery that could catch on the equipment.

How to use

1. Adjust the seat, pulley height, and other settings according to the intended exercise.
2. Attach the correct handle or bar and confirm that the connector is fully secured.
3. Select a manageable resistance and test the movement with a controlled, light repetition.
4. Stand or sit in the designated position with stable footing and a neutral posture.
5. Grip the attachment securely and perform the exercise through a comfortable, controlled range of motion.
6. Keep the cable tension controlled and avoid jerking, swinging, or letting the weight stack drop suddenly.
7. Breathe steadily and maintain correct technique throughout each repetition.

8. Return the attachment slowly to its resting position and ensure the weight stack settles fully.
9. Stop immediately if there is unusual cable noise, slipping, pain, or unstable movement.
10. After the set, place the attachment in its designated holder and lower the resistance safely.
11. Report any damage or malfunction and do not use the machine until it has been inspected.
12. Wipe contact surfaces after use and leave the area clear for the next user.

⚠ Safety

- Use the machine only as intended and follow the facility's operating instructions.
- Never use frayed cables, damaged pulleys, loose attachments, or a faulty selector pin.
- Keep fingers clear of pulleys, weight stacks, and moving cable connections.
- Do not exceed the machine's rated load or attach unapproved accessories.
- Avoid sudden release of the handle, which can cause the weight stack or cable to snap back.
- Stop exercising if sharp pain, dizziness, or unusual symptoms occur; seek appropriate assistance.

Care & storage

- Wipe down handles, seats, and contact surfaces after use.
- Inspect cables, pulleys, connectors, and weight-stack guides regularly.
- Check bolts, adjustment locks, and the machine base for looseness or damage.
- Arrange replacement of worn cables and servicing according to the manufacturer's schedule.
- Keep the area around the machine clean, dry, and unobstructed.

Common mistakes to avoid

- Selecting excessive resistance before learning the correct movement.
- Using a damaged cable or an attachment that is not secured.
- Jerking the handle or allowing the weight stack to slam down.
- Ignoring pain, unusual cable sounds, or unstable machine parts.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar