# Jute Article Finishing Machine



Category: **Sewing, Textile & Handicraft** Type: **Full SOP** Priority: **High** 1 labs

**Covers these lab items:** Jute Article Finishing Machine

## What it is used for

To finish jute articles by trimming loose fibres, smoothing surfaces, and performing approved edge or appearance finishing operations. To improve product consistency while protecting the operator from blades, moving parts, and airborne fibres.

## Main parts

- Machine frame and work surface
- Finishing or trimming head
- Feed guide or work holder
- Drive motor and speed control
- Guard and emergency stop, if fitted
- Dust collection or fibre removal arrangement

## Before you start

1. Read the manual and identify the finishing operation supported by the machine.
2. Inspect the cutting or finishing head, guards, work holder, drive belt, and power connections for damage.
3. Confirm that the correct tool or attachment is installed and securely fastened.
4. Check that dust or fibre collection equipment is connected and working where provided.
5. Prepare the jute article and remove pins, staples, or other objects that could damage the tool.
6. Wear suitable eye protection, a dust mask or respirator where required, and close-fitting work clothing.

## How to use

1. Place the machine on a stable surface and ensure the emergency stop is accessible.
2. Switch off and isolate power before fitting attachments or adjusting guides.
3. Set the feed guide and finishing settings according to the jute article and desired finish.
4. Secure the workpiece using the designated holder or guide.
5. Switch on the machine and check for unusual vibration, noise, or movement.
6. Feed the jute article steadily through the finishing area without forcing it.
7. Trim loose fibres or finish edges in controlled passes while keeping hands clear of the tool head.
8. Inspect the finished surface and repeat only where necessary to meet the specified quality.
9. Stop the machine before clearing fibre buildup or repositioning a jammed workpiece.
10. Switch off and disconnect power before cleaning, replacing a tool, or performing maintenance.
11. Remove fibre waste using the approved cleaning method and avoid blowing dust into the air.

2. Record defects or machine issues and store the equipment in a clean, dry location.

## ⚠ Safety

- Only trained operators should use the finishing machine.
- Never remove guards or reach into the moving finishing head.
- Keep fingers, loose clothing, jewellery, and hair away from the feed and cutting area.
- Isolate power before clearing jams, removing waste near moving parts, or changing attachments.
- Use appropriate dust protection and ventilation to reduce inhalation of airborne fibres.
- Do not operate with damaged blades, loose tools, faulty switches, or exposed drive components.

## Care & storage

- Remove jute fibres and dust from the work area and accessible machine surfaces after use.
- Inspect the finishing head and replace worn or damaged tools as specified by the manufacturer.
- Check guards, work holders, belts, and fasteners regularly.
- Maintain the motor and lubrication points according to the manual.
- Keep dust extraction paths clear and arrange periodic servicing.

## Common mistakes to avoid

- Using an unsuitable finishing tool or incorrect setting for the jute article.
- Forcing the material through the machine and causing uneven finishing.
- Holding the article too close to an unguarded moving tool.
- Clearing accumulated fibres while the machine is running.
- Ignoring excessive dust, vibration, or a damaged finishing head.

*Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.*