Millet Cleaning Machine



Category: **Food Processing & Kitchen** Type: **Full SOP** Priority: **High** 1 labs

Covers these lab items: Millet Cleaning Machine

What it is used for

To remove dust, stones, chaff, and other unwanted material from millet before further processing. To obtain clean grain while maintaining consistent feeding and preventing blockages or contamination.

Main parts

- Machine frame and feed hopper
- Screens or sieves
- Cleaning chamber and airflow system, if fitted
- Vibrating or rotating cleaning mechanism
- Grain outlet and waste outlet
- Motor, drive, and control panel

Before you start

1. Read the manual and confirm that the machine is suitable for the millet variety and batch size.
2. Inspect the hopper, screens, cleaning chamber, outlets, guards, and drive components for damage.
3. Ensure all product-contact surfaces are clean and free from residue from previous batches.
4. Check that the correct screen size is installed and securely fitted.
5. Confirm that grain and waste collection containers are clean and correctly positioned.
6. Remove foreign objects from the feed area and check that the waste outlet and airflow path are clear.

How to use

1. Switch off and isolate power before opening the chamber or adjusting screens.
2. Close access panels and ensure all guards are fitted before starting.
3. Set the feed rate and airflow, if available, according to the grain condition and machine instructions.
4. Place the raw millet in the feed hopper without exceeding its capacity.
5. Start the machine and allow it to reach normal operating conditions.
6. Feed millet gradually and maintain a steady flow to avoid overloading.
7. Observe the cleaned grain output and the removal of dust, chaff, and other impurities.
8. Check for unusual noise, vibration, blockage, or grain loss during operation.
9. Adjust feed or airflow only within the manufacturer's specified limits.
10. Stop the machine if screens block, grain flow becomes irregular, or a mechanical fault occurs.

1. Isolate power and wait for moving parts to stop before clearing blockages or changing screens.
2. Collect and inspect the cleaned millet, then clean the machine and record any issues.

⚠ Safety

- Only trained personnel should operate the cleaning machine.
- Keep hands and tools away from moving screens, rotating parts, belts, and feed mechanisms.
- Do not operate with missing guards, damaged screens, or exposed drive components.
- Use suitable dust protection and ensure ventilation or dust extraction where necessary.
- Keep the floor around the machine dry and free from spilled grain to prevent slips.
- Disconnect and isolate power before clearing blockages, removing screens, or performing maintenance.

Care & storage

- Remove grain, dust, and chaff from the hopper, screens, chamber, and outlets after use.
- Inspect screens for tears, wear, and loose fittings regularly.
- Check belts, bearings, fasteners, and drive components according to the maintenance schedule.
- Keep motors and electrical controls free from dust buildup using approved methods.
- Store the machine clean and dry and record maintenance or abnormal operation.

Common mistakes to avoid

- Overloading the hopper and feeding millet too quickly.
- Using the wrong screen size for the grain or required cleaning level.
- Operating with blocked screens or an obstructed waste outlet.
- Cleaning the machine while moving parts are still running.
- Ignoring excessive grain loss, unusual vibration, or poor cleaning performance.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.