Nail Gun



Category: **Power Tools & Workshop Machines** Type: **Full SOP** Priority: **High** 1 labs

Covers these lab items: Nail Gun

What it is used for

A nail gun drives nails into suitable materials using a specified power source. It speeds up fastening work but can cause serious puncture injuries if handled incorrectly.

Main parts

- Identify the nosepiece or contact tip where nails are discharged.
- Locate the nail magazine that holds the fasteners.
- Identify the trigger and contact safety mechanism.
- Locate the power source, such as battery, electrical cable or compressed-air connection.
- Identify the depth adjustment and fastener loading controls, where provided.
- Locate the air-pressure control or battery indicator, depending on model.
- Identify the safety lock and manufacturer's operating instructions.

Before you start

1. Read the operating instructions and receive supervised training before use.
2. Wear safety goggles and suitable hearing protection where required.
3. Check the tool body, trigger, nosepiece and safety mechanism for damage.
4. Confirm the nail type and length are suitable for the material.
5. Disconnect the battery, power supply or air hose before loading nails or adjustments.
6. Inspect the workpiece and ensure the fastening area contains no hidden cables or pipes.
7. Secure the workpiece and keep other people outside the working area.

How to use

1. Select the correct nails and load them into the magazine as instructed.
2. Reconnect the specified power source only after loading and inspection are complete.
3. Adjust the depth setting and air pressure if the model permits.
4. Hold the nail gun firmly against the designated fastening point.
5. Keep fingers away from the nosepiece and intended nail exit path.
6. Align the tool perpendicular to the surface unless the instructions specify otherwise.
7. Engage the contact safety mechanism and trigger according to the model design.
8. Check the fastener placement and adjust settings only after disconnecting power.
9. Release the trigger and disconnect the power source before clearing jams.
10. Store the nail gun with the safety engaged and power source disconnected.

⚠ Safety

- Never point the nail gun at yourself or another person.
- Keep hands and body parts away from the nail exit area.
- Do not carry the tool with the trigger pressed or safety defeated.
- Disconnect power before loading, unloading, clearing jams or servicing the tool.
- Never use the nail gun near hidden electrical wires or pipes without checking.
- Use only compatible nails and the specified power or air pressure.

Care & storage

- Disconnect the power source and clean dust from the tool exterior.
- Inspect the magazine, nosepiece and safety mechanism after use.
- Lubricate pneumatic models only as specified by the manufacturer.
- Store the tool dry and secure, away from children and unauthorised users.

Common mistakes to avoid

- Pressing the trigger before the nosepiece is correctly positioned.
- Using incompatible nails or excessive air pressure.
- Clearing a jam while the tool remains connected to power.
- Disabling the contact safety mechanism to speed up work.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar