Paddy Transplanter



Category: **Agriculture & Gardening** Type: **Full SOP** Priority: **High** 1 labs

Covers these lab items: Paddy transplanter

What it is used for

A paddy transplanter places young rice seedlings into prepared wet or puddled fields at regular spacing. It improves planting consistency and reduces the manual effort required for transplanting.

Main parts

- Identify the seedling tray or mat-seedling loading platform.
- Locate the seedling feeding mechanism and planting fingers.
- Identify the planting unit that places seedlings into the soil.
- Locate the engine or tractor power connection, depending on model.
- Identify the steering controls, gear selector and travel controls.
- Locate the depth, row-spacing and planting adjustments, where provided.
- Identify protective guards, emergency stop and transport locking components.

Before you start

1. Read the operating instructions and receive supervised training before use.
2. Inspect the frame, planting fingers, seedling feed mechanism and guards for damage.
3. Check fuel, engine oil and other specified fluids on engine-powered models.
4. Confirm that seedlings are healthy and prepared in the required tray or mat format.
5. Inspect the field for suitable puddling, water depth and obstructions.
6. Check that safety controls, brakes and steering work correctly.
7. Keep bystanders away and wear suitable footwear for wet-field conditions.

How to use

1. Park the transplanter on firm, level ground and stop the engine before loading.
2. Arrange seedling trays or mats correctly on the designated platform.
3. Set planting depth, row spacing and operating speed according to instructions.
4. Start the engine or power unit using the prescribed procedure.
5. Move to the field at low speed with the planting unit raised.
6. Lower the planting unit gradually at the starting point.
7. Engage the planting mechanism and move forward at a steady speed.
8. Monitor seedling feeding, planting depth and spacing during operation.
9. Stop safely to replenish trays or clear a blockage after disengaging the mechanism.
10. Raise the planting unit before turning at field ends.
11. Park on stable ground, lower the implement and stop the engine after work.

⚠ Safety

- Keep hands away from planting fingers, chains and seedling feed mechanisms.
- Never load trays or clear blockages while the planting mechanism is engaged.
- Stop the engine before adjustments, maintenance or cleaning.
- Use designated steps and handholds when mounting or dismounting the machine.
- Avoid steep banks, deep mud and unstable field edges.
- Keep people away from the machine while reversing or turning.

Care & storage

- Remove mud, roots and plant residue after stopping and lowering the unit safely.
- Clean seedling trays, feeding parts and planting fingers after use.
- Inspect chains, belts, planting fingers and fasteners for wear or damage.
- Check fluid levels and lubricate specified points according to instructions.
- Store the transplanter clean and dry with planting units secured.

Common mistakes to avoid

- Loading incorrectly prepared seedlings that feed poorly through the mechanism.
- Operating at excessive speed and producing uneven seedling spacing.
- Adjusting planting fingers while the mechanism is moving.
- Turning sharply with the planting unit lowered in the soil.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar