Blueprint Machine



Category: **Computers, IT & Office** Type: **Full SOP** Priority: **Medium** 2 labs

Covers these lab items: Blueprint machine

What it is used for

A blueprint machine reproduces large-format technical drawings, plans, and engineering documents using the supported copying or printing process. Correct document handling, settings, and ventilation help produce readable copies and maintain safe operation.

Main parts

- Document feed or scanning surface
- Original document guides and alignment marks
- Copying or printing mechanism
- Paper supply roll or sheet tray
- Control panel and size or density settings
- Output tray, ventilation system, and power connection

Before you start

1. Read the machine instructions and confirm the supported document sizes and media types.
2. Inspect the feed path, rollers, guides, output area, power cable, and ventilation openings.
3. Check that the correct paper or approved reproduction media is loaded and aligned.
4. Ensure the original drawing is clean, dry, and free from clips or objects that could damage the feed path.
5. Select the required copy size, scale, orientation, and density settings.
6. Confirm that ventilation is adequate and any required covers or safety interlocks are in place.

How to use

1. Switch on the machine and allow it to complete its startup checks.
2. Select the correct paper size, reproduction mode, scale, and image density.
3. Align the original drawing using the guides or scanning reference marks.
4. Feed or scan the document according to the machine's operating instructions.
5. Preview the image or check the first copy for line clarity, orientation, and scale.
6. Adjust approved settings if the copy is too faint, too dark, cropped, or distorted.
7. Run the required number of copies and collect each sheet from the output area.
8. Check that the reproduced dimensions and drawing details meet the job requirements.
9. Remove any jam only after stopping the machine and following the approved jam-clearing procedure.
10. Switch off the machine when finished and clean the accessible feed and output areas.

⚠ Safety

- Keep hands, hair, loose clothing, and tools away from rollers and moving feed mechanisms.
- Do not reach into the machine while it is operating or bypass fitted safety covers.
- Use only media and cleaning products approved for the machine.
- Avoid inhaling toner, ink mist, or process fumes and maintain required ventilation.
- Disconnect power before cleaning internal areas or performing maintenance.
- Allow hot components to cool before touching them, where applicable.

Care & storage

- Clean the scanning surface, guides, and accessible rollers with approved materials.
- Inspect paper feed components, cables, covers, and ventilation openings regularly.
- Replace consumables according to the manufacturer's instructions and avoid touching sensitive surfaces unnecessarily.
- Arrange servicing and calibration according to the equipment schedule.

Common mistakes to avoid

- Incorrect scale settings can produce drawings with misleading dimensions.
- Poor document alignment can crop borders or distort the reproduced plan.
- Using incompatible paper or media can cause jams and poor image quality.
- Clearing jams while the machine is running can cause injury or damage.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.