Phase Tester



Category: **Electrical & Electronic Test Instruments** Type: **Short SOP** Priority: **Medium**

13 labs

Covers these lab items: Electricity tester; Line tester; Phase tester; Tester

What it is used for

Use a phase tester to check for the presence of voltage at suitable points in an electrical circuit, following the tester's design and rating.

How to use

1. Inspect the tester body, insulation, and tip for cracks or damage.
2. Confirm the tester type and voltage rating are suitable for the circuit.
3. Test the tester on a known live source or approved proving unit where applicable.
4. Use the tester only at an appropriate accessible test point.
5. Observe the indicator according to the manufacturer's instructions.
6. Recheck the tester on the proving source after testing when applicable.
7. Keep the circuit isolated before touching conductors or making repairs.

⚠ Safety

- A basic neon line tester is not a substitute for a rated voltage detector or meter.
- Never touch exposed metal parts of the tester tip during use.
- Do not use a damaged tester or exceed its rated voltage.
- Follow safe isolation procedures before working on electrical wiring.

Care & storage

- Wipe the tester clean and keep it dry.
- Store it safely and inspect its insulation before each use.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.