Plumb Bob



Category: **Measuring & Marking Tools** Type: **Short SOP** Priority: **Medium** 11 labs

Covers these lab items: Plumb bob; Plumb rule and Bob

What it is used for

Use a plumb bob to establish a true vertical reference when checking alignment or transferring a point vertically.

How to use

1. Inspect the bob, cord, and attachment point for damage or wear.
2. Secure the cord to a stable point directly above the required reference.
3. Allow the bob to hang freely without touching the wall, floor, or nearby objects.
4. Wait until the bob stops swinging before taking a reading or marking a point.
5. Compare the cord with the surface or transfer the point vertically as required.
6. Record the result and carefully retrieve the tool after use.

⚠ Safety

- Keep the bob clear of people and fragile objects while it hangs.
- Do not stand directly beneath a suspended bob unnecessarily.
- Use a stable support and avoid working near moving machinery.

Care & storage

- Wipe the bob clean and dry the cord before storage.
- Wind the cord neatly and store the tool in a protective case.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.