Special Tool



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 10 labs

Covers these lab items: Security activator; special maintenance tools; Special tools; Suspension activation

What it is used for

Use a designated special automotive tool to perform a specific inspection, adjustment, activation, or maintenance task according to the vehicle manufacturer's instructions.

How to use

1. Identify the exact tool and the vehicle system it is designed for.
2. Read the tool instructions and relevant vehicle service procedure.
3. Inspect the tool, connectors, and accessories for damage or missing parts.
4. Park the vehicle securely and isolate power when the procedure requires it.
5. Connect or position the tool only at the specified service point.
6. Perform the prescribed operation and observe the system response or diagnostic result.
7. Disconnect the tool safely and confirm the vehicle system is returned to the required state.

⚠ Safety

- Use the tool only for its intended vehicle system and function.
- Follow manufacturer instructions for high-voltage, airbag, suspension, or electronic systems.
- Do not activate a system while anyone is near moving parts or stored-energy components.
- Stop and consult a qualified technician if the procedure or tool is unclear.

Care & storage

- Clean the tool and inspect cables or adapters after use.
- Store it with its accessories and instructions in a labeled case.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.