Drip Irrigation System



Category: **Agriculture & Gardening** Type: **Short SOP** Priority: **Medium** 9 labs

Covers these lab items: Drip and sprinkler; Drip and sprinkler system; Drip Irrigation Unit; Drip Irrigation Unit (Lateral pipe 16mm x 20 ft , Elbow , coupler , T-joint , mini valve, gurment teck, end cap , drip punch 5nos each; Drip Irrigation UTender (Lateral pipe 16mm x 20 ft , Elbow , coupler , T- joint , mini valve,

What it is used for

Use a drip irrigation system to deliver water slowly near plant roots and reduce unnecessary water loss.

How to use

1. Inspect the water source, filter, mainline, lateral pipes, fittings, and emitters for damage or blockage.
2. Place lateral pipes near the plant rows and connect fittings securely.
3. Install the filter and pressure regulator where required by the system design.
4. Open the water supply gradually and flush the lines before normal operation.
5. Check each emitter for steady flow, leaks, and blocked outlets.
6. Adjust the schedule and duration according to crop needs, soil, and weather.
7. Close the supply after irrigation and check the system for leaks or damage.

⚠ Safety

- Use pressure ratings suitable for the pipes and fittings.
- Release system pressure before disconnecting pipes or cleaning components.
- Keep electrical pumps and connections protected from water.
- Do not use untreated or unsafe water on edible crops where it creates a health risk.

Care & storage

- Clean filters and flush lines regularly to prevent clogging.
- Repair leaking fittings and store removable parts away from direct sunlight.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.