Barcode Printer

Category: **Retail, Logistics & Warehouse** Type: **Short SOP** Priority: **Medium** 7 labs

Covers these lab items: Bar Code Machine

What it is used for

Use a barcode printer to print readable barcode labels for products, stock, packages, or other approved items.

How to use

1. Check the printer, power cable, label roll, and ribbon if required.
2. Load the correct label stock and ribbon according to the printer instructions.
3. Connect the printer to the approved computer or network.
4. Switch on the printer and confirm that it is ready.
5. Select the correct label size and barcode template in the software.
6. Print a test label and scan it to verify readability.
7. Print the required batch and check label alignment and print quality.

⚠ Safety

- Use only the specified power supply and compatible consumables.
- Keep fingers clear of moving rollers and the print head while operating.
- Allow the print head to cool before cleaning if required by the manual.
- Disconnect power before servicing the printer.

Care & storage

- Clean the print head and rollers using approved materials.
- Store label rolls and ribbons in a dry, dust-free place.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.