Bevel



Category: **Measuring & Marking Tools** Type: **Short SOP** Priority: **Medium** 3 labs

Covers these lab items: Bevel

What it is used for

To set out or transfer an angle using an adjustable bevel. To reproduce an angle accurately by aligning the blade with a reference edge and locking it in position.

Main parts

- Stock or handle
- Adjustable blade
- Pivot joint
- Locking screw or clamp

Before you start

1. Inspect the blade, stock, pivot, and locking screw for damage.
2. Check that the blade moves smoothly and locks securely.
3. Prepare the workpiece and a suitable marking tool.
4. Identify the reference edge and required angle.

How to use

1. Loosen the locking screw enough to adjust the blade.
2. Align the stock with the reference edge or existing angle.
3. Rotate the blade to match the required angle.
4. Tighten the locking screw to hold the setting.
5. Transfer the angle to the workpiece and mark the line.
6. Check the alignment before cutting or machining.

⚠ Safety

- Keep fingers clear of sharp blade edges.
- Do not force a stiff or damaged pivot.
- Lock the blade before transferring the angle.
- Store the bevel with the blade safely folded or secured.

Care & storage

- Wipe the blade and stock clean after use.
- Keep the pivot free from debris.
- Check the locking screw for wear.

- Store in a dry, protected place.

Common mistakes to avoid

- Failing to tighten the locking screw.
- Aligning the stock against the wrong reference edge.
- Allowing the blade to shift during marking.
- Using a damaged or loose pivot.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar