Vehicle Ramp



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 3 labs

Covers these lab items: Ramp

What it is used for

To raise a vehicle safely for inspection or maintenance when the ramp is designed and rated for that use.

How to handle

- Inspect the ramp for cracks, deformation, oil, and other damage; verify its load rating and compatibility with the vehicle.
- Park on firm, level ground, apply the parking brake, and follow the vehicle and ramp manufacturer instructions.
- Align the wheels carefully and drive onto the ramp slowly with a spotter when appropriate.
- Secure the vehicle as instructed and use wheel chocks where required; never work beneath a vehicle supported only by an unsuitable ramp or jack.
- After work, clear the area and drive down slowly.

Storage

- Clean the ramp and inspect it after use.
- Store on a stable, dry surface in the designated area; do not stack beyond manufacturer instructions.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.