Gear Puller



Category: **Hand Tools - Fastening & Gripping** Type: **Short SOP** Priority: **Medium** 2 labs

Covers these lab items: bearing pullers; gear puller tools

What it is used for

To remove gears, pulleys, bearings, or similar press-fitted parts using a suitable mechanical puller.

How to handle

- Inspect the puller arms, centre screw, tips, and threads for cracks, wear, or damage.
- Select a puller with the correct capacity and configuration for the component; isolate power and secure the workpiece.
- Position the arms evenly behind the component and align the centre screw with the shaft centre.
- Tighten the centre screw gradually with the appropriate tool, keeping hands and face out of the potential release path.
- Stop if the puller slips, bends, or excessive force is required; never use impact methods unless the tool is designed for them.

Storage

- Clean and lightly protect metal surfaces against corrosion if recommended by the manufacturer.
- Retract the screw, arrange the arms safely, and store in a dry tool case.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.