Tenon Saw

Category: **Hand Tools - Cutting & Shaping** Type: **Short SOP** Priority: **Medium** 2 labs

Covers these lab items: Tenon Saw

What it is used for

A tenon saw makes controlled straight cuts in wood, especially for joints and detailed carpentry. Use it with a stable workpiece and suitable cutting technique.

How to use

1. Inspect the blade, handle, teeth, and fastening points for damage.
2. Wear eye protection and secure the wood firmly on a workbench.
3. Mark the cutting line clearly and position the saw at the start point.
4. Start with gentle strokes to establish a straight kerf.
5. Continue cutting with controlled forward and backward strokes without forcing the blade.
6. Support the offcut and keep hands clear as the cut finishes.
7. Place the saw safely and remove wood dust after cutting.

⚠ Safety

- Keep fingers and hands away from the blade path and cutting edge.
- Wear safety goggles and do not hold the workpiece in your hand while cutting.
- Never use a saw with a loose handle or damaged blade.
- Carry and store the saw with its teeth protected.

Care & storage

- Brush off sawdust, keep the blade dry, and store it with a suitable blade guard.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.