3D Printer Bed Leveling Tool



Category: **Computers, IT & Office** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Bed leveling tools

What it is used for

A 3D printer bed leveling tool helps check the distance or alignment between the nozzle and build plate. Use the tool specified for the printer and follow its leveling procedure.

How to use

1. Check the leveling tool for damage and confirm it suits the printer model.
2. Allow the printer to reach the required temperature if its instructions specify heated leveling.
3. Home the printer axes using the approved control procedure.
4. Move the nozzle to the specified checking positions without touching hot parts.
5. Use the leveling tool or gauge to check the nozzle-to-bed gap.
6. Adjust leveling points gradually according to the manufacturer's procedure.
7. Repeat the checks and confirm the build plate is evenly aligned.

⚠ Safety

- Keep fingers away from hot nozzles, heated beds, and moving axes.
- Do not force the nozzle against the build plate or leveling tool.
- Follow power isolation instructions before manual adjustments near electrical components.

Care & storage

- Clean the tool after use and store it safely away from heat and dust.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.