Desoldering Pump



Category: **Welding & Soldering** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: De-soldering pump

What it is used for

A desoldering pump removes molten solder from a joint to help release electronic components. Use it with a suitable soldering iron and protect nearby components from heat.

How to use

1. Inspect the pump plunger, nozzle, seal, and release mechanism for damage.
2. Switch off and prepare the soldering iron according to its instructions.
3. Position the pump nozzle near the solder joint without touching nearby components.
4. Heat the joint until the solder melts, avoiding prolonged heating.
5. Trigger the pump to draw molten solder into its chamber.
6. Allow the joint and components to cool before checking or removing the part.
7. Empty and clean the pump according to its design after use.

⚠ Safety

- Wear eye protection and work in a well-ventilated area.
- Keep the hot soldering iron and molten solder away from skin and cables.
- Do not touch the nozzle immediately after use.
- Disconnect power before cleaning or servicing the soldering iron.

Care & storage

- Clean solder residue from the pump and inspect the seal and nozzle regularly.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.