Offset Rod



Category: **Measuring & Marking Tools** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Offset rod

What it is used for

An offset rod helps transfer or mark offset positions during surveying, layout, or alignment tasks. Use it with the relevant measuring equipment and follow the project's measurement procedure.

How to use

1. Inspect the rod for bending, damaged markings, loose fittings, or worn tips.
2. Confirm the required offset and measurement reference before starting.
3. Position the rod at the designated point according to the layout plan.
4. Align the rod with the required reference line or measuring instrument.
5. Take and record the reading or mark the offset as specified.
6. Repeat the measurement to confirm accuracy when required.
7. Clean the rod and store it securely after use.

⚠ Safety

- Keep the rod clear of overhead electrical lines and nearby machinery.
- Use stable footing and avoid unprotected edges or uneven ground.
- Do not use a bent or damaged rod for precision measurements.
- Keep the work area clear of pedestrians and moving vehicles.

Care & storage

- Wipe the rod clean, protect its markings, and store it in a dry location.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.