Pattern Notcher



Category: **Sewing, Textile & Handicraft** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Hand notcher (pattern notcher)

What it is used for

A hand pattern notcher makes small notches in pattern paper or suitable marking material to identify construction points. Use the correct notch type and keep the tool aligned with the pattern marks.

How to use

1. Inspect the notcher, cutting edges, handle, and pivot for damage or looseness.
2. Place the pattern on a stable, suitable cutting surface.
3. Identify the required notch positions and confirm the pattern orientation.
4. Align the notcher with each marked position and hold the pattern securely.
5. Squeeze or operate the tool to make the required notch without damaging nearby lines.
6. Check the notches for consistency and confirm that pattern markings remain readable.
7. Clean the tool and store it safely after use.

⚠ Safety

- Keep fingers clear of the cutting edges and moving joints.
- Do not use a damaged or loose notcher.
- Use the tool only on suitable pattern materials, not on skin or unsupported hard objects.
- Store the tool closed or protected when possible.

Care & storage

- Remove paper fibres and dust and keep the cutting edges dry and protected.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.