RF Module



Category: **Electrical & Electronic Components & Kits** Type: **Short SOP** Priority: **Medium**

1 labs

Covers these lab items: RF Transmitter and receiver

What it is used for

An RF transmitter and receiver send and receive radio-frequency signals for compatible electronic communication experiments. Verify frequency, supply requirements, antenna connections, and applicable radio-use restrictions before testing.

How to use

1. Inspect the transmitter, receiver, antenna connections, power leads, and circuit board.
2. Read the datasheets to confirm frequency band, voltage, pinout, and compatible communication protocol.
3. Switch off power before making wiring connections.
4. Connect the modules to the controller or test circuit according to the wiring diagram.
5. Check antenna placement, grounding requirements, and supply polarity.
6. Power the modules using specified ratings and send a test signal.
7. Verify reception at the receiver and disconnect power after testing.

⚠ Safety

- Do not exceed the modules' voltage or current ratings.
- Use only permitted frequencies and comply with applicable radio regulations.
- Keep antennas and wiring away from hazardous electrical equipment.
- Avoid short circuits and disconnect power before changing connections.

Care & storage

- Store modules in antistatic packaging and protect antenna connectors from damage.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.