Torque Screwdriver



Category: **Hand Tools - Fastening & Gripping** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Torque Screwdriver

What it is used for

A torque screwdriver tightens screws to a specified torque to help prevent loose joints and over-tightening. Select the correct torque range and follow the manufacturer's instructions for adjustment and use.

How to use

1. Inspect the screwdriver, handle, bit, and adjustment mechanism for damage.
2. Select a compatible bit that fits the screw head correctly.
3. Set the required torque according to the equipment specification.
4. Secure the workpiece and align the bit with the screw axis.
5. Turn the screwdriver smoothly until the torque indicator or release mechanism signals the set value.
6. Stop applying force when the specified torque is reached.
7. Reset and store the tool according to the manufacturer's instructions.

⚠ Safety

- Use the correct torque range and never exceed the tool's rating.
- Keep the bit fully seated to prevent slipping and screw damage.
- Do not use a damaged tool or improvised extensions.
- Wear eye protection when required by the task.

Care & storage

- Keep the tool clean, store it securely, and arrange calibration at the recommended interval.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.