# Transmission Assembly

Category: **Automotive** Type: **Short SOP** Priority: **Medium** 1 labs

**Covers these lab items:** Transmission /Transaxle

## What it is used for

A transmission or transaxle assembly transfers engine power to the vehicle's drive wheels and provides the required gear ratios. Inspect, handle, and demonstrate the assembly using approved workshop procedures and suitable lifting equipment.

## How to use

1. Confirm the assembly identity, specifications, and intended training or service task.
2. Inspect the casing, shafts, mounts, connectors, and visible components for damage or leaks.
3. Secure the assembly on a suitable work stand or approved lifting support.
4. Review the relevant service manual before disassembly, inspection, or adjustment.
5. Use appropriate tools to demonstrate component identification and power-transfer functions.
6. Check fluid requirements and inspect seals or connections according to the service procedure.
7. Clean the work area and record any faults or maintenance actions.

## ⚠ Safety

- Never work beneath an unsupported vehicle or suspended transmission assembly.
- Use rated lifting equipment and approved lifting points.
- Keep hands clear of pinch points and rotating components.
- Drain and handle transmission fluids according to workshop safety and disposal rules.

## Care & storage

- Protect machined surfaces and openings from contamination, and store the assembly securely when not in use.

*Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.*