Under Vehicle Inspection Mirror



Category: **Safety & PPE** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Under Chassis Inspection Mirror (UCIM)

What it is used for

An under-vehicle inspection mirror helps inspect areas beneath a vehicle that are difficult to view directly. Use it from a safe position to check for visible leaks, damage, or loose components.

How to use

1. Inspect the mirror, handle, adjustment joint, and any built-in light for damage.
2. Park the vehicle on a level surface, apply the parking brake, and secure it against movement.
3. Switch off the engine and allow hot components to cool where practical.
4. Adjust the mirror angle and lighting before positioning it beneath the vehicle.
5. Inspect visible areas from outside the vehicle's underside clearance.
6. Record any suspected leaks, damage, or loose components for qualified follow-up.
7. Clean the mirror and return it to its storage location.

⚠ Safety

- Never crawl beneath a vehicle supported only by a jack.
- Keep hands and the mirror clear of moving parts and hot exhaust components.
- Do not inspect beneath a running vehicle unless an approved procedure specifically requires it.
- Use suitable lighting and personal protective equipment where necessary.

Care & storage

- Clean the mirror with a suitable cloth and store it where the reflective surface will not be scratched.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.