Vacuum Gauge



Category: **Measuring & Marking Tools** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Micron Gauge

What it is used for

A micron vacuum gauge measures very low absolute pressure in vacuum systems, including refrigeration and related service applications. Connect it correctly and follow the gauge manufacturer's instructions for accurate readings.

How to use

1. Inspect the gauge, sensor, connectors, battery, and display for damage.
2. Confirm the gauge's measurement range and compatibility with the system and refrigerant service setup.
3. Ensure the system is isolated and follow the approved service procedure before connecting the gauge.
4. Attach the sensor to the designated measurement port using clean, suitable connections.
5. Switch on the gauge and allow the reading to stabilize as specified.
6. Monitor and record the pressure reading, checking for unexpected fluctuations or leaks.
7. Disconnect the gauge safely, fit protective caps, and store the sensor clean and dry.

⚠ Safety

- Follow approved refrigeration or vacuum-system service procedures and applicable refrigerant rules.
- Do not expose the gauge to pressure or chemicals beyond its rating.
- Avoid contaminating the sensor with oil, moisture, or debris.
- Isolate equipment before servicing connections where required.

Care & storage

- Clean the sensor according to the manufacturer instructions and replace batteries when needed.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.