Oil Filter

Category: **Automotive** Type: **Handling note** Priority: **Low** 6 labs

Covers these lab items: Oil filter; Oil filters

What it is used for

Automotive oil filters remove contaminants from engine oil to help protect lubricated engine components.

How to handle

- Confirm the correct filter specification and vehicle compatibility before replacement.
- Switch off the engine and allow hot parts and oil to cool safely.
- Use suitable tools and follow the vehicle manufacturer's replacement procedure.
- Check the sealing surface and gasket; lubricate the seal if the manufacturer specifies.
- Dispose of used filters and drained oil according to local environmental requirements.

Storage

- Keep new filters sealed in clean, dry packaging.
- Store away from moisture, dust, crushing, and extreme temperatures.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.