Spark Plug

Category: **Automotive** Type: **Handling note** Priority: **Low** 5 labs

Covers these lab items: spark plug; Spark plugs

What it is used for

Spark plugs ignite the air-fuel mixture in compatible spark-ignition engines.

How to handle

- Confirm the correct plug type, thread size, heat range, and gap specification for the engine.
- Allow the engine to cool and disconnect the ignition system as specified before servicing.
- Inspect the electrode and ceramic insulator for cracks, deposits, or damage.
- Use the correct socket and tightening torque specified by the vehicle manufacturer.
- Keep removed plugs organised and dispose of damaged plugs safely.

Storage

- Store new spark plugs in their original protective packaging.
- Keep them dry and protect the ceramic insulator and threads from impact or contamination.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.