Radiator Pressure Cap

Category: **Automotive** Type: **Handling note** Priority: **Low** 4 labs

Covers these lab items: Old second hand pressure cap

What it is used for

A radiator pressure cap regulates cooling-system pressure and helps maintain the correct coolant-system seal.

How to handle

- Never remove the cap while the engine or coolant is hot or pressurised.
- Allow the engine to cool completely and follow the vehicle manufacturer's service procedure.
- Inspect the cap seal, spring, and locking features for damage or corrosion.
- Use only the specified cap rating and compatible replacement part.
- If the cap is from a used vehicle, treat it as a training sample unless it has been inspected and tested before reuse.

Storage

- Store the cap clean and dry in a labelled container.
- Protect the sealing surface and spring from dirt, corrosion, and impact.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.