

Welcome to EnkTel IPTV

Stream Beyond Limits. One subscription, every screen you own — TV, phone, tablet, computer and browser.

BEFORE YOU START

Four ways to watch

Your subscription is one login that works on everything you own. There is no app store to search and no account to create — the username and password on your welcome email are the whole of it. This guide shows you each way to watch, in the order most people set them up.

01 The web player

watch.enktel.tv

Nothing to install. Open a browser, sign in, and watch. Start here to check your line works before you set anything else up.

02 Phone & tablet

Android APK

The full app, including downloads for offline watching on a plane or a commute.

03 TV & Fire Stick

Android TV APK

The same app, laid out for a remote control and a room-sized screen.

04 Windows PC

Installer

A desktop player, and the other half of Send to PC — it pulls finished downloads off your phone over your own Wi-Fi.

Your login is the same everywhere. One username and password, on as many devices as your package allows streams. Setting up a second device never means a second account.

What you need

Your details	Username and password — on your welcome email.
Every download	https://github.com/Enkinuri666/enktel/releases/latest
Web player	Any modern browser. Nothing to install.
Phone / tablet	Android 6.0 or newer.
TV / Fire Stick	Fire TV, Fire Stick, or any Android TV box.
Windows PC	Windows 10 or 11, 64-bit.

01 WATCH.ENKTEL.TV

The web player

No installation, no waiting. If you can open a browser you can watch — which makes this the fastest way to confirm your line is live.

Setting it up

- 1 Go to **watch.enktel.tv** in any browser.
- 2 Enter the **username** and **password** from your welcome email. The server address is already filled in, so most people only type two things.
- 3 Press **Sign In**. Your channels, films and series load straight away.

Signing in here proves the line itself is working. If the web player plays and an app does not, the problem is that device's setup — not your subscription.

What you will see




Fig 1 Sign in

Two fields and a button. **Advanced** is there for a different server, an M3U playlist or a Stalker portal, and most people never open it.




Fig 2 Home

Live TV, Movies and Series in rows, with your most recent activity first.




Fig 3 Live TV

Every channel your package carries, grouped by country and genre.




Fig 4 Movies

The on-demand library, filterable by category and year.




Fig 5 Series
Box sets, organised by season and episode.




Fig 6 Settings
Playback, appearance and account, in one place.

Phone and tablet

The full app. Everything the web player does, plus downloads you can watch with no signal at all — and the ability to hand those downloads to your PC.

Setting it up

- 1 On the phone, allow installing apps from your browser when Android asks.
- 2 Open <https://github.com/Enkinuri666/enktel/releases/download/v1.71.0/enktel-mobile-1.71.0.apk> in the phone's browser and install it.
- 3 Open EnkTel and enter the **username** and **password** from your welcome email. The server is already set.
- 4 Give it a moment on first run while the channel list and guide load.

Downloads keep running when you leave the screen or switch apps — the app holds a foreground service so Android cannot quietly stop them.

What you will see




Fig 7 Signing in

Two fields, and the server is already set. On a different provider, or holding a setup link instead? Open the extra line and paste it — the app reads the server and the login out of it.




Fig 8 Home

What you land on. Live TV, Movies, Series and Sports, plus a search that looks in all of them — and how long your line has left, without going looking for it.




Fig 9 Downloads

Films and episodes saved to the device. Each one shows progress, speed and where it was saved; the folder button opens it, and **Send to PC** hands the finished ones to your computer.




Fig 10 Search

One box for all of it. Type a team, a film, a channel name or its number and the results come back in rows — channels, sport, films, box sets and the guide — with a live match showing which channel it is on and whether it has started.




Fig 11 More

The menu keeps six things on it. Everything else — the TV guide, your watchlist, recordings, catch-up — is in here, each one saying what it is for.

TV, Fire Stick and Android TV

The same application, built for a remote instead of a fingertip: bigger targets, a focus ring you can follow from the sofa, and a layout that respects the overscan a television crops.

Setting it up

- 1 On a Fire TV, install **Downloader** from the Amazon appstore. On other Android TV boxes, use whichever sideloading tool you already have.
- 2 Enter <https://github.com/Enkinuri666/enktel/releases/latest> — short enough to type on a remote, and it always points at the current build.
- 3 On the page that opens, choose the file whose name contains **-tv-**. The **-mobile-** one is for phones and will look wrong on a television.
- 4 Install, then open EnkTel from your apps row.
- 5 Sign in with the same **username** and **password**. One subscription covers every device.

Use the **tv** APK on a television and the **mobile** APK on a phone. They are the same app with different layouts, and installing the wrong one is the single most common setup mistake.

What you will see




Fig 12 Signing in on TV

The same two fields, sized for a room rather than a hand. Two short words on a remote beats a hundred-character link.




Fig 13 Home on TV

The same four categories, as tiles big enough to pick out from the sofa. The one under the focus ring lifts and lights up in its own colour.




Fig 14 Search on TV

The same one box. A team name finds the match, says which channel has it and whether it is on now — rather than leaving you to scroll the guide looking for it.




Fig 15 Downloads on TV

Saved films and episodes, navigable entirely with a remote.

Windows PC

A desktop player in its own right — and the other half of Send to PC, which moves finished downloads off your phone and onto your computer over your own Wi-Fi, with nothing going near the internet.

Setting it up

- 1 Download the installer from <https://github.com/Enkinuri666/enkotel/releases/latest> and run it. Windows will warn about an unrecognised app: choose **More info**, then **Run anyway**.
- 2 Open EnkTel and enter the same **username** and **password** from your welcome email. The server is already set here too.
- 3 For Send to PC: on the phone open **Downloads** and press **Send to PC**. It shows an address and a six-digit PIN.
- 4 On the PC open **My devices**. It finds the phone by itself — pick it, type the PIN, choose a folder, and press **Get all**.

A transfer that is interrupted resumes from the byte it reached rather than starting the film again, and the PIN is new every time sharing starts.

What you will see




Fig 16 Signing in

The same two fields as the phone and the television — deliberately, because one subscriber should not be walked through two different setups for the same account.




Fig 17 Home

A featured title, quick links, and themed rows built from your own library.




Fig 18 Live TV

The full channel list with categories down the side.




Fig 19 Movies

The on-demand library at desktop scale.




Fig 20 Series

Box sets, by season.




Fig 21 My devices — finding the phone

The PC looks for devices that are sharing, so there is no address to read off a television and retype.




Fig 22 My devices — connected

Finished downloads ready to copy across, and the phone's own download queue, which you can pause, resume, retry or cancel from here.




Fig 23 Settings

Playback, appearance and account.

If something goes wrong

Most setup problems are one of the six below, and the first check narrows it down faster than anything else.

Nothing plays on any device

Check the web player first at **watch.enktel.tv**. If that fails too, the line itself needs attention — contact support with your username.

It plays in the browser but not in the app

That device has the wrong server address or the wrong APK. Re-enter the details exactly as they appear on the web player's Advanced panel.

The PC cannot find my phone

Both devices must be on the same Wi-Fi, and the phone must be showing a PIN. Some routers block devices from seeing each other — look for “AP isolation” or “client isolation” and turn it off. Failing that, type the address the phone is showing into the box under the device list; that always works.

Send to PC will not start on mobile data

That is deliberate. On mobile data the “local network” is your carrier's, and the app will not open a server onto it. Join Wi-Fi and try again.

A download stopped when I left the app

It should not — downloads and sharing both run as foreground services. If it does, check the phone's battery optimisation settings and exempt EnkTel.

Buffering on live channels

Try another stream for the same channel from the channel's menu, then **Settings** → **Playback** to raise the buffer. On a Fire Stick, closing other apps frees the memory the decoder needs.

Still stuck? Contact support with your username and which device you are on. Do not send your password — nobody at EnkTel will ask for it.