

### **SPACE LAUNCH SYSTEM**

## START -1

# USER'S HANDBOOK VOLUME I: SPACECRAFT & LAUNCH VEHICLE INTERFACES





# START-1 Users Handbook Volume I:

# **Document Change Record**

Issue Number	Date	Revisions	Approvals
Initial Release			Zinchenko
Issue 1	May 31, 2002	Update Version	Dubyn

Issue 1, May 2002 DCR-1



### **TABLE OF CONTENTS**

Αb	brevi	ationsi	V
Lis	st of T	ables	V
Lis	st of F	iguresv	⁄i
IN <sup>.</sup>	TROD	UCTION	1
1.	S	TART-1 LAUNCH VEHICLE DESCRIPTION	2
1	I.1	General	
1	1.2	Launch Vehicle Design and Spacecraft Accommodation2	
	1.2.1	Boost Stages	5
	1.2.2	Post-boost Propulsion System and Propulsion Module	5
	1.2.3	Sealed Instrumentation Compartment Onboard Guidance and Control	
	Syst	em	5
	1.2.4	Head Module, Payload Accommodation	6
1	1.3	Transport-and-Launch Canister 6	
1	1.4	Flight Termination System 6	
1	1.5	Telemetry and Trajectory Measurement Systems 7	
1	1.6	Launch Vehicle Reliability13	
2	LAU	INCH VEHICLE PERFORMANCE DATA10	6
2	2.1	Coordinate System16	
2	2.2	Flight Sequence16	
2	2.3	Flight Performance	
2	2.4	Spacecraft Injection Accuracy 19	
2	2.5	Attitude, Linear and Angular Velocities of Spacecraft after Separation 19	
3	MEC	HANICAL AND ELECTRICAL INTERFACES BETWEEN LV AND SC 29	5
3	3.1	Mechanical Interface	
	3.1.1	Head Module29	5
	3.1.2	2 Adapter 25	5
	3.1.3	32 Fairing	2
	3.1.4	Spacecraft Access3	2



	3.1.5	Optional Services	33
	3.2 E	Electrical Interface between Spacecraft and Launch Vehicle3	3
	3.2.1	Electrical Connections	33
	3.2.2	Spacecraft Grounding	35
	3.3.1	Standard Information Interface	35
	3.3.2	Optional Services	35
	3.4	Telemetry Interface between Spacecraft and Launch Vehicle35	5
	3.4.1	Spacecraft Ground Monitoring during Pre-launch Operations	35
	3.4.2	Telemetry Monitoring at Injection Phase	35
	3.4.3	Optional Services	35
4	SPAC	ECRAFT ENVIRONMENTS	37
	4.1 F	Flight Accelerations 37	7
	4.2	Spacecraft Angular Velocities & Accelerations in LV Flight 39	9
	4.3	/ibrations39	9
	4.3.1	Acoustic Noise	39
	4.3.2	Steady-state Vibrations	41
	4.3.3	Vibro-Shock Loads	44
	4.4	Spacecraft Thermal Environments48	3
	4.4.1	General	48
	4.4.2	Optional Services	48
	4.4.3	Temperature inside Fairing at Injection Phase	48
	4.5 F	Pressure Change inside Fairing in Flight50	)
	4.6 E	Environment Cleanliness Requirements5	1
	4.6.1	Cleanliness Environment during Pre-launch Preparation	51
	4.6.2	Cleanliness Environment at Injection Phase	51
	4.7 F	Radio-frequency and Electromagnetic Environment at Pre-launch	
	Prepara	ation and Launch5 <sup>2</sup>	1
	4.7.1	Spacecraft Radio-frequency and Electromagnetic Environment during	
	Pre-la	unch Preparation	52
	4.7.2	Radio-frequency and Electromagnetic Environment in Flight	55
5	PAYL	OAD LIMITATIONS	58



5.1	Center of Mass Limitations	58
5.2	LV Angular Position Limitations at SC Separation Point	58
5.3	Spacecraft Structure Rigidity	58
5.4	Electromagnetic Compatibility Limitations	58
5.5	Safety Limitations	59
6 DO	CUMENTATION	60
7 MIS	SION ANALYSIS	61
7.1	General	61
7.2	Requirements for Spacecraft Mathematical Model for Coupled Dynamics	nic
Analy	/sis	61

Issue 1, May 2002 iii



#### **Abbreviations**

AFTS – autonomous flight termination system

ATB – assembly and test building

EGSE – electronic ground support equipment

GCS – guidance and control system

GPS - Global Positioning System

GRACS – gas-reaction attitude control system

HM - head module

ICBM – intercontinental ballistic missile

IS – interstage section

LV – launch vehicle

MIHT – Moscow Institute of Heat Technology

MS – measurement system

PBPS – post-boost propulsion system

PM – propulsion module

SC - spacecraft

SLS – Space Launch System

SPHGG – solid-propellant hot-gas generator

TLC – transport-and-launch canister

TEGSE – transponder electronic ground support equipment

UP – panels of umbilical plugs



### **List of Tables**

Table	Name	Page
1-1	Commercial launches from the Svobodny Cosmodrome	15
2-1	The injected payload mass dependence of the circular orbit altitude for different launch points and inclinations	18
2-2	Deviations of spacecraft orbital parameters	19
4-1	Start-1 LV flight accelerations (max. values for 240 kg spacecraft)	37
4-2	Acoustical noise spectrum	40
4-3	Power spectral density for qualification testing	42
4-4	Power spectral density for acceptance testing	43
4-5	Normalized pattern of onboard telemetry system antenna	56
4-6	Normalized pattern of onboard transponder antenna	57



# **List of Figures**

Figure	Name	Page
1-1	Start-1 Launch Vehicle	3
1-2	Start-1 Launch Vehicle exploded view	4
1-3	Payload accommodation	8
1-4	Start-1 Launch Vehicle in TLC on Launch Stand	9
1-5	Start-1 Launch Vehicle in launch position	10
1-6	Mobile launcher with Start-1 Launch Vehicle in pre-launch position	11
1-7	Start-1 Launch Vehicle on mobile launcher in vertical position	12
2-1	LV coordinate system	17
2-2	The injected payload mass dependence of the circular orbit altitude.  Launches from the Svobodny Cosmodrome	20
2-3	Start-1 LV flight sequence during SC injection into sun-synchronous orbit for launches from the Svobodny Cosmodrome	21
2-4	Start-1 LV burn sequence during SC injection into sun-synchronous orbit for launched from Svobodny Cosmodrome	22
2-5	Start-1 LV flight sequence (without PBPS) during SC injection into sunsynchronous orbit for launches from Svobodny Cosmodrome	23
2-6	Start-1 LV burn sequence (without PBPS) during SC injection into sun-synchronous orbit for launched from Svobodny Cosmodrome	24
3-1	Start-1 LV Head Module	26
3-2	Adapter design	27
3-3	Start-1 LV standard adapter	28
3-4	Start-1 LV standard adapter. View A.	29
3-5	Start-1 LV standard adapter. Cross Section B–B	30
3-6	Separation sensors. Start-1 LV standard adapter. Cross Section C–C	31
3-7	Electrical connections between SC integrated with HM and SC ground support equipment	33



Figure	Name	Page
3-8	Electrical connections between SC integrated with LV and SC ground support equipment	34
4-1	The maximum longitudinal acceleration dependence of the SC mass for the 4 <sup>th</sup> Stage	38
4-2	Acoustic noise spectrum	40
4-3	Power spectral density for qualification testing	42
4-4	Power spectral density for acceptance testing	43
4-5	Launch Vehicle ejection from TLC	45
4-6	1 <sup>st</sup> Stage motor firing	45
4-7	2 <sup>nd</sup> Stage motor firing	46
4-8	3 <sup>rd</sup> Stage motor firing	46
4-9	4 <sup>th</sup> Stage motor firing	47
4-10	Shock spectrum	47
4-11	The fairing internal surface temperature versus the LV flight time	49
4-12	The radiation heating flow from the fairing internal surface versus the flight time	49
4-13	Pressure profile inside the fairing in flight	50
4-14	Antenna location on the LV body	53
4-15	Measuring of normalized antenna pattern angles	54

Issue 1, May 2002 vii



#### INTRODUCTION

The multipurpose transportable Start-1 Space Launch System is intended for injection of small spacecraft into low earth orbits.

The Start-1 Space Launch System (SLS) includes the Launch Vehicle (LV), equipment for transportation of LV and launch system elements, and launch processing equipment necessary for Launch Vehicle/Spacecraft integration, final preparation and launch.

The solid-propellant Start-1 LV was developed in the early 1990s under conversion of rocket technologies by a group of Russian enterprises leaded by Scientific and Technological Center "Complex-MIHT".

The Launch Vehicle and its systems, as well as ground launch equipment and processing equipment were developed using elements, components and technologies for missile systems from the SS-25 ICBM, which ensures very high reliability.

This Start-1 Launch Vehicle User's Handbook consists of two Volumes:

**Volume 1: Launch Vehicle & Spacecraft Interfaces** 

**Volume 2: Pre-launch Preparation, Launch & Cosmodrome Operations** 

The Users Handbook is administered by United Start Corporation out of Los Angeles, CA and Puskovie Uslugi out of Moscow Russia.



#### 1. START-1 LAUNCH VEHICLE DESCRIPTION

#### 1.1 General

Launch Vehicle performance data are as follows:

LV type	Solid-propellant vehicle
Number of stages	4
Lift-off weight	47 ton
Maximum diameter	1.8 meter
Length	22.7 meter
Launching mode	Cold starting from a transport-and-launching canister using solid-propellant hot gas generator
Launcher	<ul> <li>Autonomous launching system based on 7-axis undercarriage</li> <li>Launch stand</li> </ul>

#### 1.2 Launch Vehicle Design and Spacecraft Accommodation

The Start-1 solid-propellant launch vehicle (Fig. 1-1 and Fig. 1-2) consists of four inline boost stages and a post-boost propulsion system.

The boost stages inject a spacecraft into a pre-determined orbit. The post-boost propulsion system provides accurate spacecraft placement in the orbit.


The boost stages are connected to one another by interstage sections (IS1, IS2, and IS3), and a post-boost propulsion system located inside the 3<sup>rd</sup> Interstage Section (IS3). The post boost propulsion system after its burnout is not separated from 4<sup>th</sup> stage.

#### LV upper section includes:

- Head module (HM) which includes spacecraft (SC), adapter and fairing
- Platform on which a sealed instrumentation compartment and set of guidance and control system equipment are installed
- Propulsion module (PM) in which the post-boost propulsion system and some units of guidance and control system (GCS) are installed

• Interstage section IS4.





- 1 Head Module
- 2 Platform
- 3 Guidance and Control System Compartment
- 4 Propulsion Module with
  - Post-boost Propulsion System
- 5 Interstage Section 4
- 6 4<sup>th</sup> Boost Stage
- 7 Interstage Section 3
- 8 3<sup>rd</sup> Boost Stage
- 9 Interstage Section 2
- 10 2<sup>nd</sup> Boost Stage
- 11 Interstage Section 1
- 12 1<sup>st</sup> Boost Stage
- 13 Aft Section with
  - air vanes, fins and gas vanes

Fig. 1-1. Start-1 Launch Vehicle (Dimensions in mm)






Fig.1-2. Start-1 LV exploded view



#### 1.2.1 Boost Stages

The motor of each boost stage utilizes a composite solid propellant.

Various composite materials are used in boost stage design.

All boost stages are equipped with gas-dynamic controls in pitch, yaw and roll. 1<sup>st</sup> boost stage is equipped with both gas vanes and air vanes.

Gas-reaction attitude control system (GRACS) is located at the aft section of the 4<sup>th</sup> Boost Stage. The working medium of this system is pressurized nitrogen.

#### 1.2.2 Post-boost Propulsion System and Propulsion Module

The post-boost propulsion system (PBPS) is provided to achieve required values of SC kinematic parameters at SC separation point in the final flight phase. The PBPS includes a solid-propellant gas generator, ducting, and three pairs of push-operated nozzle assemblies which are installed such that burnt products flow out in a direction opposite to the spacecraft location. These nozzle assemblies are placed outside the propulsion module and are sheltered by local protective covers.

On the side surface of the instrumentation compartment body there are two panels of umbilical plugs (UP-1) that are used to communicate onboard equipment (GCS and LV measuring system) with electronic ground support equipment (EGSE).

In case there are no hard requirements for orbit altitude insertion accuracy, the Start-1 LV without PBPS can be used to increase overall SC mass to be injected.

# 1.2.3 Sealed Instrumentation Compartment Onboard Guidance and Control System

The launch vehicle flight is controlled by autonomous inertial guidance system. The gyrostabilized platform with measuring instrumentation of GCS produces data on LV attitude and acceleration of center of mass. The onboard computer controls the flight according to the prescribed flight mission.

The main units of the GCS equipment are placed in a sealed instrumentation compartment that is installed inside the platform. Electrical connectors for onboard GCS instrument communication with LV units and EGSE are placed on rear bottom of the sealed



instrumentation compartment. On side surface of the sealed instrumentation compartment there is an optically transparent window of the aiming system.

Also on the side surface of the instrumentation compartment body there is a panel with an umbilical plug (UP-2) that is used to communicate the SC onboard equipment with EGSE for SC maintenance.

On the front ring of the platform the attachment fittings for the head module mounting are placed.

#### 1.2.4 Head Module, Payload Accommodation

The head module is an assembled unit that includes spacecraft, adapter, and fairing. It is mounted on the front end-face of the platform (see Fig. 3-1).

Head module design provides the environmental conditions required for the SC during ground operations and during ascent, up to fairing separation. The LV design and its operation mode in flight exclude SC surface contamination by exhaust products from boost stage pyrotechnical devices, retro boost motors, post-boost stage, and stage separation assemblies.

The dynamic envelope that bounds the available payload volume is shown in Fig. 1-3.

#### 1.3 Transport-and-Launch Canister

The launch vehicle is transported and launched from a mobile transport-and-launch canister (TLC). The TLC protects LV from casual mechanical damages and along with systems of ground launch complex provides humidity-and-temperature conditions during all phases of LV operating. The LV is fixed in the TLC by sabots and seal sabots.

The TLC is placed on launch stand (Fig. 1-4 and Fig. 1-5) or mobile launcher based on undercarriage (Fig. 1-6 and Fig 1-7).

#### 1.4 Flight Termination System

The Start-1 LV is equipped with an autonomous flight termination system (AFTS).

LV flight is terminated autonomously by the onboard GCS when LV angular error exceeds a programmable value on any of the axes. LV attitude analysis is performed by onboard



computer using data obtained from gyro-stabilized platform attitude sensors. In case of computer failure the AFTS command is generated for extended angles at the closing of limit contacts placed on gyro-stabilized platform frames.

#### 1.5 Telemetry and Trajectory Measurement Systems

The LV measurement system provides acquisition, transmission, and recording of data on operation of the LV units and systems during pre-launch preparations and LV flight as well as transmission of flight parameters, LV GCS operation and spacecraft separation.

The measurement system (MS) consists of:

- radio-telemetry equipment and its operation control instrumentation;
- autonomous power supply system
- antenna and feeder devices.






Fig. 1-3. Payload accommodation






Fig. 1-4. Start-1 Launch Vehicle in TLC on Launch Stand






Fig. 1-5. Start-1 Launch Vehicle in launch position






Fig. 1-6. Mobile launcher with Start-1 Launch Vehicle in pre-launch position






Fig. 1-7. Start-1 Launch Vehicle on mobile launcher in vertical position



Trajectory parameters are measured by onboard equipment providing communication with both GLONASS and GPS satellite navigation systems. The LV can be equipped with an onboard receiver-transmitter of trajectory measuring system as well.

Radio-telemetry system operates in the following modulation modes. Transmitter uses pulse-frequency modulation of carrier frequency. The first switching stage operates in pulse-amplitude modulation mode. The second switching stage operates in pulse-code modulation mode. Transmitter operates at a frequency of 203 MHz or 219 MHz. Transmitter power is 15-40 W.

The onboard receiver-transmitter operates in centimeter-wave band and transmitter power is about 2 W.

Spacecraft separation is monitored by LV systems via two contact sensors installed on the Adapter.

The LV onboard equipment does not provide SC telemetry downlink in flight for LV standard configuration.

As an option, it is possible to use the LV telemetry equipment for data transmission on SC functions. The number of transmitted parameters and sampling rate, electrical connections between LV and SC, parameters from sensors installed on SC, and other proposals associated with operating of the LV telemetry equipment to be used for downlink can be agreed upon by the spacecraft developer with STC "Complex-MIHT".

#### 1.6 Launch Vehicle Reliability

The Start-1 LV reliability is supported through design and development work, theoretical investigation and calculations, manufacturing and technology activities conformable to International Standard ISO 9000-9004. These activities have been used and proven highly effective during testing, manufacturing and operation of the Start-1 ballastic missile-prototypes.

All key structural elements of the Start-1 LV have passed full ground tests including more than 30 firing tests for each type of motor.

Long term reliability of elements and systems of the Start-1 launch equipment has been proven by more than 60 flight tests of the SS-25 missile.

Reliability and validity of estimation methods used for LV reliability and also efficiency of reliability control had been confirmed by accumulated experience relating to the reliability estimation for ballastic missiles and more than 300 launches of the SS-20 and SS-25



#### missiles.

Serviceability of the Start-1 LV was proven by its successful demonstration launch from Plesetsk Cosmodrome on March 25, 1993 and its successful commercial launches from Svobodny Cosmodome on March 4, 1997, December 24, 1997, December 5, 2000, and February 20, 2001 (See Table 1-1).

**Table 1-1**Commercial launches from Svobodny Cosmodrome

		SC mass	Start-1 Launch Vehicle Injection accuracy								
			Mean orbit altitude			Orbit inclination, deg.			Orbital period		
Launch date	Spacecraft	kg	Predicted parameters (nominal)	Allowable deviations (2.7σ)	Factual deviations	Predicted parameters (nominal)	Allowable deviations (2.7σ)	Factual deviations	Predicted parameters (nominal)	Allowable deviations (2.7σ)	Factual deviation
March 4, 1997	Zeya (Russia) Radio communications	87	490.4	±5	-1.4 / +0.9	97.27	±0.05	+0.01	5647.8	±2.5	-0.16
December 24, 1997	EarlyBird-1, EWI (USA) Earth observation	310	479.2	±5	+0.1	97.30	±0.05	+0.006	5642.7	±2.5	0.0
December 5, 2000	EROS-A1, ISI (Israel) Earth observation	247	493.9	±5	-0.1	97.33	±0.05	-0.001	5660.6	±2.5	-0.1
February 20, 2001	ODIN, SSC (Sweden) Scientific researches	240	611.5	±5	-0.5	97.83	±0.05	+0.01	5806.7	±2.5	-0.6



#### 2 LAUNCH VEHICLE PERFORMANCE DATA

#### 2.1 Coordinate System

The accepted coordinate system for the LV is shown in Fig. 2-1.

The  $X_1$  axis is directed along the LV's longitudinal axis.  $X_1$  positive direction coincides with flight direction.

The Y<sub>1</sub> axis lies in the I-III vertical plane and is directed upward along the III base line.

The  $Z_1$  axis completes the right-handed coordinate system. It lies in the II-IV horizontal plane and its positive direction coincides with the IV base line.

#### 2.2 Flight Sequence

Launch procedures are initiated at the point when the "fire" command is generated to the launch equipment. At this point the TLC with the LV is in a horizontal position on the launch stand (see Fig. 1-4) or on the autonomous launch stand (see Fig. 1-6).

Countdown cycle continues a few minutes. Then the TLC with LV is elevated into a vertical position. During elevation the spacecraft communications with ground support equipment are detached. After the TLC is in vertical position the LV mechanical links with TLC are detached and the solid-propellant hot gas generator is ignited to launch the LV from launch stand (Fig. 1-5) or mobile launcher (Fig. 1-7).

LV is ejected from TLC by pressure of a solid-propellant hot gas generator (SPHGG) system. The UP-1, which communicates ground support equipment with onboard GCS equipment and the LV measurement system, is detached via LV motion.

When the LV leaves the TLC the sabots and the seal sabot are dropped sequentially and the LV air vanes and stabilizers are opened.

Following the LV withdrawal from TLC at a safe distance the 1st stage motor is fired.

Each boost stage operates about one minute until propellant burnout is complete.


Following the 1st stage motor burnout LV continues flight with inoperative motor at coast



phase for 10-20 seconds. On finishing a prescribed coast phase the spent motor is separated and the  $2^{nd}$  stage motor is fired.

The interstage section connecting 1<sup>st</sup> stage motor with 2<sup>nd</sup> stage motor is released within 10-20 seconds after Stage 1/Stage 2 separation.

Stage 2/Stage 3 separation and  $3^{rd}$  stage motor firing are performed without a coast phase immediately after the  $2^{nd}$  stage motor burnout.



I, II, III, IV – Base coordinate planes

Fig. 2-1. LV Coordinate System

To place the spacecraft in an orbit of a prescribed altitude the LV flies with the inoperative 4<sup>th</sup> stage motor after separation of the spent 3<sup>rd</sup> stage motor. During the second (main) coast phase, which extends for a few hundred seconds, the stabilization and programmed orientation of LV are performed by gas-reaction attitude control system (GRACS).

During the main coast phase, LV lateral maneuver is performed to separate fairing using mechanical assemblies and then LV attitude (its longitudinal axis) is returned to the trajectory plane.



When the altitude is close to a prescribed SC orbit altitude the guidance and control system generates 4<sup>th</sup> stage motor ignition command.

At the end of the 4<sup>th</sup> stage motor firing the LV achieves an orbit close to the prescribed one. Following the 4<sup>th</sup> stage motor burnout the post-boost stage is ignited with a small delay (up to 5 seconds).

The post-boost propulsion system operates until burnout is complete.

By the end of the 4<sup>th</sup> stage motor burning the LV motion program during post-boost stage operation is formed with allowance for real values of LV kinematic parameters in such a way that the LV kinematic parameters conform to prescribed SC orbit with a required accuracy when the post-boost stage burnout is complete.

At the end of PBPS thrust decay the GRACS is activated again to control LV attitude.

The LV is turned so that the required SC orientation can be provided at the separation point.

The GCS generates a spacecraft separation command within about 375 seconds after the 4<sup>th</sup> stage motor is burnt out. Under that command the SC explosive fixing locks are opened and spacecraft is separated from the LV using spring assemblies.

Following the spacecraft separation the LV is turned in the SC orbit plane through 90° relative to the SC velocity vector and then LV is rotated by the GRACS.

#### 2.3 Flight Performance

In Table 2-1 and Fig. 2-2, the injected payload mass dependence of the circular orbit altitude for different launch points and inclinations is given.

Table 2-1.

Injected payload mass dependence of the circular orbit altitude for different launch points and inclinations

Launch point		Altitude, km						
		1000	800	600	400	200		
	i = 52°	204	295	395	505	632		
With PBS	i = 90°	105	186	275	374	488		
	i = 98° SSO	86	165	250	347	458		
Without PBS	i = 98° SSO	150	250	350	450	550		



An example of a trajectory for launch into sun-synchronous orbit at 481 km from the SVOBODNY Cosmodrome is shown in Fig. 2-3, and its respective burn sequence is shown in Fig. 2-4.

Fig. 2-5 presents the trajectory for the previous example without a post-boost stage. In this case after 4<sup>th</sup> stage motor thrust decay the LV GCS records zero thrust and activates GRACS which controls according to an algorithm developed for LV standard configuration. Spacecraft separation, as in LV standard configuration, is performed within about 375 seconds after the 4<sup>th</sup> stage motor burnout. The stated operation mode provides successful spacecraft injection with probability is no lower than for the PBPS configuration.

#### 2.4 Spacecraft Injection Accuracy

The spacecraft injection accuracy is characterized by maximum deviations of orbit parameters at the SC separation point (with a confidence of 0.993) shown in Table 2-2.

Table 2-2, Deviations of spacecraft orbital parameters

Tuble 2 2, Deviations of spacecraft of situal parameters							
	Orbital parameter deviation						
Orbital parameter	Standard LV configuration	LV configuration without PBPS					
Orbit altitude, km							
- at injection point	±5	±5					
- opposite to injection point	±5	±85					
Orbit inclination, arc. min	±;	3					

# 2.5 Attitude, Linear and Angular Velocities of Spacecraft after Separation

Spacecraft's longitudinal axis orientation during separation from LV can be preset in both orbital coordinate system and inertial launch coordinate system. Attitude accuracy at the separation point is  $\pm 5^{\circ}$ .

At separation point, the spacecraft is impacted to an additional linear velocity increment equal to 0.7-0.15 m/s  $\pm 10\%$  depending on the spacecraft mass. Nominal value of this increment is taken into account when a command on spacecraft separation is generated. Considering spacecraft separation velocity spreads, the orbit injection errors do not exceed values given in Table 2-2.

After separation, the spacecraft angular velocities do not exceed (with confidence of 0.993)  $\pm 1.3$  deg./s in pitch and yaw, and 1.0 deg./s in roll. (to be specified in view of spacecraft's inertial-mass properties).







Fig. 2-2. The injected payload mass dependence of the circular orbit altitude. Launches from Svobodny Cosmodrome.








Fig. 2-4. Start-1 LV burn sequence during SC injection into sun-synchronous orbit for launches from Svobodny Cosmodrome

Fig 2-5. Start-1 LV flight sequence (without PBPS) during SC injection into sun-synchronous orbit for launches from Svobodny Cosmodrome






Fig 2-6. Start-1 LV burn sequence (without PBPS) during SC injection into sun-synchronous orbit for launches from Svobodny Cosmodrome



# 3 MECHANICAL AND ELECTRICAL INTERFACES BETWEEN LV AND SC

#### 3.1 Mechanical Interface

#### 3.1.1 Head Module

The head module (Fig. 3-1) is designed for:

- protection against atmospheric effects during pre-launch period, launching phase and in flight up to the fairing separation;
- maintaining the environment around the SC and providing environmental cleanliness specified by a Customer;
- maintaining a specified temperature inside the fairing;
- LV/SC mechanical and electrical interfaces;
- Providing a shockless fairing separation.

#### 3.1.2 Adapter

The adapter (Fig. 3-2) provides the mechanical interface between LV and SC. The standard adapter has an aluminum alloy frame-type structure formed by two (front and rear) end rings joined to each other by a system of rods. To seal the head module the bottom is installed on the rear ring.

On the front ring of the standard adapter (Fig.3-3 and Fig. 3-4) the following devices are installed:

- three explosive locks for spacecraft attachment (Fig. 3-5);
- four separation spring assemblies for spacecraft separation (Fig. 3-5);
- two connectors;
- two sensors for spacecraft separation monitoring.

On the rear ring of the standard adapter the pressure equalization valves are installed so as to reduce effects upon the SC at fairing release. The pressure equalization valve design is a titanium-alloy case with a piston. The piston is moved by the pressure of gases produced by the explosive charges and opens the holes in the case which provides opening the interior of the head module to outside atmosphere. The gaseous combustion products are remained in the enclosed volume. The operation of these valves is controlled by two sensors which give a signal about the piston movement point.

In the interior of the adapter sensors are installed for measuring environment parameters inside the fairing and external effects. Number and type of these sensors to be agreed upon with a launch Customer. When SC is integrated with adapter, a maximum value of spring pusher pressing force is  $106 \pm 1 \, kgf$ . Pusher stroke is 30 mm.






Fig. 3-1. Start-1 LV head module






Fig. 3-2. Adapter design






Fig. 3-3. Start-1 LV standard adapter







Fig. 3-4. Start-1 LV standard adapter. View A.

- 1. Pyrotechnical lock
- 2. Spring assemblies (Pushers)
- 3. Electrical connectors
- 4. Separation sensors





# Position after separation




Fig. 3-5. Start-1 LV standard adapter. Cross Section B – B.






Fig. 3-6. Separation sensors. Start-1 LV adapter. Cross Section C – C



#### 3.1.3 Fairing

Fairing case (Fig. 3-1) consists of conical and cylindrical sections made of composite materials and it is attached to the support ring made of aluminum alloy. Fairing external surface is covered with a thermal-protective coating to reduce thermal effect on SC in flight. The fairing is RF isolated.

To seal the head module a spherical diaphragm is mounted on the front ring of the fairing. Fairing cap is attached to the same front ring. In order to eliminate contamination and gases in the space occupied by a spacecraft the internal surface of fairing is made of materials that have total mass losses of no more than 1% and total mass of gassing condensate of no more than 0.1%.

The fairing support ring provides fairing/adapter and HM/LV mechanical connections. Fairing case, released in flight, is attached to the support ring by six explosive bolts. To reduce impact action the explosive bolts are initiated in pairs at interval of about 0.1 second. After pyrotechnical devices are initiated the fairing is released by two spring assemblies. To protect the spacecraft from collision with the fairing the 650 mm guide rails for motion of fairing rollers are mounted on the support ring. To monitor fairing release the sensors are installed on these guide rails (two sensors on each of guide rails) which record the points in time of roller movement over guide rails.

The interior volume of the fairing is hermetically sealed. The sealing is provided by gaskets installed at the following places:

- between the front face of the front ring of the fairing and the spherical diaphragm;
- between the separated part and the base ring of the fairing;
- between the adapter and the base ring (see Fig. 3-6).

The degree of non-tightness is 5...7 mbar/h within the range of over-pressure of 10...60 mbar.

# 3.1.4 Spacecraft Access

For LV in standard configuration the access to spacecraft is terminated on finishing of head module integration. After that the monitoring of onboard spacecraft system and charging its batteries via EGSE of spacecraft are provided.

As agreed upon with a spacecraft developer, it is possible to remove the front part and the front diaphragm of fairing for access to the spacecraft in case there are no exacting requirements for SC environment parameters.



#### 3.1.5 Optional Services


The following optional services can be offered as agreed upon with a Customer:

- the development of a unique adapter for a spacecraft;
- providing of gaseous environment in given composition (for example, clean dry nitrogen) for SC integrated with head module.
- access to the encapsulated spacecraft using a special doors on the fairing; in this case environmental parameters are not controlled.

# 3.2 Electrical Interface between Spacecraft and Launch Vehicle

#### 3.2.1 Electrical Connections

Main variant of electrical connections between spacecraft and ground support equipment during pre-launch work for a spacecraft integrated with head module in the SC ATB is shown in Fig. 3-7.



1,2 – adapter cables

3 – ground extension cable for communication with electronic ground support equipment


Fig. 3-7. Electrical connections between SC integrated with HM and SC ground support equipment.



Main variant of electrical connections between spacecraft and ground support equipment during pre-launch work for a spacecraft integrated with launch vehicle in the LV ATB and at Launch Site are shown in Fig. 3-8.

Electrical communication between SC and ground support equipment is realized via umbilical plate connectors and connector installed on TLC.

A specific variant of electrical connection between SC and ground support equipment to be defined on the basis of Customer's initial data and will take account the number of electrical lines and connectors, and their layout. Electrical parameters shall be additionally agreed upon with spacecraft and launch vehicle developers.



To SC Ground Support Equipment

1-4 – LV cables; 5,6 – TLC cables;

7 – ground extension cable for communication with electronic ground support equipment

Fig. 3-8. Electrical connections between SC integrated with LV and SC ground support equipment



#### 3.2.2 Spacecraft Grounding

During spacecraft integration with launch vehicle the spacecraft is grounded through the LV structure elements.

#### 3.3 Information Interface between Spacecraft and Launch Vehicle

#### 3.3.1 Standard Information Interface

Information interface between spacecraft and launch vehicle is not provided for LV in standard configuration.

#### 3.3.2 Optional Services

If necessary, information interface can be provided through the extension cable line connected to LV guidance and control system.

# 3.4 Telemetry Interface between Spacecraft and Launch Vehicle

# 3.4.1 Spacecraft Ground Monitoring during Pre-launch Operations

Ground monitoring for SC systems through communication channels between spacecraft and SC EGSE is provided for LV standard configuration. After SC is installed inside the fairing the operations in radio-frequency emission mode via these communication channels is terminated.

# 3.4.2 Telemetry Monitoring at Injection Phase

SC telemetry monitoring during injection phase is not provided by LV standard configuration except for transmitting of information about SC separation from separation sensor installed on the adapter.

# 3.4.3 Optional Services

The following options can be provided as agreed upon with a Customer:

• telemetry data transmission through radio-frequency channel from launch system to a place where SC ground telemetry equipment is located.



- transmission of data about functioning of SC onboard systems during injection phase using LV measuring system. To perform this process the LV should be additionally equipped with telemetry switching devices and also the required number of data transmission channels should be provided.
- transmission of SC separation data that duplicates data from a standard sensor of SC separation (for example, breaking of jumpers at SC separation point).

In LV standard configuration the dynamic loads are measured by two sensors installed on adapter at the LV/SC interface.

As option, the installation of six sensors for measuring of dynamic loads along three axes can be developed. These sensors are installed on the adapter as viewed from SC.



# 4 SPACECRAFT ENVIRONMENTS

# 4.1 Flight Accelerations

During the LV flight, accelerations that spacecraft is subjected to do not exceed the values given in Table 4-1. Lateral accelerations act in any direction perpendicular to LV's longitudinal axis and simultaneously with longitudinal accelerations. Fig. 4-1 presents max. longitudinal acceleration values  $n_x$  dependence of the spacecraft mass during the 4<sup>th</sup> Stage motor burning.

Table 4-1 Start-1 LV flight accelerations

	Flight phase	Accelerations					
	r light phase	$n_{x_1}$	n <sub>y1</sub> , n <sub>z1</sub>				
1	TLC Erection and Launch	2.8	2.0				
2	1 <sup>st</sup> Stage Motor Burning	5.15	0.7				
3	2 <sup>nd</sup> Stage Motor Burning	6.5	0.6				
4	3 <sup>rd</sup> Stage Motor Burning	6.5	0.4				
5	GRACS Operation	0	< 0.01				
6	4 <sup>th</sup> Stage Motor Burning	10.0	0.5				
7	PBPS Burning	0.1	0.03				






Fig. 4-1. The maximum longitudinal acceleration dependence of the SC mass for the 4<sup>th</sup> Stage



# 4.2 Spacecraft Angular Velocities & Accelerations in LV Flight

The spacecraft angular velocities do not exceed 25 deg./s along SC axes. SC angular accelerations during powered flight do not exceed 24.5 deg/s<sup>2</sup> in roll, 11 deg/s<sup>2</sup> in yaw, and 22 deg/s<sup>2</sup> in pitch.

#### 4.3 Vibrations

During the LV flight, acoustic loads are the predominant type of a long dynamic effects acting on the payload. These loads are caused by pressure oscillations in the boundary layer of the approaching flow. Steady-state vibrations recorded at payload attachment places are secondary loads that are caused by acoustic noise effect on structural elements when the noise passes inside the fairing through its casing.

Vibro-shock processes are damping transient vibrations. Low-frequency vibro-shocks occur when launch vehicle leaves the TLC and Stage motors are fired. High-frequency vibrations are induced at initiation of pyrotechnical devices.

#### 4.3.1 Acoustic Noise

Acoustic loads depend on change of dynamic pressure of approach flow.

During powered flight, the acoustical loads achieve a maximum value at transonic flight speed. Acoustic noise spectrum is presented in Table 4-2 and Fig. 4-2 (here  $0 dB = 2 \cdot 10^{-5} Pa$ ). A maximum value of the acoustic noise level is 138 dB, action time -30 seconds.

At qualification testing for acoustic noise, load level specified in Table 4-2 is increased by 3 dB. Testing time is 90 seconds. The acceptance test modes are given in Table 4-2. Load time is 60 seconds. These values of test modes are minimum allowable for ground tests.

During tests, the spacecraft should be held by hanger to exclude effect of camera walls and floor on the SC behavior.



Table 4-2

Frequency, Hz	Spectral					
	component, dB					
20 - 200	100					
200 - 230	103					
230 - 310	107					
310 - 400	111					
400 - 500	114					
500 - 630	117					
630 - 800	124					
800 - 900	126					
900 - 1000	129					
1000 - 1050	128					
1050 - 1250	125					
1250 - 1600	122					
1600 - 2000	118					
Total:	138					




Fig. 4-2. Acoustic noise spectrum



#### 4.3.2 Steady-state Vibrations

Steady-state vibrations are response of dynamic system consisting of a spacecraft and adapter to acoustic pressure effect. The sum value of the steady-state vibrations that are registered on the adapter, does not exceed 5g rmsv. Steady-state vibration frequency content depends on SC resonance characteristics and it can be verified after consultations with the spacecraft developer.

During autonomous tests of SC units for the steady-state vibrations, the following modes presented in Tables 4-3 and 4-4 are accepted. The steady-state vibrations are random process. In the Table 4-3 and Fig. 4-3, the values of power spectral density (PSD) are given. These data are used to determine a mode of SC qualification testing. Vibration level should be controlled at places where SC is attached to the LV adapter. SC acceptance tests are conducted using testing modes presented in Table 4-4 and Fig. 4-4. The vibrations specified in Table 4-4 are accepted the same for all three axes. Test time is equal to 90 seconds for qualification testing and 60 seconds for acceptance testing.

As the steady-state vibrations are induced by acoustic noise acting on SC, random vibrations testing is allowed to conduct only during autonomous tests for units and instruments of the spacecraft.

Table 4-3

Frequency, <i>Hz</i>	Power spectral density, <i>g</i> <sup>2</sup> /Hz
20 - 200	0.00003 - 0.0003
200 - 250	0.0003 - 0.00045
250 - 315	0.00045 - 0.0011
315 - 400	0.0011 - 0.0018
400 - 500	0.0018 - 0.0036
500 - 630	0.0036 - 0.0065
630 - 800	0.0065 - 0.017
800 - 900	0.017 0.025
900 - 1000	0.025 - 0.03
1000 - 1050	0.03 - 0.028
1050 - 1250	0.028 - 0.025
1250 – 1600	0.025 - 0.005
1600 - 2000	0.005 - 0.0035
Total:	4.36 <i>g</i> rmsv






Fig. 4-3. Power spectral density for qualification testing



Table 4-4

Frequency, <i>Hz</i>	Power spectral density, <i>g</i> <sup>2</sup> /Hz				
20 - 25	0.001				
25 – 31.5	0.0018				
31.5 - 40	0.0023				
40 - 50	0.003				
50 - 63	0.004				
63 - 80	0.0055				
80 - 1000	0.0075				
1000 - 1250	0.0058				
1250 - 1600	0.0039				
1600 - 2000	0.0026				
Total	3.34 g rmv				




Fig. 4-4. Power spectral density for acceptance testing



#### 4.3.3 Vibro-Shock Loads

Figures 4-5 through 4-9 present a time chart of low-frequency vibro-shock accelerations at the adapter ring along the LV axis when the LV leaves the TLC and Stage motors are fired. Values of maximum accelerations along two other axes do not exceed 30% from the given ones.

The curves for these accelerations are plotted from assumption that the SC low natural longitudinal frequency is  $55 \, Hz$ . More accurate curves can be computed with consideration for SC finite-element model. Total number of low-frequency vibration shocks is 5.

Maximum high-frequency vibration shocks are induced by initiation of pyrotechnical devices used to separate the  $3^{rd}$  stage motor and to release the fairing. Parameters of high-frequency vibration-shocks are characterized by shock spectrum shown in Fig. 4.10. Maximum amplitude of high-frequency vibro-shocks reaches 200 g, and in this case the energy is within the frequency band of 600...1200~Hz. During tests, it is allowed to replace vibro-shock actions with triangle impulse with 200 g amplitude at duration of 0.5...1.0~ms for high-frequency shocks, and for low-frequency shocks these impulse parameters correspondingly are 2...10~g and 10...50~ms. (linear dependence of the amplitude on duration). The total number of vibro-shocks is the same as indicated above. In specific case, if natural frequencies of instruments do not exceed 300~Hz, during tests for high-frequency vibro-shocks it is allowed to increase the duration of impulse (as agreed upon with LV developer), which replaces high-frequency vibro-shock, from 1~ms to 5...6~ms with retaining the impulse energy.






Fig. 4-5. Launch Vehicle injection from TLC




Fig. 4-6. 1<sup>st</sup> Stage motor firing






Fig. 4-7. 2<sup>nd</sup> Stage motor firing




Fig. 4-8. 3<sup>rd</sup> Stage motor firing






Fig. 4-9. 4<sup>th</sup> Stage motor firing.




Fig. 4-10. Shock spectrum



# 4.4 Spacecraft Thermal Environments

#### 4.4.1 General

The initial temperature and humidity conditions of a spacecraft are determined by its location area according to the SC working process flow diagram (refer to Section 6) and they are related to the following phases of pre-launch preparation and launch:

- SC transportation to the SC ATB
- SC preparation in the SC ATB
- Integration with launch vehicle in the LV ATB
- Transportation of SC integrated with LV to Launch Site
- Pre-launch preparation and launch at Launch Site
- SC injection phase

#### 4.4.2 Optional Services

The following optional services can be provided as agreed upon with a Customer:

- Maintenance of environmental temperature inside TLC at head module area within the range that is allowed by operating conditions of LV systems to provide more favourable thermal environment for SC;
- Cold nitrogen purge to maintain a required thermal environment for SC systems with excessive heat when they are put in operating condition at SC ATB and launch site (for example, during SC battery trickle charging);
- Control of environment temperature inside the head module and inside the TLC in the HM location area during pre-launch preparation.

The nitrogen cooling system is used for supplying dry gas nitrogen with controlled parameters (temperature, flow rate).

# 4.4.3 Temperature inside Fairing at Injection Phase

Temperature change of fairing internal surface during flight up to fairing separation point is shown in Fig. 4-11.

Emissivity of the fairing internal surface is equal to 7.

Convective heat transfer does not virtually affect the SC thermal environment inside fairing as by the time of the beginning of fairing internal surface warming the pressure around SC drops up to values less that 300 Pa.



Approximate relation of the radiation heating flow effects on the SC as a function of LV flight time is presented in Fig. 4-12.

Start-1 LV fairing is jettisoned at speed no more than 5500 m/s at altitude of more than 150 km.




Fig. 4-11. The fairing internal surface temperature versus the LV flight time




Fig. 4-12. The radiation heating flow from the fairing internal surface versus the flight time.



# 4.5 Pressure Change inside Fairing in Flight

In order to level the pressure inside head module with external pressure by the time of fairing jettison, two equalizing valves are mounted in the adapter bottom. These valves are initiated by pyrotechnical devices installed in the casing of the valves. The mentioned pyrotechnical devices are ignited by GCS command at the same time when the first sabot is jettisoned at the initial LV flight phase.

Pressure profile inside fairing in flight is related to mission program and available fairing volume. Pressure drop inside the fairing in flight is characterized by the following approximate data (refer to Fig. 4-13:

Max. overpressure inside the fairing – 0.2 kgf/cm<sup>2</sup>

Gas flow rate at SC surface
 no more than 0.5 m/s

Pressure inside fairing by the time of fairing – no more than 0.0004 kgf/cm<sup>2</sup> jettison

To prevent thermal impact on SC and atmosphere impact effect the fairing is jettisoned at altitude of no more than  $150 \, km$ .




Fig. 4-13. Pressure profile inside the fairing in flight

Po – pressure inside the fairing (experimental data)

Ph – atmosphere pressure at flight altitude



# 4.6 Environment Cleanliness Requirements

#### 4.6.1 Cleanliness Environment during Pre-launch Preparation

SC environment parameters during all ground operations at the Cosmodrome comply with cleanliness class 10000 to 100000 of the U.S. Federal Standard FED-STD-209F. These parameters are provided by air conditioning and filtration of clean rooms of the SC ATB.

At the Cosmodrome, the fulfillment of requirements for hardware surface cleanliness are supervised by Customer jointly with Provider using required means and materials.

#### 4.6.2 Cleanliness Environment at Injection Phase

Up to activation of pyrotechnical valves the head module is a sealed. Before fairing jettison, after the pyrotechnical valves have been operated, the overpressure inside HM relative to atmosphere pressure at current flight altitude is retained (refer to Fig. 4-13) that prevents from ingress of contamination to the HM inside.

After the fairing jettison, the SC contamination by exhaust products of the 4<sup>th</sup> Stage motor and PBPS is excluded using the following operations:

- the 4<sup>th</sup> Stage motor and PBPS are operated in propulsive mode up to propellant burnout;
- in the flight between PBPS burnout and SC separation the SC Attitude and stabilization are performed by GRACS is operated by pressurized nitrogen;
- the SC separation is performed spring assemblies not earlier that 375 seconds after the 4<sup>th</sup> Stage motor burnout and not earlier 90 seconds after PBPS burnout;
- during SC separation when pyrotechnical devices have been operated the derbies and combustion products are remained inside of these devices;
- the separation assembly part remaining on SC contents only metal elements (stainless, carbon spring, and alloyed steels) that meet the outgassing requirements;
- after SC separation, the LV's longitudinal axis is turned out into plane perpendicular to the velocity vector and is rotated in this plane. This ensures perpendicularity of the motor nozzle to the SC motion and excludes contamination of SC by gas exhaust from LV motor.

# 4.7 Radio-frequency and Electromagnetic Environment at Pre-launch Preparation and Launch



# 4.7.1 Spacecraft Radio-frequency and Electromagnetic Environment during Pre-launch Preparation

During pre-launch preparation, the radio-frequency and electromagnetic fields induced by LV onboard radio systems, SLS ground equipment and Cosmodrome equipment affect a spacecraft.

#### LV onboard telemetry system transmitter.

LV onboard telemetry system operates in pulse-frequency modulation of carrier frequency using pulse-amplitude and pulse-code modulation.

Carrier frequency 203.3 MHz
Pulse duration 1.56 ms
Pulse-recurrence rate 320 kHz
Maximum emissive power up to 40 W
Antenna and feeder device losses 1.5 dB

Attenuation in the second and subsequent harmonics no less than 60 dB

Antenna gain 2.61 *dB*Polarization linear

Cutoff time 30 s after SC separation

Onboard telemetry system antenna location is shown in Fig. 4-14. Normalized pattern of onboard telemetry system antenna is given in Table 4-5. The angles in this pattern are measured in the LV coordinate system as shown in Fig. 4-15.

#### LV onboard transponder.

Launch vehicle can be equipped with transponder that is a part of trajectory measuring system and radiates pulse radio signals.

Carrier frequency 2860 MHz

Pulse duration 1 ms

Pulse-recurrence rate up to 3.5 kHz Maximum emissive power up to 300 W

Antenna and feeder device losses 1.5 dB

Attenuation in the second and subsequent harmonics no less than 60 dB

Antenna gain 5.1 *dB*Polarization linear

Cutoff time at the time of SC separation




Fig.4-14. Antenna location on LV body






Fig. 4-15. Measuring of normalized antenna pattern angles



LV onboard transponder antenna Location is shown in Fig. 4-14. Normalized pattern of onboard transponder antenna is given in Table 4-6. The angles in this pattern are measured in the LV coordinate system as shown in Fig. 4-15.

#### <u>Transmitters of ground radars</u>.

Carrier frequency	2725 MHz
Pulse duration	1.56 <i>m</i> s
Code distance between pulses	3-6 <b>m</b> s
Pulse-recurrence rate	625 <i>Hz</i>
Maximum emissive power	5000 <i>kW</i>
Transmitting antenna gain	35 <i>dB</i>
Antenna and feeder device losses	1.0 <i>dB</i>

#### Transponder electronic ground support equipment.

Transponder electronic ground support equipment (TEGSE) is a radar simulator and it emits radio signals with parameters closed to radar ones. The transponder electronic ground support equipment is used only during LV preparation phase at the LV ATB when spacecraft is inside the HM and is covered by the fairing. This provides reduction of electromagnetic effect on SC from TEGSE no less than 30 dB.

Maximum emissive power	10 W
Transmitting antenna gain	5 <i>dB</i>

# 4.7.2 Radio-frequency and Electromagnetic Environment in Flight

At injection phase the spacecraft is subjected to radio-frequency and electromagnetic effects from the mentioned above LV radio systems: telemetry system and trajectory measuring system transponder.



**Table 4-5**Normalized pattern of onboard telemetry system antenna

Angle	Angle																		
_	Aligie 0, deg.																		
φ, deg.	0	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150	160	170	180
acg.	Ü				l														
0	.34	.84	.92	.86	.74	.65	.63	.84	.79	.77	.80	.69	.42	.39	.41	.60	.65	.48	.36
10		.83	.92	.86	.73	.73	.63	.83	.88	.72	.72	.52	.33	.35	.41	.58	.70	.57	.41
20		.85	.87	.83	.71	.63	.68	.88	.85	.73	.71	.53	.35	.40	.43	.60	.72	.59	.46
30	.34	.84	.92	.83	.66	.58	.62	.78	.74	.59	.57	.35	.28	.35	.42	.58	.69	.63	.50
40	.34	.77	.85	.78	.66	.59	.64	.77	.73	.58	.58	.36	.25	.30	.35	.50	.66	.62	.54
50		.68	.69	.79	.80	.56	.58	.71	.75	.67	.70	.58	.36	.34	.31	.39	.51	.56	.52
60		.57	.78	.74	.61	.59	.63	.72	.76	.71	.73	.69	.50	.36	.31	.37	.42	.44	.46
70	.34	.48	.67	.69	.54	.52	.60	.65	.71	.69	.77	.76	.57	.43	.36	.44	.66	.42	.41
80		.47	.63	.63	.54	.56	.60	.63	.65	.67	.73	.75	.63	.46	.40	.45	.53	.48	.46
90		.48	.59	.59	.52	.50	.56	.58	.58	.65	.67	.69	.63	.53	.49	.51	.54	.48	.50
100	.34	.40	.51	.54	.50	.47	.57	.60	.56	.59	.63	.64	.61	.54	.52	.53	.52	.52	.53
110	.34	.34	.45	.49	.47	.40	.51	.58	.53	.55	.62	.64	.61	.54	.53	.52	.52	.52	.60
120		.26	.30	.35	.33	.27	.32	.42	.43	.46	.54	.63	.63	.61	.55	.51	.51	.56	.59
130	.34	.24	.26	.28	.28	.24	.19	.24	.24	.23	.39	.53	.59	.58	.60	.63	.60	.61	.61
140	.34	.27	.25	.25	.27	.25	.16	.17	.17	.16	.31	.61	.52	.54	.66	.69	.66	.66	.62
150		.26	.20	.19	.24	.21	.14	.23	.27	.21	.25	.42	.53	.58	.77	.88	.77	.68	.58
160		.37	.17	.13	.21	.22	.14	.32	.43	.39	.39	.51	.55	.67	.80	.88	.77	.65	.58
170	.34	.30	.12	.16	.21	.14	.16	.44	.49	.47	.48	.61	.70	.60	.74	.87	.75	.65	.62
180		.40	.12	.09	.22	.21	.13	.39	.57	.46	.52	.63	.82	.67	.57	.70	.69	.60	.58
190		.33	.05	.11	.21	.10	.14	.45	.40	.28	.39	.53	.73	.62	.52	.55	.54	.50	.54
200	.34	.40	.07	.06	.20	.19	.06	.30	.27	.11	.21	.30	.61	.59	.50	.56	.48	.46	.49
210		.32	.05	.05	.23	.14	.08	.30	.21	.11	.20	.32	.63	.60	.56	.59	.48	.43	.46
220		.46	.14	.03	.12	.14	.04	.28	.40	.30	.36	.42	.64	.59	.61	.70	.60	.43	.41
230	.34	.33	.09	.04	.10	.07	.06	.37	.47	.45	.45	.57	.71	.61	.66	.76	.59	.41	.38
240	.34	.33	.16	.20	.12	.06	.09	.44	.59	.52	.50	.62	.66	.58	.71	.87	.76	.48	.42
250		.28	.20	.17	.17	.09	.07	.31	.51	.43	.39	.60	.67	.66	.83	.92	.85	.59	.48
260		.30	.25	.24	.29	.16	.27	.25	.35	.23	.32	.61	.69	.75	.90	.96	.88	.70	.53
270		.25	.26	.32	.33	.27	.21	.20	.21	.21	.41	.65	.73	.85	.94	.90	.82	.68	.55
280		.24	.31	.39	.42	.30	.23	.25	.25	.44	.71	.77	.83	.92	.84	.73		.55	.45
290		.26	.38	.49	.52	.47	.47	.44	.54	.81	.96	.92	.85	.81	.66	.49	.48	.47	.45
300		.29	.41	.60	.61	.61	.49	.50	.62	.95	1.0	.90	.90	.88	.64	.48	.47	.52	.47
310		.33	.46	.58	.64	.62	.54	.61	.77	.94	.90	.82	.82	.65	.34	.43	.32	.40	.43
320		.46	.60	.71	.75	.67	.58	.62	.75	.93	.63	.56	.58	.39	.34	.31	.41	.34	.37
330		.49	.64	.69	.71	.65	.60	.64	.71	.63	.50	.43	.37	.29	.35	.40	.46	.27	.31
340	.34	.60	.70	.72	.66	.56	.49	.59	.70	.56	.49	.50	.38	.27	.41	.34	.39	.31	.30
350		.79	.88	.87	.73	.60	.55	.76	.77	.57	.59	.51	.60	.32	.27	.35	.39	.28	.32
360	.34	.84	.92	.86	.74	.65	.63	.84	.79	.77	.80	.69	.42	.39	.41	.60	65	.48	.36
L																			



**Table 4-6**Normalized pattern of onboard transponder antenna

Angle									Ano	le θ,	deg								
φ,					1	ı		1	7 5	,10 0,	105.	ĺ	l						
deg.	0	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150	160	170	180
0	.14	.08	.22	.61	.60	.14	.03	.34	.11	.12	.30	.27	.20	.41	.97	.97	.08	.26	.14
10	.14	.16	.36	.58	.49	.21	.25	.32	.14	.20	.22	.29	.13	.35	.89	.63	.13	.18	.13
20		.17	.38	.40	.45	.17	.11	.24	.14	.22	.45	.35	.37	.95	1.0	.46	.11	.14	.13
30		.12	.25	.26	.35	.33	.27	.12	.12	.15	.15	.22	.65	.71	.49	.14	.14	.16	.09
40		.11	.21	.25	.28	.39	.38	.35	.29	.17	.31	.53	.45	.35	.15	.08	.21	.10	.07
50		.12	.18	.21	.25	.34	.36	.61	.59	.39	.47	.61	.50	.38	.14	.13	.18	.15	.07
60	.14	.17	.19	.25	.24	.37	.30	.44	.51	.45	.49	.61	.54	.27	.09	.13	.21	.04	.06
70	.14	.17	.20	.06	.26	.17	.11	.17	.13	.26	.35	.46	.46	.14	.13	.16	.21	.09	.07
80	.14	.18	.17	.12	.15	.18	.21	.13	.10	.01	.04	.16	.09	.07	.14	.11	.15	.11	.07
90	.14	.16	.19	.14	.18	.21	.34	.33	.33	.15	.05	.05	.07	.06	.13	.11	.11	.13	.10
100	.14	.16	.16	.12	.16	.14	.26	.35	.37	.26	.14	.06	.08	.08	.07	.05	.08	.13	.10
110	.14	.16	.16	.11	.12	.11	.17	.30	.27	.16	.09	.10	.09	.11	.06	.10	.07	.13	.12
120	.14	.16	.15	.09	.21	.10	.11	.22	.12	.11	.06	.11	.11	.05	.04	.04	.04	.12	.10
130	.14	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00
140	.14	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00
150	.14	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00
160	.14	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00
170	.14	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00
180	.14	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00
190		.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00
200		.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00
210		.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00
220		.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.01
230		.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.00	.04	.08	.09
240	.14	.06	.19	.05	.07	.12	.03	.03	.04	.22	.40	.37	.27	.22	.28	.04	.09	.04	.08
250	.14	.16	.10	.10	.04	.07	.07	.05	.04	.13	.65	.22	.22	.08	.12	.05	.04	.03	.04
260 270	.14 .14	.13 .15	.14 .18	.09	.11 .15	.12	.21 .22	.18 .14	.32 .12	.22 .11	.86 .07	.66 .07	.35	.23	.12	.25 .17	.11	.06 .04	.17 .10
280	.14	.13	.13	.11 .10	.13	.29	.14	.03	.05	.11	.07	.07	.10	.19 .12	.03	.07	.16 .24	.04	.04
290		.15	.15	.27	.39	.33	.09	.03	.33	.19	.08	.65	.25	.12	.05	.13	.38	.44	.16
300		.13	.13	.23	.33	.32	.26	.12	.56	.99	.99	1.0	.23	.23	.19	.13	.13	.11	.13
	.14	.20	.09	.15	.33	.52	.54		.32	.25		.64		.97	.65		.33	.10	.11
310		.09	.19	.27	.27	.30	.19	.14	.05	.15	.15	.16	.25	.97	.97	.56	.10	.25	.14
330		.09	.17	.26	.25	.22	.10	.16	.16	.21	.35	.11	.13	.63	.70	.41	.06	.22	.13
340		.07	.15	.26	.24	.18	.07	.11	.21	.03	.15	.09	.05	.32	.67	.53	.08	.19	.10
350		.06	.23	.44	.45	.13	.09	.25	.06	.15	.18	.28	.07	.36	.83	.91	.07	.22	.10
	.14	.08	.22	.61	.60	.14	.03	.34	.11	.12	.30	.27	.20	.41	.97	.97	.08	.26	.14
			.==										. =						



#### 5 PAYLOAD LIMITATIONS

#### 5.1 Center of Mass Limitations

After separation the spacecraft angular velocities do not exceed (with confidence of 0.993)  $\pm 1.3$  deg./s in pitch and yaw, and 1.0 deg./s in roll (refer to Section 2.5) provided that maximum deviations of the SC center of mass in lateral plane (static imbalance) is within limit  $\pm 4$  mm.

If the static imbalance increases, the angular velocities increase after SC separation. Particular values of the angular velocities to be specified according to presented SC mass and inertial properties and SC center of mass position.

# 5.2 LV Angular Position Limitations at SC Separation Point

Roll maneuvering at the SC separation phase is not provided for LV standard configuration. At the SC separation time the LV's longitudinal axis makes an angle *TBD* (by a SC developer) with the velocity vector. Also a SC developer should specify the relative orientation of SC axes and LV axes after SC integration with LV taking into account loads acting during LV erection before launch (refer to Chapter 3, Mechanical Interface).

# 5.3 Spacecraft Structure Rigidity

To avoid dynamic interaction between LV and SC in low-frequency range the SC should meet the following rigidity requirements:

- at the points where SC is rigidly attached to the LV, the lower frequency in lateral plane should be more than  $15 \, Hz$ .
- at the points where SC is rigidly attached to the LV, the lower frequency in longitudinal direction along the LV axis should be more than  $50 \, Hz$ .

# 5.4 Electromagnetic Compatibility Limitations

Launch vehicle, systems and units of the Start-1 SLS and a spacecraft should meet the requirements to electromagnetic environment induced by onboard and ground radio systems. Effects of radio systems used for LV and SLS are given in Section 4.7.



A spacecraft developer should issue to LV developer the initial data on all radio systems used during launch campaign, including:

- onboard radio systems;
- electronic ground support equipment;
- communications (satellite communication system, radio intercommunication system, wireless telephones etc.);

#### Initial data should include:

- operating frequency range;
- antenna pattern;
- transmitter power
- operating mode (direct radio measurement, operation in cable network);
- radiation power attenuation coefficient for devices operating without direct radio radiation.

These initial data should be presented for 1 year prior to the beginning of launch campaign at Cosmodrome

On the basis of initial data issued by SC developer, LV developer should conduct analysis for electromagnetic compatibility.

# 5.5 Safety Limitations

SC developer shall issue initial data on hazardous operations and procedures, hazardous materials used during launch campaign, and requirements for hazardous work organization.

LV developer shall conduct jointly with Cosmodrome the analysis of the presented initial data that is used as a base to issue instructions on safety measures during pre-launch and launch operations for each launch campaign.



# **6 DOCUMENTATION**

Documents to be issued during preparation and launch campaign are presented in Table 6-1.

**Table 6-1**List of documents to be issued

	Document	Responsible Party
	Launch Vehicle and Spacecraft User's Handbook d User's Handbook)	Provider
2. Stateme Start-1	ent of Work (schedule of SC pre-flight operations using LV)	Customer
3. Spacecr	raft/Start-1 LV Interface Control Document (ICD)	Provider and Customer
	Analysis (calculations associated with a spacecraft using the Start-1 LV; two versions – preliminary and eases)	Contractor
5. Spacecr	raft and Start-1 LV Mechanical Interface Drawings	Provider
_	ns of electrical and telemetry interfaces for SC, Start-1 Cosmodrome	Provider and Customer
7. Spacecr Diagran	raft and Launch Vehicle Integration Process Flow	Provider and Customer
8. Schedul	e of Spacecraft Hardware Delivery	Customer
9. Work S Start-1	chedule of Spacecraft Preparation and Launch using LV	Provider and Customer
•	and Safety Plan for Pre-flight Operations and SC from the Svobodny Cosmodrome aboard the Start-1 LV	Provider
11. Informa	tion on SC state vector at the separation time	Provider
12. Final Ro	eport on Spacecraft Launch Results	Provider



#### 7 MISSION ANALYSIS

#### 7.1 General

Mission analysis is prepared to estimate the possibility to perform launch program and to determine expected trajectory parameters.

Mission analysis is conducted to make sure that the program purposes are achieved and spacecraft can be injected into prescribed orbit with designed parameters of angular motion.

Program analysis is conducted in two phases:

- Preliminary analysis in order to define the spacecraft compatibility with the Start-1 LV;
- Final analysis in order to develop a mission program and to determine the expected trajectory parameters.

Mission analysis includes the following Sections:


- Coupled Dynamic Analysis
- Flight Sequence
- Trajectory Parameters and Injection Accuracy
- Fairing Separation Dynamics
- Spacecraft Separation Dynamics
- SC and LV relative motion in the first orbit after separation

# 7.2 Requirements for Spacecraft Mathematical Model for Coupled Dynamic Analysis

The SC mathematical model for calculations using the finite-element method should be presented by SC developer as physical (if degree of freedom does not exceed 10000) or condensed model. The initial data should includes:

- Mass, Stiffness and Damping matrices,
- requirements to damping;
- information on frequency range where the SC model is representative.

The model must describe the full three-dimensional behavior of the spacecraft, and values of the initial data shall be expressed according to International metric System. In case of the condensed method, the inverse transformation matrices shall be presented for acceleration, displacement and loads. The calculations are performed using NASTRAN software package. Kind of model and format of results shall be previously agreed upon with LV developer.



# SPACE LAUNCH SYSTEM START -1

# **USER'S HANDBOOK VOLUME II:**

PRE-LAUNCH PREPARATION, LAUNCH, & COSMODROME OPERATIONS





# START-1 Users Handbook Volume II: Document Change Record

Date	Revisions	Approvals
		Zinchenko
May 31, 2002	Update Version	Dubyn

Issue 1, May 2002 DCR-1



# **TABLE OF CONTENTS**

Abbreviations	iii
List of Figures	iv
List of Tables	v
1. Introduction	1
2. Svobodny Cosmodrome Infrastructure	2
2.1 Technical Site	2
2.1.1 Spacecraft Assembly-and-Test Building	2
2.1.1.1 Clean Rooms	7
2.1.1.2 Environment Monitoring in Spacecraft ATB	10
2.1.1.3 Technical Site Mechanical Equipment	10
2.1.1.4 Head Module Assembly Support Equipment	12
2.1.1.5. Spacecraft ATB Video Monitoring System	14
2.1.1.6. Spacecraft Fueling Equipment	14
2.1.1.7 Spacecraft ATB Electrical Power Supply System	17
2.1.2 Launch Vehicle Assembly-and-Test Building	17
2.2 Launch Site	20
2.3 Cosmodrome Electrical Power Supply	23
2.4 Telemetry Measurements	24
2.5 Communications	26
2.6 Residential Area	26
2.7. Optional Services: HM Environmental Conditions	26
2.7.1 Nitrogen Cooling System	26
2.7.2 Control of Environmental Conditions Inside Head Module	27
3. Spacecraft Preparation at the Cosmodrome	28
3.1. Transportation of Spacecraft and Ground Equipment	28
3.1.1. Transportation Conditions	28
3.1.2. Vehicles	28



3.1.3	. Hoisting Equipment	30
3.1.4	. Customer's Hardware Storage Conditions	30
3.2.	Spacecraft Preparation in SC ATB	30
3.2.1	. Spacecraft Processing	31
3.2.2	. Spacecraft Fueling with Hydrazine in Clean Room 2	31
3.2.3	. Head Module Assembling in Clean Room 1	31
3.2.4	. Head Module Transportation to LV ATB	31
3.3.	Head Module Preparation in LV ATB	35
3.4.	Launch Vehicle with Spacecraft Preparation at Launch Site	35
3.5	Post-Launch Operations	35



### **Abbreviations**

**ACCD** - air contamination control device

**ATB** – assembly-and-test building

**BAC** - breath air compressor

**EGSE** – electronic ground support equipment

FC - fire cock

**HM** – head module

**HMIS** - head module integration stand

**HMT** - head module trolley

**LNSS** - liquid nitrogen supply system

**LV** – launch vehicle

MCC – mission control centerMS – measurement system

NCS - nitrogen cooling system

SC – spacecraft

**SLS** – space launch system

**UPS** – uninterrupted power supply

Issue 1, May 2002 iii



# **List of Figures**

Table	(a) Title	Page
2.1	Location plan of Svobodny cosmodrome area	3
2.2	Svobodny cosmodrome plan	4
2.3	Cosmodrome Technical Site facilities location	4
2.4	Spacecraft assembly-and-test building layout	5
2.5	Clean room load-bearing frame stubs layout	9
2.6	Hoist hook	12
2.7	Head module integration stand	13
2.8	Head module trolley	13
2.9	Equipment arrangement during spacecraft fuelling with hydrazine	16
2.10	Launch vehicle assembly-and-test building layout	19
2.11	Launch Pad	21
2.12	Layout of MCC and equipment arrangement	22
2.13	Scheme of Cosmodrome electrical power supply	25
3.1	Spacecraft with HM adapter on Customer's stand in horizontal position	32
3.2	Spacecraft with HM adapter on Customer's rotation fixture in horizontal position	32
3.3	Transfer of spacecraft 1 with adapter to HMIS by crane	33
3.4	Transfer of spacecraft 2 with adapter to HMIS by crane	33
3.5	Spacecraft placement inside the fairing	34
3.6	Head module assembling	34
3.7	Head module preparation for checkout and transport to LV ATB	34



# **List of Tables**

Table	(b) Title	Page
2.1	Clean rooms environmental conditions	7
2.2	SC ATB crane equipment performance data	10
2.3	LV ATB crane equipment performance data	11
2.4	Hoist hook dimensions	11
2.5	Uninterrupted power supply performance data	23
3.1	Transportation conditions	28
3.2	Maximum values of vibro-accelerations	29
3.3	Root-mean-square acceleration	29



### 1. Introduction

This Start-1 Launch Vehicle User's Handbook consists of two Volumes:

**Volume 1: Launch Vehicle & Spacecraft Interfaces** 

**Volume 2: Pre-launch Preparation, Launch & Cosmodrome Operations** 

This document *Pre-Launch Preparation, Launch & Cosmodrome Operations* covers cosmodrome infrastructure, spacecraft and launch vehicle processing and launch operations for the Start-1 Space Launch System.

The Users Handbook is administered by United Start Corporation out of Los Angeles, CA and Puskovie Uslugi out of Moscow Russia.



# 2. Svobodny Cosmodrome Infrastructure

The Svobodny cosmodrome infrastructure provides for all operations on the spacecraft and LV preparation for launch as well as launch implementation. The infrastructure includes the following:

- Technical Site and Launch Site
- **Ground Instrumentation Sites**
- Flightpath and LV spent elements impact areas
- Ground support equipment and facilities
- Communications system and power supply
- Residential area
- Road network.

Location plan of Svobodny Cosmodrome area is presented in Figure 2.1, Svobodny cosmodrome layout is presented in Figure 2.2.

#### 2.1 Technical Site

The Technical Site is intended for implementation of assembly and test operations on preparation of LV, SC, head module and ground support equipment for launch.

The following facilities are located at the Technical Site:

- SC Assembly-and-Test Building (SC ATB) for SC and head module processing
- LV Assembly-and-Test Building (LV ATB) for LV and Space Launch System processing
- Pads for hardware unloading/reloading
- Storage facilities for ground support equipment and vehicles.

The Cosmodrome Technical Site facilities location are presented in Figure 2.3.

# 2.1.1 Spacecraft Assembly-and-Test Building

The SC ATB consists of working area A dedicated to SC and head module assembly and test, and working area B dedicated to placement of fueling system for SC propulsion system filling with hydrazine and compressed gas. The SC ATB layout is presented in Figure 2.4.

2






Fig. 2.1. Location Plan of Svobodny Cosmodrome Area







Fig. 2.3. Cosmodrome Technical Site Facilities Location







# Spacecraft Assembly-and-Test Building Room Identification (see Fig. 2-4)

Area A –	SC processing and HM assembling
1	entrance airlock
2	room for SC ATB duty officer
3	cloakroom for upper clothing
4	passage
5	refreshment room
6	lavatory
7, 8, 16	cloakrooms, shower room
9	room for Customer's security
10	lavatory
11	Customer's Manager room
12,13	rooms for EGSE placement
14	auxiliary room for water supply system
15	auxiliary room
16	storage room for special clothing for Clean Room
17, 18	auxiliary room for air conditioning and ventilation equipment
19	room for accommodation of operating consoles of environment examination
	system, air conditioning and ventilation system, and NCS
20,21	Provider's auxiliary rooms
22	ventilation room
23	area for equipment and containers temporary storage
24	equipment unloading area
25	main hall for SC and HM processing
26	Clean Room-1 (for SC and HM processing)
	Fueling system
27	Clean Room-2 (for SC filling with hydrazine and compressed gas)
28	room for fuelling equipment dry cleaning and preparation
29	storage room for safety equipment
30	chemical laboratory
31	hydrazine storage
32	evacuation airlock
33	Clean Room-1/Clean Room-2 airlock passage
34	switchboard room
35	stairway to 2 <sup>nd</sup> floor
36	control and visual monitoring room
37	thermal entry point (water/heat supply)
38	room for washing (neutralization) of equipment and personnel
39	plenum ventilation, air heater
40	filters



41	exhaust ventilation
42	special drainage tank
43	area for Clean Room-2 arrangement
44	evacuation airlock

Note: rooms 39, 40, 41 are located above rooms 31, 32, 35.

#### 2.1.1.1 Clean Rooms

Clean rooms are intended for assembly and test operations with SC and HM under environmental conditions presented in Table 2.1.

**Table 2.1** 

	Tuble #41					
	Clean Rooms    Environmental Conditions   Dust Loading in   Operating   Humidity,   Illumin					
					,	
		Accordance with	Temperature,	%	lux	
		FED STD-F209E	°C			
1	Clean room 1 – for	Class 100,000 –	(+19+25) –	4060	≥ 500	
	SC and HM	for operations	for non-			
	processing	with protected	operating SC			
		optics				
		Class 10,000 – for	(+19+23) –			
		operations with	for operating			
		unprotected optics	SC			
2	Clean room 2 – for	Class 100,000	+19+25	4060	≥ 500	
	SC fuelling with					
	hydrazine					
3	Airlock passage	Class 100,000	+19+25	4060	400	

Clean rooms are demountable structures of tent type consisting of supporting frame, suspended ceiling, filtering units built-in ceiling and antistatic film. Clean rooms 1 and 2 layout in SC ATB are presented in Fig. 2.4.

Required environmental conditions inside clean rooms are kept by the following systems:

- air conditioning and filtration system;
- emergency ventilation system;
- automatic environment control system.


Air conditioning and filtration system mixes plenum and return air, purifies and processes it in the central conditioner and then supplies prepared air to a clean room through filtering chamber and air duct.



Emergency ventilation system is independent for each clean room and ensures gas-laden air disposal from clean room through filter-absorber of hydrazine vapour by environment monitoring system command.

Automatic environment control system ensures measuring and keeping temperature and humidity within the required intervals, their displaying, recording and records keeping with print out capability. The Clean rooms location in SC ATB is presented in Fig. 2.5.







#### 2.1.1.2 Environment Monitoring in Spacecraft ATB

In the process of SC processing the following environment for parameters are monitored continuously

- Dust loading
- Temperature
- Relative humidity
- Hydrazine vapour concentration
- Oxygen percentage.

Control over air conditioning and filtration system and environment monitoring system is carried out by Provider personnel.

#### 2.1.1.3 Technical Site Mechanical Equipment

Operations with spacecraft, head module and launch vehicle at the Technical Site are conducted with the use of special mechanical hoisting equipment. The operations with the use of mechanical equipment in SC ATB and LV ATB are as follows:

- hardware transportation to the Technical Site;
- Technical Site facilities preparation and equipping;
- unloading and accommodation of Customer's and Provider's hardware in the working rooms:
- assembly operations with SC, HM and LV;
- Customer/Provider joint assembly operations;
- Ground equipment dismantling and removing after launch.

The SC ATB (see Fig.2.4) is equipped with three bridge cranes installed in rooms 24, 25 and 43 and one telpher in room 25. The SC ATB crane equipment performance data is presented in Table 2.2.

Table 2.2, Crane Equipment Performance Data

Performance Data	Room 24	Room 25	Room 43	Room 25	
Crane Type	Bridge crane	Bridge crane 5T15			
Hoisting capacity, tons	5.0	5.0	5.0	3.0	
Bridge speed, m/min	19.6	16.0	19.6	-	
Trolley speed, m/min	11.8	11.8	11.8	6.0	
Hook speed, m/min	1.7	1.7	0.96	2.0	
Hook max. altitude, m	6.0	6.0	6.2	7.0	

The LV ATB crane equipment performance data is presented in Table 2.3.



Table 2.3

Performance data	Room 11		Room 12
	15-ton	5-ton	3-ton hoist
Hook speed, m/min			
high speed	2.4	2.1	2.1
low speed	0.24	0.23	0.23

The parameters of hoists hooks used during rigging operations at Cosmodrome including crane truck are presented in Table 2.4 and Fig. 2.6.

Table 2.4

Equipment	Hook Di	Hook Dimensions (mm)				
	S	D	d	h	I	а
Bridge crane 5T15 (SC ATB)	65	85	56	82	130	86
Bridge crane 5T15 (LV ATB)						
Bridge crane 15T15 (LV ATB)	120	150	85	150	210	96
Telpher – 3T (LV ATB)	65	70	56	60	130	42
Telpher – 1.5T (SC ATB)	90	120	80	115	180	86
Truck crane KC-3576						






Fig. 2.6. Hoist Hook

# 2.1.1.4 Head Module Assembly Support Equipment

Assembly support equipment provides head module assembling in horizontal position. The Head Module Integration Stand (HMIS) and Head Module Trolley (HMT) are used for HM assembling.

HM Integration Stand (Fig.2.7) is a structure consisting of frame (1) carried by four swivel wheels (2).






Fig.2.7. HM Integration Stand




Fig.2.8. HM Trolley



Special devices providing 5 degrees of freedom for head module elements (adapter and spacecraft) to be fixed on faceplate (3) are mounted on the frame.

Vertical movement along the Y axis is provided by rotating the handwheel (4) installed on reduction gear worm. Lateral movement along Z-axis is provided by moving the carriage (5) with the help of handle (6).

Rotation about HM longitudinal X-axis is provided by rotating of the faceplate, which has a brake (7). To measure adapter angular position there are marks on faceplate and case. Rotation about transversal Z-axis is provided by raising/lowering the right (in Fig. 2.7) edge of pad (8) by rotating the screw (9). Rotation about vertical Y-axis is provided by turning the platform (10) with help of screws (11).

HM trolley (Fig. 2.7) consists of frame (1) on four wheels (2), two of which are swivel ones. Two semi-ring supports 3 are mounted on the frame to provide installation of two banding rings with HM fairing (Fig. 7.9 of Volume I). Herewith fairing can be rotated about Y and Z-axes.

Mechanisms of rotation are similar to ones used in HMIS.

### 2.1.1.5. Spacecraft ATB Video Monitoring System

The SC ATB monitoring system is intended for video monitoring by Customer's personnel of SC assembly in clean room 1 and SC fueling in clean room 2 and also SC and ground equipment safe keeping. The video monitoring system consists of the following parts:

- two video cameras in clean room 1
- two video cameras in clean room 2
- four monitors each is able to display information from four video cameras simultaneously
- power cables and signal cables.

### 2.1.1.6. Spacecraft Fueling Equipment

The SC is fueled with hydrazine by joint Customer/Provider team with the use of the following equipment:


- Fueling system for SC propulsion system filling with hydrazine and gas (supplied by Customer)
- Breathing air system (including breath air compressor, air ducts, heaters, air dispensers, cables, etc.) for clean air supply to protective suits of fuelling team.



- Protective suits for fueling team (supplied by Customer)
- Special materials for hydrazine neutralization (supplied by Customer)
- Liquid nitrogen supply equipment and self-contained cryogenic tanks (supplied by Provider)
- Fire engines and medical team with means for treating for hydrazine contamination injuries (supplied by Provider)
- Vehicles for transportation of the above mentioned equipment (provided by Provider).

There is a chemical laboratory in SC ATB to carry out chemical analysis of hydrazine samples. Procedure of hydrazine samples analysis is complied with MIL-PRF-26536E. Arrangement of equipment during SC fueling with hydrazine is presented in Fig. 2.9.







#### 2.1.1.7 Spacecraft ATB Electrical Power Supply System

Electrical power to the SC ATB equipment and devices are supplied from SC ATB Power Supply System as a part of the Cosmodrome power supply system (see paragraph 2.3). The SC ATB electrical power supply system consists of:

- distribution devices 3 pcs;
- voltage check device 1 pc;
- socket outlets.

Two distribution devices are intended for supplying the consumers which need uninterrupted power supply, and one distribution device is intended for consumers allowing interruption of power supply no more than 45 s (power backup).

Distribution devices provide short-circuit protection and overload protection of supply units as well as load cable connections.

The maximum permissible load (steady current) for each feeder of distribution devices of uninterrupted power supply is 25 A, power backup -60 A.

Total power loads of all feeders for each uninterrupted power supply unit may not exceed 8 kW, and for power backup – 16 kW.

Explosion-proof sockets (2P+, 16 A, 6") are intended for connection of Customer's equipment cables 220 V, 50 Hz.

Voltage check device is intended for checking the parameters and correctness of phase sequence of voltage 380/220 V, 50 Hz for most critical consumers. In the event that parameters of voltage or phase sequence do not meet the specifications within more than 45s, the check device generates audible and light signals.

# 2.1.2 Launch Vehicle Assembly-and-Test Building

#### Launch Vehicle Assembly-and-Test Building Rooms


1	Airlock	$40.3 \text{ m}^2$
2	Power supply switchboard room	$11.1 \text{ m}^2$
3	Airlock	$4.2 \text{ m}^2$
4	Measuring system laboratory	$36.8 \text{ m}^2$
5	Passage	$13.4 \text{ m}^2$
6	Entrance airlock	$14.6 \text{ m}^2$
7	Stairway	-
8	Spare parts storage	$45.0 \text{ m}^2$



9	Guidance and control system laboratory	$21.8 \text{ m}^2$
10	Laboratory (shielded)	$47.0 \text{ m}^2$
11	Assembly and maintenance hall	425.0 m <sup>2</sup>
12	HM room	67.0 m <sup>2</sup>
13	Auxiliary room for personnel	$20.1 \text{ m}^2$
14	Auxiliary room for personnel	$3.0 \text{ m}^2$
15	Passage	$20.7 \text{ m}^2$
16	Duty officer's room	$9.86 \text{ m}^2$
17	Stairway	
18	Service room	$18.3 \text{ m}^2$
19	Power supply switchboard room	$13.4 \text{ m}^2$
20	Power supply switchboard room	$15.4 \text{ m}^2$
21	Transformer substation	$7.2 \text{ m}^2$
22	Transformer substation	$7.2 \text{ m}^2$
23	Hall	37.9 m <sup>2</sup>
24	Office	$20.6 \text{ m}^2$
25	Office	$21.3 \text{ m}^2$
26	Office	$23.8 \text{ m}^2$
27	Hall	51.4 m <sup>2</sup>
28	Passage	$28.4 \text{ m}^2$
29	Ventilation chamber	63.1 m <sup>2</sup>
30	Communications center	14.1 m <sup>2</sup>
31	Service room	22.1 m <sup>2</sup>
32	File of technical documentation	$12.0 \text{ m}^2$
33	Passage	66.4 m <sup>2</sup>
34	Ventilation chamber	22.5 m <sup>2</sup>

The layout of the LV ATB is presented in Fig. 2.10.







#### 2.2 Launch Site

The launch Site is used for implementation of pre-launch operations with the space launch system, launch vehicle and spacecraft, launch and post-launch operations.

The launch Site includes the following facilities:


- mission control center fitted out with the required equipment (measurement system receivers and transmitters, base timing system equipment, remote control panel, communication means, etc.)
- Launch Pad fitted out with base of astronomical orientation system, three geodetic reference points, diverters, etc.

The layout of facilities and units of START-1 Space Launch System at Launch Site is presented in Fig. 2.11.


The process of LV launch is monitored from an observation post located at 3 km from the Launch Pad.

The layout of the mission control center and equipment arrangement is presented in Fig. 2.12.











## 2.3 Cosmodrome Electrical Power Supply

The cosmodrome electrical power system is supplied by the federal power network and a self-contained backup power supply. The scheme of electrical power supply is presented in Fig. 2.13.

In the mission control center the following stationary self-contained power supplies are accommodated:

- Stationary automatic diesel-generator set
- Batteries incorporated in uninterrupted power supply (UPS) system.

In order to provide uninterrupted power supply to consumers, two uninterrupted power supply systems are used. Each system includes static inverters and batteries.

3-phase alternating voltage 380/220V, 50 Hz is supplied to uninterrupted power supply system from the federal power network or from automatic diesel-generator sets, which are automatically started and connected to power buses if federal power network fails. In this case interruption is no more than 45 s.

In case of absence of input voltage the power is supplied by UPS batteries through the inverter. UPS performance data is presented in Table 2.5.

Table 2.5

	Parameter	
	(a) Input Pa	rameters
1	(2) Nominal voltage (phase/line), V	220/380
2	A number of phases	3
3	Frequency, Hz	50
4	Voltage tolerance, %	+10, -15
	(a) Output 1	Parameters
1	Total power, kVA	17, 25
2	Nominal voltage, V	
	• phase	220
	• line	380
3	Nominal current, A	
	• at $\cos f = 1.0$	20
	• at $\cos f = 0.8$	25



4	Frequency, Hz	50
5	Duration of batteries continuous operation, min	10
6	Voltage maintenance accuracy, %	±3
7	Frequency maintenance accuracy, %	±1
8	Voltage transient deviation at 100% load-off/load-on	+10, -15
9	Transient process duration, s	=3

During operations with the SC at the Technical Site and Launch Site the stationery self-contained power supplies and two mobile support stations, which are included in START-1 Space Launch System, are used. Each mobile support station has two diesel-generator sets.

There are two schemes of power supply providing uninterrupted power supply:

- Scheme 1 (primary scheme) the main power supply is federal power network and the reserve power is diesel-generator set of mobile support station or stationary automatic diesel-generator set through UPS providing continuity of power supply during automatic transfer from main power supply to reserve one and back
- Scheme 2(reserve scheme) power is supplied from two diesel-generator sets of mobile support station to common buses with the load allowable for one diesel-generator set.

### 2.4 Telemetry Measurements

The LV on-board measurement system is used to receive telemetry and trajectory information (see paragraph 1.5, Volume I).

Telemetry information transmitted from LV is received during the powered flight using the receiving equipment of ground measurement stations.

LV flight sequence and SC separation are controlled through the use of telemetry and trajectory measurement systems in real time.

Based on the telemetry information received at SC separation from LV, the Provider presents spacecraft state vector to Customer 90 minutes after launch in order to estimate spacecraft orbit. SC separation is confirmed by the telemetry information.

While launching from Svobodny cosmodrome the following operations are performed:

- determination of LV and MS readiness for launch
- determination of exact time of LV launch
- reporting about LV flight sequence in real time
- refining the predicted parameters of SC separation
- post-launch analysis of LV systems operation based on the telemetry information received.






Fig. 2.13. Scheme of Cosmodrome Electrical Power Supply System



#### 2.5 Communications

The Technical and Launch Sites facilities and also some facilities in residential area are equipped with the following communications:

- Voice communication (intercom or telephone communication) between all rooms for SC preparation
- Two international telephone lines including fax machine with dedicated phone line
- Video monitoring system for clean rooms monitoring from SC control room
- Cable lines between computer terminals and between ground equipment elements
- Audible and light alarm.

If necessary two-way radio communication between EGSA and SC can be provided. Also satellite communication system may be used (satellite communication equipment is supplied by Customer).

#### 2.6 Residential Area

The Customer's personnel involved in the launch campaign are accommodated in a hotel located in a residential area, where the appropriate conditions are assured for comfort and safety.

There are one room and two room apartments in the hotel. Each apartment has well-equipped bathroom. Cable and satellite TV is available in each room.

On the ground floor there are recreation rooms and dinning room. Three meals per day are served for Customer's team.

Customer's team is provided with every day services and medical care. Cosmodrome hospital is available for Customer's personnel, other hospitals and clinics can be reached in 2-3 hours.

## 2.7. Optional Services: HM Environmental Conditions

## 2.7.1 Nitrogen Cooling System

In order to ensure required SC environmental conditions at the Technical Site and Launch Site, Provider can supply a Nitrogen Cooling System (NCS) to carry out the following ground operation:

- HM purging with dry nitrogen and creation of inert medium over SC
- Cooling the battery of SC integrated with HM
- Operations with SC battery out of HM with the use of Customer equipment (cryostat).



#### 2.7.2 Control of Environmental Conditions Inside Head Module

In order to provide continuous measurement, display and control of parameters of nitrogen medium over SC at Technical and Launch Sites a NCS local computer network can be supplied.

The parameters to be controlled as follows:

- Temperature and pressure (flow rate) of gaseous nitrogen in adapter/SC separation plane during HM pressurization
- Temperature of nitrogen dew point at NCS outlet
- Temperature and pressure under fairing
- Temperature of fairing internal surface.

In order to adapt the Nitrogen Cooling System to specific spacecraft the Customer shall provide the requirements for environmental conditions inside HM (nitrogen temperature, flow rate, dew point, etc.) and SC specifications (thermal characteristics and operating regimes).



# 3. Spacecraft Preparation at the Cosmodrome

Spacecraft preparation at the cosmodrome begins from the Customer hardware unloading from an aircraft in Blagoveschensk airport and its further transportation to cosmodrome Technical Site (about 250 km from the airport).

## 3.1. Transportation of Spacecraft and Ground Equipment

The Customer's hardware is transported from Blagoveschensk to cosmodrome by cosmodrome's trucks escorted by security and cosmodrome's, Customer's and Provider's technical personnel.

Any hydrazine (hazardous) containers are transported by special truck equipped with temperature and humidity control system, hydrazine vapour control system, communication system and neutralizing materials in case of hydrazine spillage.

The time taken to transport SC and ground equipment form airport to cosmodrome does not exceed 11 hours.

### 3.1.1. Transportation Conditions

The temperature and humidity environments during transportation are presented in Table 3.1.

Table 3.1

	Transported Equipment	Temperature, °C	Humidity, %	Environment Control equipment
1	Container with SC	+20±10	3580	Shall be provided
2	Container with sensitive equipment and hazardous materials	+25±15	3580	Shall be provided
3	Containers not containing sensitive equipment	-40+50	3595	-
4	Containers with hydrazine	+5+40	3580	Shall be provided

#### 3.1.2. Vehicles

Vehicles for cargo transportation from Blagoveschensk to the cosmodrome are as follows:

• Four-axle all-wheel drive tractor on the basis of MAZ-543A truck – for transportation of container with SC, sensitive equipment and hazardous materials



- Standard vehicles on the basis of trucks ZIL-130 (ZIL-131) and KAMAZ-4310 for transportation of ground mechanical equipment and other cargo
- Vehicle on the basis of GAZ-66 KUNG for transportation of containers with hydrazine
- Escort trucks including fire fighting and hydrazine neutralizing truck, handling vehicles, etc.

In transportation of spacecraft and ground equipment by the above mentioned vehicles vibration induced accelerations affecting shipping containers for frequency band 0.5...20 Hz do not exceed the values presented in Table 3.2.

Table 3.2

	Direction of Acceleration Load	(3) Maximum Values of Vibro-Accelerations, g				
	Acceleration Load	Vehicle				
		MAZ-543	ZIL-130/131		GAZ-66	
1	Vantical	0.75	2.5	2.0	2.5	
1	Vertical	0.75	2.5	2.0	2.5	
2	Transversal	0.6	2.0	1.8	2.0	
3	Longitudinal	0.6	2.0	1.8	2.0	

Permissible transportation speed for vehicles on the basis of MAZ-543A and KAMAZ-4310 trucks is no more than 40 km/h and for vehicles on the basis of ZIL-130 (ZIL-131) and GAZ-66 is no more than 25 km/h.

• Vibro-accelerations for SC fixing points during transportation of LV integrated with SC by mobile launcher are presented in Table 3.3.

Table 3.3

Frequency Band		Root-Mean-Square Acceleration, g	
1	0.17.5 Hz	0.35	



2 7.550 Hz	0.25
------------	------

Speed of transportation by mobile launcher does not exceed 15 km/h. The Table 3.3 shows vibro-accelerations acting along vertical axis, vibro-accelerations acting along longitudinal and lateral axes are 30% of the given values.

### 3.1.3. Hoisting Equipment

Hardware unloading from aircraft and loading to vehicles at Blagoveschensk airport are carried out with the use of aircraft hoisting equipment or special lorry-mounted crane with hoisting capacity no less than 10 tons.

Hardware unloading in SC ATB from the cosmodrome vehicles is also carried out by special lorry-mounted crane with the use of low-bed cargo trolley.

Lorry-mounted crane specifications:

• Type - hydraulic

Hoisting capacity (maximum) - 10 t

• Hoisting altitude - 12.6 m

• Hoisting speed -(0...6) m/s.

# 3.1.4. Customer's Hardware Storage Conditions

Customer's spacecraft and clean ground equipment are stored at SC ATB under the following conditions:

Temperature - (22±3)°C
 Relative humidity - (50±10)%

Containers with hydrazine and fueling equipment are stored at Special Fuelling Complex under the following conditions:

Temperature - (+5...+35)°C
 Relative humidity - (60±20)%

Shipping containers are stored at the site located near SC ATB.

## 3.2. Spacecraft Preparation in SC ATB

Operations with spacecraft in SC ATB begin from delivery of SC in shipping container by vehicle in SC ATB.



### 3.2.1. Spacecraft Processing

Customer personnel carry out operations with spacecraft in Clean Room 1 using Customer's equipment (integration stand, mountings, and rotation fixture other handling devices).

After completion of SC processing joint Customer/Provider team moves the spacecraft from Customer's stand to Provider's head module integration stand.

Herewith the following options of SC installation on HM adapter are possible:

- HM adapter and SC are placed on Customer's integration stand and then this adapter/spacecraft assembly is rotated to horizontal position (Fig. 3.1)
- HM adapter is integrated with SC after the SC is rotated to horizontal position using rotation fixture (Fig. 3.2).

Spacecraft is moved from Customer's stand to Provider's HMIS by bridge crane in Clean Room 1, options are presented in Figures 3.3 and 3.4.

### 3.2.2. Spacecraft Fueling with Hydrazine in Clean Room 2

After spacecraft has been placed on HMIS and cosmodrome personnel have prepared for fuelling the spacecraft on HMIS is moved from Clean Room 1 to Clean Room 2 and SC propulsion system is fuelled (see Fig. 2.9).

Preparation for fuelling and the fuelling are conducted by Customer's personnel. After propulsion system has been fuelled the spacecraft is moved to Clean Room 1, where its final assembly and electrical checkouts are carried out.

# 3.2.3. Head Module Assembling in Clean Room 1

HM assembly in Clean Room 1 is conducted by Provider's personnel. Beforehand HM trolley with installed fairing is delivered to SC ATB. HM trolley with fairing is moved to hall 24, where they are preliminarily cleaned, and then they are delivered to hall 25 and Clean Room 1. The fairing placed on HM trolley is integrated with SC by HM trolley pushing in HMIS, which has internal guiding rails for HM trolley. The process of head module assembling is presented in Figures 3.5, 3.6 and 3.7.

Electrical checkout of SC as a part of HM is a final phase of HM assembly operations in SC ATB, and after this head module on HM trolley is moved to hall 24 and then transported to LV ATB.

## 3.2.4. Head Module Transportation to LV ATB

HM inside standard sealed fairing container is transported from SC ATB to LV ATB (distance is about 200 m) by vehicle.

Hardware is placed in LV ATB in hall 11 with the use of bridge crane.






Fig. 3.1. Spacecraft with HM adapter on Customer's stand in horizontal position




Fig. 3.2. Spacecraft with HM adapter on Customer's rotation fixture in horizontal position






Fig. 3.3. Transfer of spacecraft 1 with adapter to HMIS by crane




Fig. 3.4. Transfer of spacecraft 2 with adapter to HMIS by crane






Fig. 3.5. Spacecraft placement inside the fairing




Fig. 3.6. Head module assembling




Fig. 3.7. Head module preparation for checkout and transport to LV ATB



### 3.3. Head Module Preparation in LV ATB

Operations in LV ATB are as follows:

- HM processing
- HM integration with LV
- Operations with S LV
- LV transportation to Launch Site.

After the head module is integrated with LV, during LV integrated tests in the LV ATB, the SC/LV transportation to Launch Site, ptr-launch preparation and launch operations at Launch Site, the initial SC temperature and humidity conditions are maintained by TLC temperature and humidity control system and they kept up to the launch time within the temperature range from 15°C to 25°C at relative humidity of less than 60%.

LV integrated with HM is transported to Launch Site by mobile launcher with a speed of about 5-7 km/h.

## 3.4. Launch Vehicle with Spacecraft Preparation at Launch Site

At Launch Site the following operations are conducted:

- Placement of launcher with LV and ground equipment at Launch Pad
- LV azimuthal orientation
- Electrical integration test of LV with SC and ground support equipment with recording of their operation parameters by MS receiving-and-recording equipment
- Launch
- Post-launch operations and equipment removing from Launch Pad.

Decision about launch implementation is taken based on the results of integration test.

Before launch three launch readiness regimes are set: 2-hours readiness, 1-hour readiness and 30-minutes readiness, during which countdown operations are implemented.

Arrangement of main facilities and components of START-1 Space Launch System at Launch Site is presented in Fig. 2.11, and Mission Control Center layout is presented in Fig. 2.12.

## 3.5 Post-Launch Operations

Final post-operations include dismantling and evacuation of Customer's and Provider's hardware from Launch Site to Technical Site and then its storage and placing into shipping cargo containers.



After launch under mutual agreement it is possible to place and store Customer's hardware for example, ground equipment, which is to be used for additional operations, in Technical Site facilities.

Specific program of hardware transportation from Svobodny Cosmodrome by air or by rail shall be agreed upon additionally.