

ShapePilot trace calibration sheet · dark centre — targets 180 × 240 mm

PRINT AT 100% — no fit-to-page, no shrink-to-fit, no borderless.

Measure first: triangles 100.00 mm apart, end bars 150.00, target diagonal exactly 300.00 mm.



TOP LEFT

PUT THE PART ON THE BLACK — centred between the ticks, flattest face down

CALIPER, triangle to triangle = 100.00 · RULE, bar to bar = 150.00

10

20

30

40

50

60

70

80

90

100

110

120

130

140

CALIPER, triangle to triangle = 100.00 mm · RULE, bar to bar = 150.00 mm

10

20

30

40

50

60

70

80

90

100

110

120

130

140

SHOOT: directly overhead, part centred, all four targets in frame. Zoom in rather than moving closer.

Diffuse light. No flash, and no shadow lying across an edge that matters.

Measure the part's HEIGHT too: 20 mm tall, 100 mm off centre, traces ~5 mm oversize uncorrected.

Black is for pale parts. Only the four targets are ever measured, so the middle of the sheet can be anything.