

ShapePilot trace calibration sheet — targets 180 × 240 mm

PRINT AT 100% — no fit-to-page, no shrink-to-fit, no borderless.

Measure first: triangles 100.00 mm apart, end bars 150.00, target diagonal exactly 300.00 mm.



TOP LEFT

CALIPER, triangle to triangle = 100.00 · RULE, bar to bar = 150.00

PUT THE PART HERE — centred, flattest face down

CALIPER, triangle to triangle = 100.00 mm · RULE, bar to bar = 150.00 mm

SHOOT: directly overhead, part centred, all four targets in frame. Zoom in rather than moving closer.

Diffuse light. No flash, and no shadow lying across an edge that matters.

Measure the part's HEIGHT too: 20 mm tall, 100 mm off centre, traces ~5 mm oversize uncorrected.

Pale or shiny part on white paper has no edge to find — use the dark-centre sheet for those.