Beam deflect

```
OEMP 3 Group 2 Part 5 a-c Group 11, 10:40 Lab
Code by: Daniel Mascarenas
clear;
clc;
Shear_Max = 27*10^3; % Maximum Transverse sheat stress
BendMax = 35*10^3; % Maximum Bending stress
%Length in inches
B = 3.75; % Base
H = 11.25; % Height
Area = 40.25; % (in<sup>2</sup>)
FOS = 1.5153; % Ideal Factor of Saftey
L = 27.25 *12; % Wing length (in)
t = 1.75; % Thickness (in)
w0 = 2001; %Beam weight
p = 0.098; % lb /in^3
w1 = 0.5*L*(2001/12);% Maximum lift force
w2 = -p*Area; % Maximum weight force
E = 9.9*10^6; % psi
I = ((B*H^3)/12) - (((H-2*t)*((B-2*t)^2))/12);% Moment of Inertia for
hollow square
V = ((w0/2)*(-L))+(w2*(L^2)); % Takes place at x = 0
Q = (4.49)*(Area/2); % 4.49 = y'
Shearstress = (V*Q)/(I*t*2) % Min shear
M = ((w0/2)*((L^2)/3))+((w2/2)*(L^2)); %Min bending stress
sig = (-1*(M*(H/2))/I) %min bending stress
deflection = ((w0*L^4)/(30*E*I)) + ((w2*L^4)/(8*E*I)) %Beam Deflection
 in inches
Fos_bend = abs(sig/Shear_Max) % Min shear FOS
Fos_shear = abs(Shearstress/BendMax)%Min bending stress FOS
feet = deflection/12 %Deflection in feet
Shearstress =
```

-4.3461e+04

sig =

-4.4820e+05

deflection =

171.8665

Fos_bend =

16.5999

Fos_shear =

1.2417

feet =

14.3222

Published with MATLAB® R2021a