## WHERE IS MY PROGRAM?

- Does my microcontroller run C language code?
- Where does it store its instructions?
- How does the microcontroller know where to begin?
- What happens during a reset?
- How does a computer *program* a microcontroller
- Are there going to be burgers in today's class?

## MICROCONTROLLER PROGRAMMING

Daniel Martínez

I7266 - Programación de Sistemas Embebidos

CUCEI - UDG

# **MEMORY**

## Do you remember?

The 21st night of September?

Love was changing the minds of pretenders

While chasing the clouds away

## MEMORY CLASSIFICATIONS

- Volatility
- Access method
- Read/write characteristics
- Physical location
- Functionality
- Technology
- Usage in CPU
- Data organization

## **VOLATILITY**

#### Volatile Memory:

• Loses its stored information when power is turned off. Examples include RAM (Random Access Memory).

### Non-Volatile Memory:

• Retains data even when power is turned off. Examples include CDs, flash memory, and hard drives.

## **ACCESS METHOD**

#### Random Access:

Allows data to be accessed in any random order. (RAM)

### Sequential Access:

 Requires accessing data in a sequential manner. Examples include tape drives and optical drives.

## READ/WRITE CHARACTERISTICS

#### Read-Only:

• Typically used for storing permanent or semi-permanent data, and the data cannot be easily modified. Examples include some optical drives.

#### • Read/Write:

• Allows both reading and writing of data. Examples include RAM and Flash memory.

## PHYSICAL LOCATION

#### Internal Memory:

• Embedded within the microprocessor or closely connected to it. Examples include Cache memory or SRAM.

### • External Memory:

• Separate from the microprocessor and connected via buses. Examples include EEPROM, hard drives, etc.

## **FUNCTIONALITY**

### • Primary Memory:

• Fast and used for temporary storage (e.g., RAM).

### Secondary Memory:

• Slower but provides larger storage capacity (e.g., hard drives).

### **TECHNOLOGY**

- Dynamic Random Access Memory (DRAM):
  - Requires periodic refresh to maintain data integrity.
- Static Random Access Memory (SRAM):
  - More stable and does not require frequent refreshing.
- Electrically Erasable Programmable ROM (EEPROM):
  - Non-volatile but needs UV light to be erased.
- Flash Memory:
  - Non-volatile memory commonly used in storage devices.

## USAGE INSIDE CPU

#### • Cache Memory:

• High-speed memory used by the CPU to store frequently accessed instructions and data.

### • Registers:

• Fast, small, and internal memory locations within the CPU.

# HELLO WORLD!

## NOT SO FAST...

# THE MINIMAL SYSTEM

What is needed for a microcontroller to work?

A minimal system refers to the basic set of components required to create a functional electronic system. The components in a minimal system may vary depending on the specific application, for embedded systems, some common elements include:

#### Microcontroller or Microprocessor:

 The central processing unit responsible for executing instructions and controlling the overall operation of the system.

#### Clock Source:

 A clock oscillator or crystal to provide the system with a timing reference, ensuring synchronization of operations

#### • Memory:

 This includes both volatile memory (RAM) and non-volatile memory (ROM, Flash), for storing data and program instructions, respectively.

#### Input/Output (I/O) Components:

• These could be sensors, actuators, communication interfaces, or other peripherals that allow the system to interact with its environment.

#### Power Supply:

 A source of electrical power to provide the necessary voltage levels for the components in the system.

#### Basic Support Components:

 Resistors, capacitors, and other passive components that are necessary for circuit stability and functionality.

### Power Supply:

 A source of electrical power to provide the necessary voltage levels for the components in the system.

#### • Basic Support Components:

- Resistors, capacitors, and other passive components that are necessary for circuit stability and functionality.

# ATMEGA328P MINIMAL SYSTEM

## **POWER SUPPLY**

- In the datasheet we can find the required power connections for the microcontroller to work, depending on our application, we might need to connect the following pins:
  - ACC
  - GND
  - AVCC
  - AREF

## **CLOCK SOURCE**

- A clock signal is needed to synchronize all the logic circuits inside the microcontroller. In the ATmega328P we have the following clock sources:
  - Low Power Crystal Oscillator
  - Full Swing Crystal Oscillator
  - Low Frequency Crystal Oscillator
  - Internal 128kHz RC Oscillator
  - Calibrated Internal RC Oscillator
  - External Clock

## **RESET**

# HELLO WORLD!

No BS this time!

### HELLO WORLD!

whut???

```
#define F_CPU 16000000U
   #include <avr/io.h>
    int main(void)
        DDRD &= ~(1 << PORTD2);
        while (1)
 9
10
            PORTD |= (1 << PORTD2);</pre>
11
12
13
14
```

# TALKING COMPUTER LANGUGE

## HEXADECIMAL

- The hexadecimal numbering system (hex for short) is used to represent nibbles.
  - Knowledge check:
    - A **bit** is a binary digit, i.e., 1 or  $\theta$ .
    - A **nibble** is a group of four bits, e.g., 1011.
    - A byte is a group of two nibbles (or eight bits), e.g., 11001111
- Hexadecimal uses the first ten digits, plus, A, B, C, D, E and F to represent quantities. Let's see how it is used.

## HEXADECIMAL

- In hex after the first ten numbers (from 0 to 9), the decimal values 10, 11, 12, 13, 14 and 15 are represented by A, B, C, D, E and F, respectively.
- Since four digits in binary can represent up to 15 (the binary number 1111) then a single hex character can represent four bits.
- For example, the binary number 1100, (a.k.a. 12 in decimal) is represented by the character C.
- This means we can represent a full byte with just two hex characters!

## HEXADECIMAL

- To represent a byte in the common computer science slang, for example, 10100101 in binary (or 165 in decimal) we use the hexadecimal notation 0xA5, where:
  - "0x" means "we are talking hexadecimal"
  - "A" represents the first four bits (from left to right) in binary:
    - 1010 in binary is 10 in decimal. Since it is in the second character position, its value in decimal is multiplied by 16.  $(10 \cdot 16 = 160)$
  - "5" represents the last four bits (least significative) in binary:
    - 0101 in binary is, unsurprisingly, 5 in decimal.

# **MEMORY**

One more time...

## WE ALREADY KNOW... DON'T WE?

- We have already seen different types of memory used in computer systems, however, we have yet to learn the uses for these kind of memory.
- Of all the classifications we explored, there are four key memory types:
  - ROM
  - RAM
  - Registers
  - Cache

ROM

Back to the burgers...

- In our "big company" examples, we know we must follow certain steps to achieve a desired output, these steps usually don't change. In computer systems, the place where we store our instructions is called ROM or Program Memory.
- ROM, in embedded systems, is located inside the microcontroller and it is not usually updated. It is intended to be programmed once and to need the very least number of updates possible.
- ROM is a type of non-volatile memory, since we need it to keep its contents for a long time.

#### RAM

More RAM, more FPS.


- RAM is our temporary storage; in our "big company" we need places to do what we are doing.
- We cannot prepare a burger on our hands, (and if we can, we should not), we need at least a table where we can place our ingredients.
- RAM, in embedded systems, is also located inside the microcontroller and it is written all the time while the microcontroller is working, it stores the data we need during the execution of a program.
- RAM is a usually a kind of volatile memory.

#### **REGISTERS**


More RAM, more FPS.

- The registers inside a microcontroller or microprocessor are small memory cells that are meant to hold some very important data that is useful for general purposes.
- In our "big company" these are like the boards where we place important company updates.
- Registers are usually implemented with some special logic cells like latches or flip-flops.
- When using the microcontroller, we will understand better how these registers are used and why.


## SR LATCH



## D FLIP-FLOP



## 8-BIT REGISTERS



# **ADDRESSES**

Where you at rn?

#### ADDRESSES AND RELATED CONCEPTS

- A memory address is a unique identifier for a specific location in the microcontroller's memory.
- We use addresses to identify addressable units. In most systems the smallest addressable unit is the byte, so, each memory cell can store a byte.
- The address space is the range of possible memory addresses that out control unit can generate.
- Word Addressing is accessing to memory with the addresses for words, this means, groups of bytes of a predefined size.
- Endianness refers to the order of multi-byte datatypes. We have Little-Endian and Big-Endian.

## THE MEMORY MAP


#### WHAT IS A MEMORY MAP?

- A memory map is the way a to describe how a computing system has its memory organized.
- It can represent different physical memory devices into one single address space.
- It can also represent multiple regions of a single memory device into the address map.
- We usually care about certain special memory regions that we will cover in detail later, this is the overview:


#### MEMORY REGIONS

- Program memory
  - This is the region where the code is stored, this refers to the ROM device.
- Data memory
  - This is the region where variables and constants are stored, this is usually in the RAM device.
- Registers
  - These are also mapped here.


## AVR MEMORY MAP




## 78KOR MEMORY MAP



## ARM CORTEX-M MEMORY MAP





# UPDATES!

# THANKS!

Please feel free to ask any related questions at any time.