
Power Supply
LiPo Charger
External Power Sense
Battery Measurement
ESP32-WROVER-IE MODULE
ESP32-WROVER & ESP32-WROOM-32 MODULEs
SD/MMC Card
Access Bus
USB to UART
VGA
Audio
LCD Connector
ESP32-WROVER Notes:
Software Selectable Pins
Internal Bootstrapping Resistors
Bootstrapping Pins Settings
PS/2 Port 0 -> Keyboard
PS/2 Port 1 -> Mouse
Mounting Holes
IO Expander
UEXT
Fiducials
OLIMEX LTD.
Title: ESP32-SBC-FabGL