L298 MOTOR DRIVER C1 _{ESP32-CAM} 220 35V OUT4 OUT1 MOTOR DE LA VENTANA 5V GND IO12 IO13 IO15 IO14 RVT 3.3V 15 14 13 12 11 10 9 IO16 IO0 GND U1:A www.TheEngineeringProjects.com VCC UoRX Sensor 1 > OUT2 (0)+12V GND +5V OUT3 UoTX GND 12V IO2 IO4 Sensor 2 > 74HC386 ENA IN1 IN2 IN3 IN4 ENB ESP32-CAM 12V Vcc OUT GND TestPin () GAS1 **BATERIA** MQ-135 SENSOR GAS CO2 12V MQ-4 TestPin **VENTILADOR** RL1 (O)12V 12V GND > Vcc OUT GND 0 0 www.TheEngineeringProjects.com **∆** GND PIR1 PIR SENSOR

L1