
UART Application Note



Document Title:	SIM52xx GPIO Application Note
Version:	0.01
Date:	2011-06-22
Status:	Release
Document Control ID:	SIM52xx_GPIO_Application_Note_V0.01

General Notes

Simcom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Simcom. The information provided is based upon requirements specifically provided to Simcom by the customers. Simcom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Simcom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of SIMCOM Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2010



Version History

Version	Chapter	Comments	Author
V0.01	New Version		Roma

SIMOM Confidential, Will Required



Contents

1.	Introduction
1.	1.1 Overview
	1.2 References.
	1.3 Terms and Abbreviations.
2.	UART function
2.	2.1 Standard mode (7 lines mode)
	2.2 Null mode (3 lines mode).
	2.2 Null mode (3 lines mode)
	COLLIA
	COLLINA
	COUNTY COUNTY

1. Introduction

1.1 Overview

This document will depict the usage of UART functions supplied by SIM52XX. User can get useful information about the SIM52XX's UART function quickly through this document.

SIM52XX UART can work in two modes:

- Standard mode.
- Null mode (default mode)

Seven UART pins: RX, TX, RI, DCD, DTR, RTS, CTS.

Note: This UART application note is to help user understand the above seven related GPIOs, which can be used as UART function and GPIO function. Please take care of the references.

1.2 References

- [1] SIMCOM_SIM52XX_ATC_EN_Vx.xx.doc.
- [2] SIM52xx GPIO Application note V0.01.doc
- [3] SIM5215E & SIM5216E HD Vx.xx.DOC

1.3 Terms and Abbreviations

For the purposes of the present document, the following abbreviations apply:

 AT ATtention, the two-character abbreviation is used to start a command line to be sent from TE/DTE to TA/DCE

2. UART function

2.1 Standard mode (7 lines mode)

When UART is in standard mode, all of the UART pins must follow the standard RS232 protocol. User can not set the UART pins to other functions, meaning that AT+CGFUNC is invalid.

Example:

AT+CSUART=1 // to set UART to work in standard mode
OK
AT+CGFUNC=10,0 // to disable DCD function of DCD pin



ERROR

//invalid AT command

2.2 Null mode (3 lines mode)

When UART is in NULL mode (the default mode), just RX and TX must follow the standard RS232 protocol. The other UART pins can be set to other function, such as GPIO function. User can get more information from the function table.

Pin name	Pin	Function	Detail
	number		
CTS	33	Flow control	Standard UART pin
		GPIO	General GPIO(input, output)
		ISR	Interrupt
RTS	34	Flow control	Standard UART pin
		GPIO	General GPIO(input, output)
		ISR	Interrupt
DTR	35	Data terminal ready	Standard UART pin
		Wake up me	Interrupt to wake up the module
		GPIO	General GPIO(input, output)
		ISR	Interrupt
DCD	36	Data carrier detect	Standard UART pin
		GPIO	General GPIO(input, output)
		ISR	Interrupt
RI	37	Ring indicator	Standard UART pin
		GPIO	General GPIO(input, output)
		ISR	Interrupt

Table 1 function table

In NULL mode, the UART pins except RX and TX will be set to their own special function. One simple example is the DCD function:

DCD pin number: 36

Special function: DCD function

GPIO function: general GPIO (default: output GPIO)

AT+CSUART=0 //to set UART to NULL mode OK //to get the current function of the DCD pin AT+CGFUNC=10 +CGFUNC: 1 //it's DCD function

AT+CGSETV=36,1 //it's invalid in DCD function

ERROR

AT+CGFUNC=10,0 //to disable DCD function, and enable GPIO function

OK

AT+CGSETV=36,1 //to set the DCD pin to output high-level voltage



Redilired

Contact us

Shanghai SIMCom Wireless Solutions Ltd.

SIMOM CONFIDENTIALS

Add: Building A, SIM Technology Building, No.633, Jinzhong Road, Changning District

200335

Tel: +86 21 3252 3300 Fax: +86 21 3252 3301

URL: http://www.sim.com/wm/