

1. Place these capacitors very close to the AVDD and DVDD and ground pins on the ADC.



2 2. Place these capacitors very close to the V+ and V- pins on the opamps.



3. The feedback resistors and capacitors should be placed close enough to have 3 low inductance but far apart enough for easy reworking by hand.



Photodiodes must be placed in a tight square formation.





Place these capacitors close to the REF and REFCAP pins on the ADC

6. Large contiguous areas of extra space on the board should have a 0.1" spacing grid of plated through holes for the addition of future through-hole components. Holes must be large enough for standard 1.1mm pins.

## Standoff holes in PCB







This part should appear on the BOM as 2x 10 pin female-

