


Battery and charging

- 1. When charging the battery, you need to remove the battery pack from the car and plug the charger into the DC socket of the battery pack to charge.
- 2.Don't use the battery while charging to prevent the charger or battery from exploding.
- 3.Please charge the battery when the voltage is about 11.1V. The battery voltage is about 12.6V after fully charged.

As shown below.

1) Insert charger into battery charging port.



2) The state of the indicator during charging is shown in the figure below.

