

MASTER

		Función		Función	
Entradas	Descripción	3.3V MPU	PB5 D13	D12 PB4	Pantalla LCD
			3V3	D11 PB3	
			REF	D10 PB2	
			PC0 A0	D9 PB1	
			PC1 A1	D8 PB0	
SDA1 / MPU	Resistor 4	Resistor 4	PC2 A2	D7 PD7	D7
SCL1 / MPU			PC3 A3	D6 PD6	D6
SDA2 / MASTER			PC4 A4	D5 PD5	D5
SCL2 / MASTER			PC5 A5	D4 PD4	D4
SDA3 / MASTER			ADC 6 A6	D3 PD3	D3
SCL3 / MASTER			ADC 7 A7	D2 PD2	D2
Salidas		VOLTAJE	5V	GND	D1
			PD6 RST	RST PC6	D0
			GND	RX PD0	TIERRA
			VIN	TX PD1	UART /ESP32
					UART/ESP32

SLAVE1

		Función		Función	
Entradas	Descripción	LASER	PB5 D13	D12 PB4	MOTOR DC
			3V3	D11 PB3	
			REF	D10 PB2	
			PC0 A0	D9 PB1	
			PC1 A1	D8 PB0	
SDA2 / MASTER	Resistor 4	Resistor 4	PC2 A2	D7 PD7	ULTRA SONICO / ECHO
SCL2 / MASTER			PC3 A3	D6 PD6	
ULTRASONICO			PC4 A4	D5 PD5	
			PC5 A5	D4 PD4	
			ADC 6 A6	D3 PD3	
Salidas		VOLTAJE	5V	D2 PD2	LED 6
			PD6 RST	GND	LED 5
			GND	RST PC6	LED 4
			VIN	RX PD0	LED 3
				TX PD1	LED 2
MOTOR DC		TIERRA			LED 1
LED 1					
LED 2					
LED 3					
LED 4					
LED 5					
LED 6					
LED 7					
LED 8					
LASER					

SLAVE2

		Función		Función				
Entradas	Descripción		PB5	D13	D12	PB4		
			3V3		D11	PB3		
			REF		D10	PB2		
		SDA3 / MASTER	INT1/STEPPER	PC0	A0	D9	PB1	SERVO MOTOR
		SCL3 / MASTER	INT2/STEPPER	PC1	A1	D8	PB0	
		SENSOR DE COLOR	INT3/STEPPER	PC2	A2	D7	PD7	
			INT1/STEPPER	PC3	A3	D6	PD6	OUT / SENSOR COLOR
	SDA3	PC4	A4	D5	PD5	S2 / SENSOR COLOR		
	SCL3	PC5	A5	D4	PD4			
Salidas			ADC 6	A6	D3	PD3	S1 / SENSOR COLOR	
			ADC 7	A7	D2	PD2	S0 / SENSOR COLOR	
			5V		GND		TIERRA	
		VOLTAJE	PD6	RST	RST	PC6		
		TIERRA	GND		RX	PD0		
				VIN		TX	PD1	