

Lect. #10: Revision


since 1839

Ahmed M. Zaki



#### Arduino UNO

MICROCONTROLLER	ATmega328P			
OPERATING VOLTAGE	5V	FLASH MEMORY	32 KB (ATmega328P) of which 0.5 KB used by bootloader	
INPUT VOLTAGE	7-12V			
(RECOMMENDED)		SRAM	2 KB (ATmega328P)	
INPUT VOLTAGE (LIMIT)	6-20V	EEPROM	1 KB (ATmega328P)	
DIGITAL I/O PINS	14 (of which 6 provide PWM output)	CLOCK SPEED	16 MHz	
PWM DIGITAL I/O PINS	6	LED_BUILTIN	13	
ANALOG INPUT PINS	6	LENGTH	68.6 mm	
DC CURRENT PER I/O PIN	20 mA	WIDTH	53.4 mm	
DC CURRENT FOR 3.3V PIN	50 mA	WEIGHT	25 g	






## 10 Configuration

```
#define DIG INP PIN
     #define DIG_INP_PULLUP_PIN 7
     #define DIG OUT PIN 1
     #define DIG_OUT_PIN_2
                                 12
     #define ANA INP PIN
                                 5
     #define ANA OUT PIN
                                 10
     void setup() {
       pinMode(DIG INP PIN, INPUT);
10
       pinMode(DIG_INP_PULLUP_PIN,INPUT_PULLUP);
       pinMode(DIG_OUT_PIN_1,OUTPUT);
12
       pinMode(DIG OUT PIN 2,OUTPUT);
   □void loop() {
15
         byte v1=digitalRead(DIG INP PIN);
16
         byte v2=digitalRead(DIG INP PULLUP PIN);
17
         unsigned int v3=analogRead(ANA INP PIN);
18
19
         digitalWrite(DIG OUT PIN 1,v1);
         digitalWrite(DIG_OUT_PIN_2,v2);
20
         analogWrite(ANA OUT PIN, v3>>2);
```

[0-13]
14 Digital I/O
----[3,5,6,9,10,11]
6 of them
PWM




6 Analog Inputs



## **IO Configuration**


```
#define DIG_INP_PIN
     #define DIG_INP_PULLUP_PIN 7
     #define DIG OUT PIN 1
     #define DIG_OUT_PIN_2
                                 12
     #define ANA INP PIN
     #define ANA OUT PIN
                                 10
    void setup() {
      pinMode(DIG INP PIN, INPUT);
      pinMode(DIG_INP_PULLUP_PIN,INPUT_PULLUP);
      pinMode(DIG_OUT_PIN_1,OUTPUT);
12
       pinMode(DIG OUT PIN 2,OUTPUT);
   □void loop() {
15
         byte v1=digitalRead(DIG INP PIN);
16
         byte v2=digitalRead(DIG INP PULLUP PIN);
17
         unsigned int v3=analogRead(ANA INP PIN);
18
19
         digitalWrite(DIG OUT PIN 1,v1);
         digitalWrite(DIG OUT PIN 2,v2);
20
         analogWrite(ANA OUT PIN, v3>>2);
```





# Interrupts (Timer)

```
1 #define DIG_OUT_PIN 2
 2 #include <MsTimer2.h>
 4 void isr (){
     static bool OUT_STATE=0;
     OUT_STATE=(OUT_STATE==0)?1:0;
     digitalWrite(DIG_OUT_PIN,OUT_STATE);
 8 }
10 void setup() {
    pinMode(DIG_OUT_PIN,OUTPUT);
    MsTimer2::set(20,isr);
    MsTimer2::start();
14 }
16 void loop(void) {
17 }
```





# Interrupts (Digital Pins With Interrupts)

```
1 #define DIG_INP_ON_PIN
                                                                       DIG INP OFF PIN
2 #define DIG_INP_OFF_PIN 3
 3 #define DIG_OUT_PIN
                                                                       DIG INP ON PIN
 4 void isr off (){
     digitalWrite(DIG_OUT_PIN,LOW);
 6 }
7 void isr_on (){
     digitalWrite(DIG_OUT_PIN,HIGH);
 9 }
10 void setup() {
    pinMode(DIG_OUT_PIN,OUTPUT);
                                                                      DIG_OUT_PIN
    pinMode(DIG_INP_ON_PIN,INPUT_PULLUP);
    pinMode(DIG_INP_OFF_PIN,INPUT_PULLUP);
    attachInterrupt(digitalPinToInterrupt(DIG_INP_OFF_PIN), isr_off, RISING );
    attachInterrupt(digitalPinToInterrupt(DIG_INP_ON_PIN) , isr_on , RISING );
16 }
18 void loop(void) {
19 }
```



# Interrupts (Digital Pins With Interrupts) – Cont.

```
1 #define DIG_INP_ON_PIN

    LOW to trigger the interrupt whenever the pin is low,

 2 #define DIG_INP_OFF_PIN 3
 3 #define DIG_OUT_PIN
 4 void isr off (){
                                                • CHANGE to trigger the interrupt whenever the pin changes value
     digitalWrite(DIG_OUT_PIN,LOW);
 6 }

    RISING to trigger when the pin goes from low to high,

 7 void isr on (){

    FALLING for when the pin goes from high to low.

     digitalWrite(DIG_OUT_PIN,HIGH);
 9 }
10 void setup() {
    pinMode(DIG_OUT_PIN,OUTPUT);
    pinMode(DIG_INP_ON_PIN,INPUT_PULLUP);
    pinMode(DIG_INP_OFF_PIN,INPUT_PULLUP);
    attachInterrupt(digitalPinToInterrupt(DIG_INP_OFF_PIN), isr_off, RISING );
    attachInterrupt(digitalPinToInterrupt(DIG_INP_ON_PIN) , isr_on , RISING );
16 }
18 void loop(void) {
19 }
```



# Interrupts (Digital Pins With Interrupts) – Cont.

```
BOARD
                                                                                                                                     DIGITAL PINS USABLE FOR INTERRUPTS
 1 #define DIG_INP_ON_PIN
                                                                                        Uno, Nano, Mini, other 328-based
                                                                                                                               2, 3
 2 #define DIG_INP_OFF_PIN
                                                                                        Uno WiFi Rev.2, Nano Every
                                                                                                                               all digital pins
 3 #define DIG_OUT_PIN
                                                                                                                               2, 3, 18, 19, 20, 21 (pins 20 & 21 are not available to use
 4 void isr off (){
                                                                                        Mega, Mega2560, MegaADK
                                                                                                                               for interrupts while they are used for I2C communication)
        digitalWrite(DIG_OUT_PIN,LOW);
                                                                                        Micro, Leonardo, other 32u4-based
                                                                                                                               0, 1, 2, 3, 7
 6 }
                                                                                                                               all digital pins, except 4
                                                                                        Zero
 7 void isr_on (){
                                                                                        MKR Family boards
                                                                                                                               0, 1, 4, 5, 6, 7, 8, 9, A1, A2
        digitalWrite(DIG_OUT_PIN,HIGH);
                                                                                        Nano 33 IoT
                                                                                                                               2. 3. 9. 10. 11. 13. A1. A5. A7
 9 }
                                                                                        Nano 33 BLE, Nano 33 BLE Sense
                                                                                                                               all pins
10 void setup() {
                                                                                        Due
                                                                                                                               all digital pins
      pinMode(DIG_OUT_PIN,OUTPUT);
                                                                                                                               all digital pins (Only pins 2, 5, 7, 8, 10, 11, 12, 13 work with
                                                                                        101
      pinMode(DIG_INP_ON_PIN,INPUT_PULLUP);
                                                                                                                               CHANGE)
      pinMode(DIG_INP_OFF_PIN,INPUT_PULLUP);
      attachInterrupt(digitalPinToInterrupt(DIG_INP_OFF_PIN), isr_off, RISING);
      attachInterrupt(digitalPinToInterrupt(DIG_INP_ON_PIN) , isr_on , RISING );
16 }
18 void loop(void) {
19 }
```



- UART: universal asynchronous receiver-transmitter
- I<sup>2</sup>C: Inter-Integrated Circuit
- SPI: Serial Peripheral Interface



## Communications UART/Serial

Used for communication between the Arduino board and a computer or other devices. All Arduino boards have at least one serial port (also known as a UART or USART), and some have several.

BOARD	USB CDC NAME	SERIAL PINS	SERIAL1 PINS	SERIAL2 PINS	SERIAL3 PINS
Uno, Nano, Mini		0(RX), 1(TX)			
Mega		0(RX), 1(TX)	19(RX), 18(TX)	17(RX), 16(TX)	15(RX), 14(TX)
Leonardo, Micro, Yún	Serial		0(RX), 1(TX)		
Uno WiFi Rev.2		Connected to USB	0(RX), 1(TX)	Connected to NINA	
MKR boards	Serial		13(RX), 14(TX)		
Zero	SerialUSB (Native USB Port only)	Connected to Programming Port	0(RX), 1(TX)		
Due	SerialUSB (Native USB Port only)	0(RX), 1(TX)	19(RX), 18(TX)	17(RX), 16(TX)	15(RX), 14(TX)
101	Serial		0(RX), 1(TX)		



UART/Serial (cont.)

# Arduino Mega example: // Arduino Mega using all four of its Serial ports // (Serial, Serial1, Serial2, Serial3), // with different baud rates: void setup() { Serial.begin(9600); Serial1.begin(38400); Serial2.begin(19200); Serial3.begin(4800); Serial.println("Hello Computer"); Serial1.println("Hello Serial 1"); Serial2.println("Hello Serial 2"); Serial3.println("Hello Serial 3"); } void loop() {}

- Serial.print(78, BIN) gives "1001110"
- Serial.print(78, OCT) gives "116"
- Serial.print(78, DEC) gives "78"
- Serial.print(78, HEX) gives "4E"
- Serial.print(1.23456, 0) gives "1"
- Serial.print(1.23456, 2) gives "1.23"
- Serial.print(1.23456, 4) gives "1.2346"



UART/Serial (cont.)

```
int incomingByte = 0; // for incoming serial data
void setup() {
  Serial.begin(9600); // opens serial port, sets data rate to 9600 bps
void loop() {
 // send data only when you receive data:
  if (Serial.available() > 0) {
   // read the incoming byte:
    incomingByte = Serial.read();
   // say what you got:
    Serial.print("I received: ");
    Serial.println(incomingByte, DEC);
```



UART/Serial (cont.)

```
void setup() {
    Serial.begin(9600);
}

void loop() {
    Serial.write(45); // send a byte with the value 45

    int bytesSent = Serial.write("hello"); //send the string "hello" and return the length of the string.
}
```




#### (I<sup>2</sup>C) Inter Integrated Circuit

- I2C or I<sup>2</sup>C came from the term Inter Integrated Circuit. You see two 'I's and one 'C'
- I2C is implemented by only Two Wires (SDA, SCL), it is also called TWI (Two Wire Interface).
- It is a kind of serial communication technology which is originally designed for exchanging data between multiple IC chips.
- This is very simple communication mechanism, and It is very smartly designed. It requires only two lines as. One of the line is used for sending Clock signal and the other line is to send/receive data.
- Also, these two lines can be shared by multiple devices. This communication works as Master-Slave mode. One Master can control / communicate multiple Slaves.




#### (I<sup>2</sup>C) Inter Integrated Circuit (Cont.)





### (I<sup>2</sup>C) Inter Integrated Circuit (Cont.)






## (I<sup>2</sup>C) Inter Integrated Circuit (Cont.)

How can a Master send data to a specific Slave?

Step	Direction	Message	
1	Master -> Slave	Start	
2	Master -> Slave	Slave Address	
3	Master <- Slave	Ack	
4	Master -> Slave	Data	
5	Master <- Slave	Ack	
6	Master -> Slave	Stop	






### (I<sup>2</sup>C) Example( Port Expander)

```
1 #include <Wire.h>
  2 #define IN_ADDRESS 80
                                                                                            I2c device is detected at address :80
                                                                                            I2c device is detected at address:81
  3 #define OUT_ADDRESS 81
  4 void I2C_scan(void){
       for (byte address=0;address<127;address++){</pre>
           Wire.beginTransmission(address);
          byte error=Wire.endTransmission();
          if (!error){
                                                                                           Arduino Uno-4
                  Serial.print("I2c device is detected at address :");
                  Serial.println(address):
 11
12
13 }
14 void setup(){
       Wire.begin();
                                                                                                                      GND
GND
5V
3V3
RST
       Serial.begin(9600);
17
       I2C_scan();
18 }
                                                                              I2CToParallel-1077
19 void loop(){
                                                                                            Value
20
          Wire.requestFrom(IN_ADDRESS, 1);
                                                                              I2CToParallel-1077
21
22
23
24
25
26 }
          byte read_val = Wire.read();
                                                                                            12CToParallel
          Wire.beginTransmission(OUT_ADDRESS);
                                                                                            I2CToParallel-1077
          Wire.write(read_val);
                                                                               Show id
          Wire.endTransmission();
                                                                               Control Code
          delay(100);
```



#### (SPI) Serial Peripheral Interface


- Serial Peripheral Interface (SPI) is a synchronous serial data protocol used by microcontrollers for communicating with one or more peripheral devices quickly over short distances. It can also be used for communication between two microcontrollers.
- With an SPI connection there is always one master device (usually a microcontroller) which controls the peripheral devices. Typically, there are three lines common to all the devices:
  - MISO (Master In Slave Out) The Slave line for sending data to the master,
  - MOSI (Master Out Slave In) The Master line for sending data to the peripherals,
  - SCK (Serial Clock) The clock pulses which synchronize data transmission generated by the master and one line specific for every device:
  - SS (Slave Select) the pin on each device that the master can use to enable and disable specific devices.
- When a device's Slave Select pin is low, it communicates with the master. When it's high, it ignores the master. This allows you to have multiple SPI devices sharing the same MISO, MOSI, and CLK lines.
- Arduino UNO (SCLCK: 13, MISO: 12, MOSIO: 11, SS: 10)





#### (SPI) Example (LCD SW/HW)

```
15 #include <SPI.h>
16 #include <Adafruit_GFX.h>
17 #include <Adafruit_PCD8544.h>
19 // Software SPI (slower updates, more flexible pin options):
20 // pin 7 - Serial clock out (SCLK)
21 // pin 6 - Serial data out (DIN)
22 // pin 5 - Data/Command select (D/C)
23 // pin 4 - LCD chip select (CS)
24 // pin 3 - LCD reset (RST)
25 Adafruit PCD8544 sw display = Adafruit PCD8544(7, 6, 5, 4, 3);
27 // Hardware SPI (faster, but must use certain hardware pins):
28 // SCK is LCD serial clock (SCLK) - this is pin 13 on Arduino Uno
29 // MOSI is LCD DIN - this is pin 11 on an Arduino Uno
30 // pin 10 - Data/Command select (D/C)
31 // pin 9 - LCD chip select (CS)
32 // pin 8 - LCD reset (RST)
33 Adafruit_PCD8544 hw_display = Adafruit_PCD8544(10, 9, 8);
34 // Note with hardware SPI MISO and SS pins aren't used but will still be read
35 // and written to during SPI transfer. Be careful sharing these pins!
37 void setup() {
    sw_display.begin();
    sw_display.clearDisplay(); // clears the screen and buffer
    sw_display.drawPixel(10, 10, BLACK);
    sw_display.display();
    hw_display.begin();
    hw_display.clearDisplay(); // clears the screen and buffer
    hw_display.drawPixel(30, 30, BLACK);
    hw_display.display();
47
49 void loop() {
```





#### Difference Between I2C vs SPI

#### What is I2C Protocol?

I2C stands for Inter-Integrated Circuit. I2C is a simple two-wire serial protocol used to communicate between two devices or chips in an embedded system. I2C has two lines SCL and SDA, SCL is used for clock and SDA is used for data.

#### What is SPI Protocol?

SPI stands for Serial Peripheral interface. SPI is a four-wire serial communication protocol. SPI follows master-slave architecture. The four lines of SPI are MOSI, MISO, SCL and SS. SCL is a serial clock that is used for entire data communication. Slave Select(SS) is used to select the slave. Master out Slave In (MOSI) is the output data line from the master and Master in Slave out(MISO) is the input data line for the Master.

#### **Advantage I2C:**

• Easy device add on: It is easy to add new slave devices into the bus. Just add the new device without adding a new slave select unlike SPI.

#### Advantage SPI:

• Speed : SPI can support up to 10MB/s however I<sup>2</sup>C in the ultra-fast mode can support only 5MB/s.

