
## **Overhead Three Phase Fault Indicator**

**Utility Network Detailed Model** 



## Key

**Electric Line** 

- ☐ Medium Voltage Conductor☐ Overhead Single Phase
- Electric Junction

  Medium Voltage Attachment

  Overhead
- Electric Device

   Medium Voltage Line Monitor and Relay
   Fault Indicator
- Structure Junction

  LElectric Medium Voltage Pole
  Length Single Pole
- - > Structural attachment association
  - Electric Assembly

    Medium Voltage Line Monitor and Relay
    Fault Indicator