
USER MANUAL

Red Light Therapy & Vibration Belt

rePretty Arc Y2



Please read this manual carefully before use.
For personal at-home wellness use.

CONTENTS

01	Getting Started	01
02	Product Overview	02
03	Product Highlights	04
04	What's Included	05
05	Important Safety Information	06
06	Controller & Button Functions	07
07	How to Use	10
08	Cleaning, Care & Storage	12
09	Customer Support	13
10	Warranty & After-Sales Support	14
11	General Wellness Notice	14
12	Troubleshooting	15
13	Technical Specifications	16
14	Where to Use	17
15	Fit, Light & Charging Guide	19
16	Frequently Asked Questions	20

Welcome to rePretty

Wellness should feel simple, dependable, and easy to maintain.

Thank you for choosing rePretty Arc Y2, a cordless red light therapy belt for targeted back pain relief, muscle relaxation, and recovery after activity. Use it during a break after hours at a desk or on your feet. Add vibration when your muscles feel tight, or remove the support stays for a softer fit while you rest.

This rechargeable belt combines 660nm red and 850nm near-infrared light, optional vibration, preset timers, adjustable support, and cordless convenience in one wearable design. It can be used after activity, during a break, or as part of a comfortable personal wellness routine.

Before using the belt, read this manual carefully and keep it for future reference.

1. Getting Started

Before First Use


- Inspect the belt, integrated controller, charging port, and charging cable. Do not use the product if any part is damaged.
- Fully charge the belt while it is switched off, dry, and disconnected from your body.
- Place the light-emitting side against clean, dry, intact skin and adjust the strap for a secure, comfortable fit.
- Keep the controller within easy reach and disconnect the charging cable before operation.

Recommended First Session

Start with light setting L1, vibration setting A1, and a 10- to 15-minute session. Increase the setting only when use remains comfortable.

Important: Do not exceed 30 minutes per session. Stop use if you feel pain, burning, unusual heat, numbness, persistent redness, or other discomfort.

2. Product Overview



The rePretty Arc Y2 is a rechargeable red light therapy belt for back pain relief and muscle relaxation. This flexible red light therapy back wrap combines red and near-infrared light with optional vibration, preset timers, and removable stays for adjustable lower back support. Wrap it around your waist or another suitable area where muscles feel sore after work or exercise.

Item	Details
Overall Dimensions	Approx. 53.1 × 9.8 in
Recommended Waist Fit	Up to Size: W48
LED Configuration	176 pcs 3-in-1 LED beads
Wavelengths	660nm red + 850nm near-infrared
Battery	Built-in rechargeable 5000 mAh

Main Functions

Light

L1, L2, and L3 provide progressively increasing steady-light brightness. C2 provides 10 Hz pulsed light, and C3 provides 40 Hz pulsed light.

Vibration

A1 through A4 select four vibration timing patterns. A0 turns vibration off for light-only use. Press and hold the Vibration button to select B1, B2, or B3 intensity; B2 is the default.

Timer

Select 10, 15, 20, or 30 minutes. The belt counts down and switches off automatically when the session ends.

Adjustable Support

The pre-installed support stays provide a firmer feel while worn. Remove them when a softer, more flexible fit is preferred.

3. Product Highlights

- **176 pcs 3-in-1 LEDs:** Each LED bead combines 660nm red and 850nm near-infrared light for broad, targeted coverage in a dual wavelength red light belt.
- **Adjustable Light Settings:** Three steady-light brightness levels plus 10 Hz and 40 Hz pulsed settings.
- **Independent Vibration Control:** Use the red light therapy belt with vibration as a back massage belt to help relax tight, sore muscles. Choose among four timing patterns and three strengths, or select A0 for light-only use.
- **Built-In 5000 mAh Battery:** The wireless red light therapy belt supports rechargeable cordless operation away from a power outlet.
- **Breathable Ice-Silk Mesh Lining:** The inner fabric provides a soft, breathable feel during use.
- **Adjustable Fit and Support:** This adjustable lumbar support belt has two removable aluminum stays for firmer lower back support. Keep them in for a more structured fit while standing, or take them out for a softer wrap while seated.
- **Preset Timers:** Four timer choices make it easy to select a comfortable session length.

Use Tip: Fit the belt snugly enough for even contact, but never so tightly that breathing or circulation feels restricted.

4. What's Included

Check the package before first use. If an item is missing or damaged, contact rePretty Customer Support.

Item	Qty.
Red Light & Vibration Belt with integrated controller	1
USB charging cable	1
User manual	1

Before You Continue

- Confirm that the light-emitting surface and charging port are clean and dry.
- Keep the manual and your order information for future support.
- Do not operate the belt while it is connected to the charging cable.


5. Important Safety Information

Before and During Use

- Use only on clean, dry, intact skin. Do not use over open wounds or actively irritated skin.
- Do not use while sleeping, unconscious, or unable to operate the product safely.
- Keep the light-emitting surface away from the eyes and do not look directly at the LEDs.
- Keep the belt, controller, charging port, and cable dry. Do not spray, wash, soak, or submerge the product.
- Charge only while the belt is switched off and dry. Disconnect the charging cable before use.
- Do not sharply fold the belt, crush the controller, or place heavy pressure on the LED area or support stays.
- Do not disassemble, modify, or repair the product. Stop use if it becomes damaged, abnormally hot, or behaves unexpectedly.
- Do not fasten the belt so tightly that it restricts breathing or circulation.

Special Precaution: Consult a qualified healthcare professional before use if you are pregnant, have reduced skin sensation, are sensitive to light, take medication that may increase light sensitivity, use an implanted electronic device, or are receiving care for a skin-related condition. Children should use the product only under close adult supervision; keep it away from infants and toddlers.

6. Controller & Button Functions



From left: Display, Vibration Button, Light Button, Power/Timer Button

Display: Shows the selected light mode, vibration pattern A0-A4, vibration intensity B1 – B3, or remaining session time. On the segmented display, B may look like 8.

Vibration Button: Short-press to cycle A1, A2, A3, A4, then A0. Press and hold to select B1, B2, or B3 intensity. The default is B2.

Light Button: Cycles L1, L2, L3, C2, and C3.

Power/Timer Button: Press and hold for about 1 second to switch the belt on or off. Briefly press to change the timer.

Display	Light Mode	Indicator
L1	Steady - Level 1	White
L2	Steady - Level 2	Orange
L3	Steady - Level 3	Blue
C2	10 Hz Pulsed	Cyan
C3	40 Hz Pulsed	Purple

Setting Cycles

Light: L1 → L2 → L3 → C2 → C3 → L1

Vibration: A1 → A2 → A3 → A4 → A0 → A1

Vibration Intensity: B1 (Low) / B2 (Medium, default) / B3 (High)

Timer: Starts at 15 minutes; adjustments cycle 20 → 30 → 10 → 20 minutes.

Vibration Patterns


Setting	Pattern
A1 - Gentle Pulse	0.5 s vibration, 1.5 s pause, repeat
A2 - Rapid Pulse	10 quick pulses, 2 s pause, repeat
A3 - Progressive	Output gradually rises from low to high, repeat
A4 - Combination	Cycles through A1, A2, and A3, repeat
A0 - Off	Vibration is switched off

Vibration Intensity: Press and hold the Vibration button to select B1 (Low), B2 (Medium, default), or B3 (High). On the segmented display, the letter B may look like 8, so B2 may appear as 82.

Suggested Starting Points

- First use: L1 + A1 + B1 or B2 for 10 – 15 minutes.
- Everyday relaxation: L2 + A1 or A2 + B2.
- After prolonged sitting or standing: L3 + A3 + B2, if comfortable.
- After physical activity: C2 or C3 + A2 or A4; select B3 only if a stronger intensity is preferred.

Vibration Pattern Timing Guide



How to Read: A1-A4 change the vibration timing pattern. B1-B3 change the vibration strength without changing the selected timing pattern.

7. How to Use

Charging

- Switch off the belt and make sure the charging port, cable connector, and surrounding area are dry.
- Connect the charging cable to the marked USB port. The battery indicator flashes while charging.
- The belt cannot operate while charging. Disconnect the cable before use.
- A full charge provides approximately 2-3 hours of use, depending on the selected light and vibration settings.

Position the Belt

Place the light-emitting side of the red light waist belt against clean, dry, intact skin. Adjust the strap for close, even contact without excessive pressure. Keep the controller facing outward and within easy reach.

Support Stays: Keep the stays installed for a firmer feel. Remove them when resting or when a softer, more flexible fit is preferred.

Operating Steps

1. Turn On

Press and hold the Power/Timer button for about 1 second. The default timer is 15 minutes.



2. Select Light

Press the Light button until the desired setting appears. L1 is recommended for first use.



3. Select Vibration

Short-press the Vibration button to select A1-A4, or A0 for light-only use. Press and hold to select B1, B2, or B3. The default intensity is B2.



4. Set the Timer

The initial timer is 15 minutes. Briefly press the Power/Timer button to cycle 20, 30, and 10 minutes.



5. Turn Off

Press and hold the Power/Timer button for about 1 second. Remove the belt and allow it to cool before storing or charging.



After Use: Switch off the belt, remove it gently, allow it to cool, and wipe the inner surface if needed. Let it dry completely before charging or storage.

8. Cleaning, Care & Storage

- Switch off the belt and disconnect the charging cable before cleaning.
- Wipe the belt, controller, and strap gently with a soft, dry, lint-free cloth. If necessary, use a lightly dampened cloth, then dry the product completely.
- Never spray liquid directly on the product. Do not soak, submerge, machine-wash, dry-clean, bleach, or use strong solvents or abrasive cleaners.
- Allow the belt to dry completely before charging, using, folding, or storing.
- Avoid sharp folds, crushing the controller, or placing heavy pressure on the light-emitting surface.
- Store in a cool, dry place away from direct sunlight, heat sources, and heavy objects.

Storage Check

Before the next use, confirm that the belt, integrated controller, charging port, cable, and light-emitting surface are clean, dry, and undamaged.

9. Customer Support

For setup, operating, or after-sales assistance with your rePretty Arc Y2, use the official support contacts below:

 Website: re-pretty.com

 Email: support@re-pretty.com

For an operating issue, include your Amazon order number, product-label information, and clear photos or a short video.

Before contacting support, check the Troubleshooting section. Stop using the belt if it is damaged, abnormally hot, or behaves unexpectedly.

10. Warranty & After-Sales Support

Warranty coverage and duration are governed by the terms associated with your purchase and marketplace. Keep your order number and product-label information.

If the belt does not operate normally, stop using it and contact rePretty Customer Support. Provide your order number, a description of the issue, and photos or a short video when available.

Do Not Repair: There are no user-serviceable parts. Do not disassemble or modify the belt, controller, charging port, or battery.

11. General Wellness Notice

This product is intended for general wellness and personal self-care use. It is not a substitute for professional healthcare advice. Consult a qualified healthcare professional if you have health concerns or are unsure whether the product is appropriate for you.

Individual experiences may vary. No specific result or time frame is guaranteed.

12. Troubleshooting

Issue	What to Check
Belt does not turn on	Charge the battery. Confirm the belt is dry, disconnected from the cable, and the Power/Timer button is held for about 1 second.
Light does not operate	Press the Light button and confirm L1, L2, L3, C2, or C3 appears on the display.
Vibration does not operate	A0 means vibration is off. Select A1-A4. Press and hold the Vibration button to adjust B1-B3 intensity.
Belt does not charge	Switch it off. Check that the port and connector are dry and the USB cable and power source are connected securely.
Belt feels too warm	Stop the session, loosen or remove the belt, and allow it to cool. Contact support if unusual heat continues.
Fit feels uncomfortable	Loosen the strap, reposition the belt, or remove the support stays for a softer fit.

Support Request: If the problem continues, stop using the belt and contact support@re-pretty.com.

13. Technical Specifications

Item	Specification
Product Name	Red Light & Vibration Belt
Model	rePretty Arc Y2
LED Quantity	176 pcs 3-in-1 LED beads
Overall Dimensions	Approx. 53.1 × 9.8 in
Recommended Waist Fit	Up to approx. 48 in, namely Waist Size W48
Wavelengths	660nm red + 850nm near-infrared
Light Modes	L1/L2/L3 steady; C2/C3 pulsed
Vibration Modes	A0 off; A1/A2/A3/A4 timing patterns
Vibration Intensity	B1 low; B2 medium (default); B3 high
Session Timer	10 / 15 / 20 / 30 minutes
Battery Capacity	Built-in rechargeable 5000 mAh
Controller	Display; Vibration; Light; Power/Timer

Refer to the product label for model-specific information. Keep this manual and your order details for future support.

14. Where to Use

Use this flexible red light wrap for targeted pain relief and muscle relaxation. Find the sore area below and follow its settings on the next page.

Common body names	Everyday relief and positioning
Lower back / waist	Lower back pain or stiffness after desk work, standing, or driving. Place the LEDs over the sore area.
Belly / stomach / tummy	Lay the red light therapy waist belt across the belly for comfort and relaxation. Keep the fit loose.
Sides of the waist	For tight muscles after chores. Lay the LED section flat along the side of your waist.
Hips / buttocks	For sore hips or buttocks after walking or standing. Place the wrap alongside the sore area. Do not sit on it.
Legs: thighs / calves	For sore thighs or calves after a walk, run, or workout. Reposition the wrap without tight overlap.
Arms: upper / lower	Relax sore upper or lower arms (forearms) after computer work, chores, or exercise. Keep a comfortable fit.
Upper chest / side ribs	For gentle light contact on the upper chest or side ribs. Keep the fit loose and away from the neck and throat.

Recommended Light and Vibration Settings

Body Area	Light	Pattern	Intensity	Session	Frequency
Lower back / waist	L1-L2	A1-A2	B1-B2	15-20 min	3-5/week
Belly / stomach / sides	L1-L2	A0-A1	B1-B2	10-15 min	3-5/week
Hips / buttocks	L1-L2	A1-A2	B1-B2	15-20 min	3-5/week
Legs: thighs / calves	L2-L3/C2	A1-A3	B2-B3	15-20 min	3-6/week
Arms: upper / lower	L1-L2/C2	A0-A2	B1-B2	10-15 min	3-5/week
Upper chest / side ribs	L1	A0-A1	B1	10-15 min	3-5/week

Important: Starting points only. Do not exceed 30 minutes per session. For chest use, keep the belt loose, do not restrict breathing, and keep it away from the neck and throat. If you have an implanted electronic device, consult a qualified healthcare professional before use.

Adjusting the Session

- For the first use on any suitable area, begin with L1 and A0 or A1 for 10-15 minutes.
- Keep the LED section flat without sharp folds or tight overlap. Keep the controller outward, and loosen or reposition the belt if it causes pressure, numbness, tingling, or discomfort.

15. Fit, Light & Charging Guide

Fit & Wearing

- Wear the infrared waist belt around the waist, lower back, abdomen, hips, thighs, calves, upper arms, forearms, or a comfortable upper-chest or rib area where it can lie flat and secure.
- Position the light-emitting surface toward the body and keep the controller facing outward and within easy reach.
- The adjustable fit is intended for waist sizes up to approximately 48 in. Do not fasten it tightly enough to restrict breathing or circulation.
- Use the removable support stays for a firmer feel, or remove them for a softer and more flexible fit.

Understanding the Light

660nm red light is visible to the eye. 850nm near-infrared light is less visible and may appear dim or nearly invisible during normal operation.

LED Check: Some LEDs may look dim because 850nm near-infrared light is not easily visible. This alone does not mean the belt is malfunctioning.

Charging & Battery

- The belt contains a built-in rechargeable 5000 mAh battery, which is UL certified.
- A full charge provides approximately 2-3 hours of use, depending on the selected settings.
- Charge only while the belt is switched off and dry. Disconnect the cable before wearing or operating the belt.

16. Frequently Asked Questions

Back Pain and Everyday Relief

Q1. What can I use Arc Y2 for?

A: Arc Y2 is a cordless red light therapy belt for back pain relief, muscle relaxation, and recovery after activity. Red and near-infrared light, optional vibration, and removable support stays combine targeted comfort with an adjustable fit.

Q2. How can it help with a stiff, aching lower back?

A: After a long stretch of sitting, Arc Y2 makes red light therapy for lower back pain easy to fit into a break. Center the LEDs on sore lower-back muscles. Start with L1–L2, gentle vibration, and 15–20 minutes.

Q3. Is it suitable for long days at a desk or computer?

A: Yes. This cordless red light belt for back pain fits into a desk break away from an outlet. The stays add firmer lower back support. Take them out for a softer fit while you rest.

Q4. Can I use it after standing all day?

A: Yes. For back pain relief after a long shift on your feet, wrap Arc Y2 around your lower back. The stays add firmer lower back support. Remove them while resting. Add gentle vibration if your back feels tight. The lower-back guide suggests 15–20 minutes.

Q5. Can I use it after a long drive or flight?

A: Yes. The cordless Arc Y2 lets you fit red light therapy for back pain into a break after a long drive or flight. Once parked or settled at your destination, wrap it around your lower back to help relax tight muscles. Keep the controller within reach.

Frequently Asked Questions

Exercise Recovery and Active Days

Q6. Can I use it for muscle recovery after a workout?

A: Yes. After a workout, place the red light therapy wrap over sore muscles in your lower back, hips, or legs. The flexible panel directs light to the area you want to relax. Add vibration if you want a massage feel during your recovery break.

Q7. Can I use it on tired legs after a walk or run?

A: Yes. Use the red light wrap to help relieve soreness in a thigh or calf after walking or running. Place the LEDs over one area at a time. The leg guide suggests 15–20 minutes. Begin gently on a new area.

Q8. What if my back feels sore after housework or gardening?

A: For lower back pain after housework or gardening, center the red light back wrap over the sore muscles. Take out the stays for a softer fit while you rest, and add gentle vibration to relax tight muscles.

Q9. Can it help me unwind after lifting or carrying things?

A: Use Arc Y2 during an after-activity break to relax tight lower-back muscles. Choose a comfortable fit and session length; avoid tightening the straps or increasing the setting simply because the area feels sore.

Q10. Can I use it when my muscles feel stiff in the morning?

A: Yes. A short, gentle session can help you ease into your morning routine and relax stiff muscles. Begin with L1 and A0 or A1 for 10–15 minutes before choosing a stronger setting.

Frequently Asked Questions

Belly Waist Hips and Legs

Q11. Can I wear it across my belly?

A: Yes. Arc Y2 offers red light therapy for stomach and waist comfort. Lay the LED side flat across the front of your waist or belly. Begin with L1–L2 and 10–15 minutes, with a loose, comfortable fit.

Q12. Can I wrap it around the side of my waist?

A: Yes. Position the red light stomach wrap along the side of your waist if that is where your muscles feel tight. Keep the LED section flat. Adjust the strap for even contact without tight overlap or pressure.

Q13. Is Arc Y2 mainly for pain relief or for belly fat and weight loss?

A: Choose Arc Y2 for targeted pain relief, muscle relaxation, and comfortable light sessions. It can be worn across the belly, but this manual does not promise belly-fat loss or weight reduction from wearing the belt.

Q14. Can I use red light therapy for hip pain or sore buttock muscles?

A: Yes. For sore hip or buttock muscles after walking or standing, place the Arc Y2 red light therapy wrap alongside the sore area for pain relief and muscle relaxation. The hip guide suggests L1–L2 and 15–20 minutes. Do not sit directly on the controller or LED section.

Q15. Can I move it between my thighs and calves?

A: Yes. The same flexible red light therapy wrap can fit around a thigh or calf wherever the LED section lies flat and the strap closes comfortably. Switch the belt off before moving it between the upper and lower legs, then follow the leg settings.

Frequently Asked Questions

Arms Chest and Comfortable Fit

Q16. Can it ease tired arms after computer work, chores, or exercise?

A: Yes. Use the same Arc Y2 red light wrap on your upper arm or forearm to relax muscles and relieve soreness after computer work, chores, or exercise. Start with L1–L2 or C2 for 10–15 minutes.

Q17. Where can it be placed around the upper chest or ribs?

A: The upper chest and side-rib area can be used for a gentle light session where the wrap lies flat. Choose L1, low or no vibration, and 10–15 minutes. Keep the fit loose and away from your neck.

Q18. Will it fit a 48-inch waist?

A: This adjustable back support belt fits waists up to about 48 inches (W48). Measure around the spot where you plan to wear it. The belt measures about 53.1 by 9.8 inches laid flat. Use the straps to adjust the fit for even contact without squeezing.

Q19. Should I keep the removable support stays in or take them out?

A: Keep both aluminum stays in this infrared back brace for a firmer fit. Take them out when you want a softer lower back support belt while sitting or reclining, or when wrapping another suitable area.

Q20. Can I sit or recline while wearing it?

A: Yes. An adjustable lumbar support belt can make a seated break more comfortable, with or without its stays. Keep Arc Y2 flat and avoid trapping the LEDs, controller, or support stays beneath your body.

Frequently Asked Questions

Light Massage and Support Together

Q21. Why choose this instead of an ordinary back support belt?

A: Arc Y2 gives you a back support belt and an infrared back pain relief device in one wrap. Two removable aluminum stays give you firmer lower back support. Take them out for a softer fit while seated. Use the built-in red and near-infrared light with optional vibration in the same session.

Q22. Do I have to stay near an outlet?

A: No. This cordless infrared belt runs on a built-in 5000 mAh battery. Charge it first and disconnect the cable. Then settle on the couch or in a reading chair. The controls are built into the belt, so there is no separate controller to carry.

Q23. What do the two wavelengths and 176 LEDs add?

A: This dual wavelength red light therapy belt combines 660nm red light and 850nm near-infrared light in 176 three-in-one LED beads. The wearable shape keeps the light-emitting surface directed toward the body area you choose.

Q24. Does relief depend on the belt becoming hot?

A: No. Red light therapy for back pain relief does not require Arc Y2 to feel hot. It has no separate active-heating function. Mild warmth can occur, but stop the session if it becomes uncomfortably warm.

Q25. Can I use it as a back massage belt?

A: Yes. Use Arc Y2 as a back massage belt to relax tight muscles after work. This red light therapy belt with vibration offers gentle pulses (A1), quick pulses (A2), gradually rising output (A3), and a combination (A4). Set the vibration strength separately with B1–B3.

Frequently Asked Questions

Choosing a Session That Suits You

Q26. Which setting is best when I want a gentle relief session?

A: Begin with L1, A0 or A1, and low or medium vibration intensity for 10–15 minutes. Gentle contact and a comfortable setting matter more than using maximum brightness or strength on a sore area.

Q27. Can I use red light for back pain relief without vibration?

A: Yes. Select A0 for light-only use. This lets you enjoy red light for back pain relief during a reading or desk break without the vibration sensation; adjust the light setting separately.

Q28. What can I try for stronger massage after a demanding day?

A: The original guide suggests L3 with A3 and B2 after prolonged sitting or standing, if comfortable. After activity, C2 or C3 with A2 or A4 is another starting option. B3 provides the strongest vibration.

Q29. How long and how often should I use the belt?

A: For lower-back or hip comfort, a typical session is 15–20 minutes; start shorter on a new area. Begin 3–5 times per week, increasing up to once daily if comfortable. Keep sessions within 30 minutes.

Q30. Why does the vibration strength show B2, or look like 82?

A: B2 is the default medium vibration intensity. On the segmented display, B can resemble 8. Press and hold the Vibration button to select B1, B2, or B3; this changes strength without changing the A1–A4 timing pattern.

Frequently Asked Questions

Fitting Relief Into Daily Life

Q31. Can I wear this red light therapy back wrap over clothing?

A: Yes. Thin, dry clothing may be used if preferred. Position the red light therapy back wrap securely, with the LED side facing the body and the controller outward. Avoid thick folds that prevent comfortable, even contact.

Q32. Can I wear it during light activities around the house?

A: The cordless, wearable design lets you fit a session into a light household routine or seated break. Keep the belt comfortable and dry, avoid bending or crushing the LED area, and keep the controller within reach.

Q33. Can I fit a session into a short work break?

A: Yes. The initial timer is 15 minutes; short presses cycle through 20, 30, and 10 minutes. Choose a short break that suits your schedule. The belt switches off automatically when the selected time ends.

Q34. Can I reposition it when another area feels sore?

A: Yes. Switch off before moving the belt from the lower back to another suitable area, then adjust the fit and use that area's settings. Keep the session within the original 30-minute maximum rather than extending it by restarting.

Q35. How soon should I expect to feel more comfortable?

A: Try a comfortable session on the area that feels sore or tight and notice how it feels during and afterward. Relief varies between users and sessions; keep a regular, comfortable routine instead of increasing settings to chase an immediate result.

Frequently Asked Questions

Essential Controls and Power

Q36. How do I turn it on and choose steady or pulsed light?

A: Hold Power/Timer for about one second. The Light button cycles L1, L2, L3, C2, and C3. L1–L3 increase steady-light brightness; C2 provides 10 Hz pulses and C3 provides 40 Hz pulses.

Q37. How are vibration pattern and intensity adjusted separately?

A: Short-press Vibration to cycle A1, A2, A3, A4, and A0. Press and hold it to select B1 low, B2 medium, or B3 high. A0 switches vibration off for light-only use.

Q38. Can I wear it while sleeping?

A: No. Use Arc Y2 during an awake rest break, with the controller within reach. Do not use it while sleeping, unconscious, or unable to operate it safely, even though the timer switches the belt off automatically.

Q39. How long can the rechargeable red light therapy belt run?

A: A full charge provides approximately 2–3 hours of use, depending on the light and vibration settings. Charge the rechargeable red light therapy belt only while it is switched off and dry; disconnect the cable before operating it.

Q40. What if it will not turn on or charge?

A: Switch it off and check that the charging port, connector, and cable are dry and undamaged. Charge securely, then disconnect the cable and hold Power/Timer for about one second. If the problem continues, contact support.

Frequently Asked Questions

Care and Support

Q41. Why do some LEDs look dim during my session?

A: 850nm near-infrared light is less visible than 660nm red light, so some LEDs can look dim or almost invisible. If an entire area stays dark, flickers, or behaves unexpectedly, stop use and contact support.

Q42. How do I clean the lining after a session?

A: Switch off, disconnect the cable, and let the belt cool. Gently wipe with a soft, dry cloth or a lightly dampened cloth if needed, then dry completely. Do not wash, soak, bleach, dry-clean, or machine-dry it.

Q43. How should I store it between relief sessions?

A: Store the clean, dry belt in a cool place away from sunlight, heat sources, and heavy objects. Avoid sharp folds and pressure on the LED area, controller, or removable stays. Check that it is dry before charging again.

Q44. What warranty and after-sales help can I receive?

A: Warranty coverage and duration follow the terms associated with your purchase and marketplace. Keep your order number and product-label information. Contact rePretty if an operating problem develops; do not attempt to repair or modify the belt yourself.

Q45. How do I contact rePretty about fit, use, or a problem?

A: Email support@re-pretty.com or visit re-pretty.com for product and after-sales help. Include your Amazon order number, product-label information, a description of the issue, and clear photos or a short video when available.

Frequently Asked Questions

Travel and Everyday Scenarios

Q46. Is Arc Y2 a good fit for business trips?

A: Yes. Arc Y2's built-in 5,000 mAh (18.5 Wh) lithium battery is below the standard 100 Wh limit for U.S. flights. Switch the belt fully off and pack it in your carry-on. After a flight or a long day of meetings, use this portable red light therapy belt in your hotel room to relax tight lower-back muscles.

Q47. Can I use it in a hotel room?

A: Yes. Unplug the charging cable and settle into a chair. The cordless red light therapy belt runs on its built-in battery, so you can sit wherever you're comfortable. If you're sharing the room, choose A0 for a light-only session.

Q48. Can I use it on sore legs after sightseeing?

A: Yes. Place the red light therapy wrap over a sore thigh or calf after a long day of sightseeing. Keep the LED panel flat and use the settings in the leg guide. Switch it off before moving it to another area.

Q49. Can it help after carrying my toddler?

A: Use the red light back wrap for lower back pain relief after carrying a toddler or lifting a stroller. Center the LEDs over the sore area during a seated break. Remove the stays for a softer fit and add gentle vibration if your muscles feel tight.

Q50. Can I use it after a round of golf?

A: Yes. Center the LEDs over your sore lower back after a round of golf and follow the lower-back guide. The removable stays give you firmer lower back support while standing. Take them out for a softer fit when you sit down to rest.