Simulation Techniques for 5G Transmission

Wen-Rong Wu


Institute of Communication Engineering
National Chiao Tung University
Hsinchu, Taiwan
2019/04/05

Content


- 1. Introduction to 5G
- 2. Introduction to OFDM
- 3. F-OFDM and W-OFDM
- 4. Mini-meter wave communication

Introduction to 5G

 Wireless communication has experienced a rapid growth and evolution since 1980s (1G, ...4G, or now 5G).



Evolution:




5

■ What is 5G?

 5G is the fifth generation technology, and it has many advanced features potential enough to change our life dramatically.

Targets:




https://5g-ppp.eu/#

- Features:
 - High increased peak bit rate
 - Larger data volume per unit area
 - High capacity
 - Lower battery consumption
 - Better connectivity irrespective of the geographic region
 - Larger number of supporting devices
 - Lower cost of infrastructural development
 - Higher reliability of the communications
- How to increase the capacity by 1000 times?


- Better spectral efficiency (4):
 - Spectral efficiency: 30 bps/Hz →?
 - Key enabling technology, MIMO, ...
- Larger spectrum (5):
 - Carrier bandwidth Increase: 100MHz →500MHz/1GHz
 - Spectrum availability?
 - Higher band: millimeter wave (mmWave)
 - Spectrum sharing
 - Unlicensed bands
- More cells, network densification (50):
 - Greatly reduce the coverage of a cell, i.e., dramatically increase the cell number
 - Key enabling technology, ultra-dense small cells

- Technology challenges:
 - Authorized shared access
 - Unlicensed bands
 - mmWave
 - Massive MIMO
 - Phase antenna array
 - Beam-forming and beam-tracking
 - Small cell
 - Interference management
 - Full duplex radios
 - SDN and NFV
 - **-** ...

- ITU has defined three usage scenarios in 5G
 - Enhanced mobile broadband
 - Massive machine type communications
 - Ultra-reliable and low latency communications
- Key features:




■ Three scenarios:




11

3GPP RAN workshop on 5G (9/18/2015):




Introduction to OFDM

- OFDM can also be defined with the framework of frequency-division-multiplexing (FDM).
- FDM: Split a high-rate data-stream into a number of lower rate streams transmitted simultaneously over a number of carriers.




- Since the symbol duration increases for low rate carriers, the channel dispersion is decreased.
- Drawback: Guard bands make this approach inefficient.

Remedy: use overlapping sub-channels.




It is possible to arrange carriers such that there is no interference between them. To do that the carriers must be mathematically orthogonal.



15

- Note that a necessary and sufficient condition for this requirement is that all carriers must has a same period.
- Time domain waveform:




 $\int_{-\infty}^{\infty} \varphi_n(t) \varphi_i^{*}(t) dt = \begin{cases} 1, & n = I \\ 0, & n \neq I \end{cases}$

Consider the sampled Φ(t).

$$\Phi_{k}(n) = e^{jk\Omega_{0}n}, \qquad \Omega_{0} = \frac{2\pi}{N}, \quad k = 0, 1, \dots, N - 1$$

$$\frac{1}{N} \sum_{n=0}^{N-1} e^{j(k-m)\Omega_{0}n} = \begin{cases} 1, & k = m \\ 0, & k \neq m \end{cases}$$


The complex exponential exhibit an impulse in the DFT domain.



Thus, we can conduct processing in the frequency domain using DFTs.


17

The main idea is to use conduct modulation in the frequency domain.




■ In other words, we define QAM symbols in the frequency domain

- To eliminate ISI completely, a guard time is introduced for each symbol. Since the guard time has no signal, the problem of intercarrier interference (ICI) arises.
- ISI and guard interval:




* Continuous transmission




19


■ ICI:



- The selected delayed version in the OFDM symbol is not a sinusoidal signal anymore.
- To solve the problem, cyclic prefix is added in the guard period.

Cyclic prefix:






Since the CP is added, the channel output will be a circular convolution of the channel response and the transmit signal. We then have


$$y'''(n) = x'''(n) \otimes h(n) \Rightarrow \tilde{x}'''(e^{j\omega_k}) = \frac{\tilde{y}'''(e^{j\omega_k})}{\tilde{h}(e^{j\omega_k})}$$
 * In the DFT domain

- Thus, data in each channel can be recovered using a single-tap FEQ. (Trequency domain equatizer)
- The system using this modulation technique is called orthogonal frequency division multiplexing (OFDM).

21

• Frequency domain response:





- Let the bandwidth for an OFDM system be f_s , the DFT size be N, and the CP size be μN where $0<\mu<1$.
- Let the sampling frequency of an OFDM be f_s . Then, the period will be $T=1/f_s$. Then, the subcarrier spacing (f_{ss}) will be $1/NT = f_b/N$.
- Let the number of subcarriers for data transmission be M. $(M \le N)$. The occupied bandwidth (f_b) is then Mf_s/N .
- The data rate (r) will be $QM/(1+\mu)NT=Qf_sM/(1+\mu)N$ where Q is the number of bits each QAM transmit.
- LTE system:
 - f_s =30.72MHz, N=2048, M=1200, μ =1/8.
 - $-f_{ss}$ =30.72MHz/2048=15KHz, f_b =1200x15KHz =18MHz (20MHz).
 - For QPSK, r=2x30.72MHzx1200/(1.125x2048)=32Mbps

23

Specifications of LTE:

Channel Bandwidth (MHz)	1.25	2.5	5	10	15	20
Frame Duration (ms)	10					
Subframe Duration (ms)	1					
Sub-carrier Spacing (kHz)	15					
Sampling Frequency (MHz)	1.92	3.84	7.68	15.36	23.04	30.72
FFT Size	128	256	512	1024	1536	2048
Occupied Sub-carriers (inc. DC sub-carrier)	76	151	301	601	901	1201
Guard Sub-carriers	52	105	211	423	635	847
Number of Resource Blocks	6	12	25	50	75	100
Occupied Channel Bandwidth (MHz)	1.140	2.265	4.515	9.015	13.515	18.015
DL Bandwidth Efficiency	77.1%	90%	90%	90%	90%	90%
OFDM Symbols/Subframe	7/6 (short/long CP)					
CP Length (Short CP) (µs)	5.2 (first symbol) / 4.69 (six following symbols)					
CP Length (Long CP) (µs)	16.67					

Practice:

- Build an OFDM system with LTE specifications including
- Transmitter
- AWGN channel, and
- Receiver (perfect synchronization).
- Plot SER vs. SNR.
- * Note: SNR in time domain is different from that seen in each subcarrier
- Assume QPSK symbols
- FFT size=2048 (number of used subcarriers=1200)


Homework:

- Redo the practice with a multipath channel.

25




Result:



F-OFDM and W-OFDM

- Problems with CP-OFDM system:
 - Out of band (OOB) power leakage (10% guard band needed)
 - Rigorous requirement of synchronization
 - Same waveform parameters, i.e., the subcarrier spacing,
 CP length and TTI length for entire bandwidth
- Filtered-OFDM (F-OFDM)
 - Applying subband filtering on traditional CP-OFDM
 - The system bandwidth is divided into sub-bands and filtered independently.
 - Each sub-band can be configured with different waveform parameters set according to the actual traffic scenario.
 - Each subband combined 5G waveforms would supports dynamic soft configurations for traffic types.


Architecture:



29


30

Comparison:




Key features

- Subband filter is added on top of CP-OFDM, without any change on existing CP-OFDM (co-existence of waveform with different OFDM primitive)
- Filtering for each subband (subband BW >= 1 RB)
- Independent subcarrier spacing/ CP length/ TTI configuration for each subband
- Low guard band overhead between neighboring subband
- Support asynchronous inter-band transmission due to good OOB performance




OOB performance:



33

• Filter design:


- Soft truncated filter with specific window is recommended.
- Trade-off between time and frequency localization (that is ISI and ICI)
- Easy implementation for flexible subband configuration
- Small round-up error due to frequency domain fixed point implementation




Example of filter

120/15 = 48 subcamers

- Example with Hanning window
 - Subcarrier spacing = 15KHz
 - Subband = 720KHz
 - Fs = 30.72MHz (LTE baseband sampling rate)






Implementation:

- Filtering is continuously operated in time domain
- However, frequency domain filtering operation is preferred for implementation.

Overlap-Save Method




- Another proposal to achieve low OOB interference is weighted OFDM (W-OFDM):
 - Extend prefix and postfix.
 - Weighted extended signal, and
 - Add resultant OFDM symbols.
- Comparison:

CP	Symbol N-1	CP	Symbol N	СР	Symbol N+1	
			CP-OFDM			-
CP	Symbol N-1	СР	Symbol N	СР	Symbol N+1	
			f-OFDM		-, be- , - 7	-
CP	Symbol N-1	CP	SymbolN	/ CP	Symbol N+1	Market
THE RESIDENCE OF			w-OFDM			T

37

Spectrum property:



■ Practice:

- Use the OFDM system built (LTE), and let the subband occupies 350 subcarriers. (350 x 15K/ $_2$ = 2.625MH $_2$)
- Let the filter size be 512.

(2.7)

32


- Design a filter for the F-OFDM system with the Hann,
 Blackman, or Chebychev windows.
- Plot the power spectrum of OFDM and F-OFDM systems.
- Try different filter length and see the effect.
- Try different window size for power spectrum calculation.

· Homework: (tilter)

Apply the windows to evaluate the SER of the F-OFDM systems.

39

■ Result:






Mini-meter wave communication

41

- Why mmWave?
 - Crowded spectrum at sub 6 GHz
 - Increasing demand on data rate
 - Huge amount of spectrum possibly available in mmWave bands: 30 GHz ~ 300 GHz




Communication with mmWave has been used in some applications.

Personal/local area networks:


Standard	Band	Bandwidth	Rates (Glops)	Application
WirelessHD	60 GHz	2.16 GHz	3.807	HD Video S.
IEEE 802.11ad		2.16 GHz	6.76	WLAN

■ Collision avoidance:



■ In 5G cellular:

- Network



Usage model:





Fig. 3. Millimeter-wave cellular use cases. (a) Outdoor coverage in a campus-like environment, as illustrated in [65]. (b) Urban microcells or picocells as illustrated in a figure detail from [66] showing mmW access points (blue and pink crosses) placed on every block on an urban grid to serve mobiles (green circles) on the streets.



Micrometer vs. milimeter:

	Sub 6 GHz	mmWave	
Bandwidth	<160 MHz	100 MHz – 2 GHz	
Role of antennas	multiplexing & diversity	array gain & multiplexing	
Exploiting channel	limited feedback	directional beamforming	
Antennas @ BS	1 to 8	32 to 256	
Antennas @ UE	1 to 2	1 to 32	
Scattering	Rich	Sparse	
Urban coverage	Via diffraction	Via reflection	
Penetration loss	Low	High	
Large-scale fading	Distant dependent + shadowing	Distant dependent + blockage	

- Propagation channels in mmWave:
 - Distant-based path loss: Friis' law

$$P_r = G_r G_t \left(\frac{\lambda}{4\pi d}\right)^2 P_t$$

- The received power is proportional to the square of wavelength ☺
- The gain provided by antenna array is proportional to the inverse of the square of wavelength ☺

$$G_r, G_r \propto \lambda^{-2}$$

- Since more antenna elements can be fit into the same area
- Array gains more than compensates for the increased pathloss
- In this manner, directional transmission with antenna array is required, explaining how MIMO is a defining characteristic of mmWave


- In general, the pathloss depends on the particular position of objects that can attenuate, diffract and reflect signals
- The most common statistical model describes the average path loss (not including small-scale fading):

$$PL(d)[dB] = \alpha + 10\beta \log_{10}(d) + \xi$$

 $\xi \sim N(0, \sigma^2)$: lognormal term for shadowing

Blockage and outage:

Significance of blockage



49

Loss:

- Brick: 40~80 dB
- Foliage loss can also significant
- Human body (depends on material of the clothing): 20~35
 dB
- Diffraction is not significant → NLOS path is via reflection
- Three-state model: LOS, NLOS and outage
 - The probability of a link being in each state is a function of distance
 - Similar in form to some LOS-NLOS probabilities used in 3GPP LOS-NLOS for heterogeneous networks
- Shall characterizing the joint probabilities in outage between links from different cells
- Path can rapidly appear and disappear, with significant impact on channel tracking



- The paths arrive in "clusters" and each cluster has some distribution on the delay, power, and central (AOA, AOD)
- Detailed channel models have been built for different purposes.
- Since the signal attenuation is severe in mmWave environments, antenna array become a must either for transmitter as well as receiver.

- There are a number of ways to use the multiple transmit/ receive antennas.
 - Beamforming
 - Spatial multiplexing
 - Space-time coding
- Beamforming (spatial filtering) is a signal processing technique used in antenna arrays for directional signal transmission or reception.
- This is achieved by combining elements in a array in such a way that signals at particular angles experience constructive while others experience destructive interference.

Hardware constraints: cost and power consumption of mmWave components are high.

Device	Number of devices	Power (mW) (single device)
PA	$N_t(N_r)$	40-250
LNA	$N_t (N_r)$	4-86
Phase shifter	$N_t(N_r) \times L_t(L_r)$	15-110
ADC	$L_t(L_r)$	15-795
VCO	$L_t(L_r)$	4-25


 $-N_t(N_r)$: number of transmit antennas (receive antennas)

antenna need one ADC

 $-L_t(L_r)$: number of RF chains at transmitter (receiver)




- Digital array:
 - All weights are digital
- Analog array:
 - All weights are analog (may be phase only).
- Hybrid array:
 - Some weights are digital and some are analog.
- Analog beamforming:




Hybrid beamforming:

- Combined analog and digital beamforming
- Make compromise on power consumption and hardware complexity
- Enables spatial multiplexing and multiuser MIMO
- Digital can correct for analog limitations
 - Different RF precoding/combining can be implemented using different analog approaches




55

Architectures:



Beamformer as spatial filter :

Linear array beamformer



57

Now, consider a sinusoidal input:

$$\Delta_r = \frac{L_r}{N_r}$$

$$u_{k}(t) = e^{j2\pi f_{c}(t+\Delta t)} \rightarrow e^{j2\pi f_{c}\Delta t} = e^{jk\theta_{0}}$$

$$k\theta_{0} = 2\pi k f_{c}\Delta t = \frac{2\pi k f_{c}\lambda_{c}\Delta_{r}}{c} = 2\pi k \Delta_{r} \cos(\phi_{0})$$


$$= 2\pi k \Delta_{r} \cos(\phi_{0})$$

$$= 2\pi k \Delta_{r} \cos(\phi_{0})$$

$$= 2\pi k \Delta_{r} \cos(\phi_{0})$$


* θ_0 is the phase delay (related to direction of arrival ϕ_0)


The array output can be seen as the output of a spatial filter.





* Definitions of Ω and θ are different from previous ones.

Beam pattern:









59

Practice:


- Consider digital receive beamforming for a uniform linear array (ULA).
- Plot its beam pattern. (for a given W contesponding to a specific AOA)
- Try different antenna spacing and different number of antennas.

Homework:

- Consider a system with two users; one is desired and the other is interfering (assume Gaussian signal).
- Their signals arrive BS with different AOAs.
- BS is equipped with a hybrid array (one ADC).
- Design a beamformer to best recover the desired signal (highest SINR).

(0 (09(0 (04WHQ1))

■ Result:



Given W if we let $\alpha(k) = [1, e^{ik\alpha}, ..., e^{ik(m-i)\alpha}]^T$ where k = 0, ..., |k-1| and $\alpha = \frac{2\pi i}{k}$, then $\frac{2}{k}$ is called the beam pattern of the away.