





A16	ABS control module
B138	Accelerator pedal position (APP) sensor
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
M131	Brake servo vacuum pump
K279	Brake servo vacuum pump relay
B223	Brake system vacuum sensor
Y182	Camshaft position (CMP) actuator
B132	Camshaft position (CMP) sensor
R99	Clutch position potentiometer
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A130	Diagnostic module
A35	Engine control module (ECM)
A35	Engine control module (ECM) Engine coolant blower motor control module
B24-I	Engine coolant temperature (ECT) sensor 1
B24-II	Engine coolant temperature (ECT) sensor 2
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
Y151	Exhaust gas recirculation (EGR) valve actuator
B149	Exhaust gas recirculation (EGR) valve position sensor
B131	Exhaust gas temperature sensor
B3	Fuel gauge tank sensor
Y63	Fuel pressure regulator control solenoid
M12	Fuel pump (FP)
A107	Fuel pump control module
B186	Fuel rail pressure (FRP) sensor
B26	Fuel system pressure sensor
F	Fuse
X28-I	Fuse box/relay plate, engine bay 1
X28-IV	Fuse box/relay plate, engine bay 2
X28-II	Fuse box/relay plate, fascia 1
B72	Heated oxygen sensor (HO2S)
A91	Heater function control module
A52-I	Ignition amplifier 1
A52-II	Ignition amplifier 2
A52-III	Ignition amplifier 3
A52-IV	Ignition amplifier 4
T1	Ignition coil
K79-I	Ignition main circuits relay 1
K79-II	Ignition main circuits relay 2
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25-I	Intake air temperature (IAT) sensor 1
B25-II	Intake air temperature (IAT) sensor 2
B155	Intake manifold air control actuator position sensor
	· ·

Y102	Intake manifold air control solenoid
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
A11-I	Multifunction control module 1
B202	Nitrogen oxide (NOx) sensor
A217	Nitrogen oxide (NOx) sensor control module
A236	Steering column function control module
P7	Tachometer
A177	Throttle control unit
M89	Throttle motor
B169	Throttle motor position sensor
P9	Vehicle speedometer

