## 7. NETWORK ERROR CODE

## 7.1 Display procedure

- It displays the error code when a network error occurred.
  Network error code is displayed only when the following setting is in "Display."
  [Administrator Settings] -> [Network Settings] -> [Detail Settings] -> [Error Code Display Setting]

## 7.2 IEEE802.1X

Code	Description
1	Connection has already been established.
2	Parameter error.
3	Unable to find the destination AP (SSID).
4	The authentication mode does not match the AP (IEEE802.1X/WPA-EAP/WPA-PSK/NONE).
5	Negotiation of the EAP method falled.
6	The EAP authentication failed (user ID, password, certificate, etc.)
7	Encryption negotiation with the AP failed (TKIP/CCMP).
8	Failed to retrieve the client certificate.
9	The client certificate has expired.
10	Verification error of the server certificate (EAP-TLS/EAP-TTLS/PEAP).
11	Although the WPA-PSK mode is selected, the Pre-Shared Key is not specified.
12	An authentication error occurred in the WPA-PSK mode (un-matched Pre-Shared Key).
13	The phase 2 method is not specified (PEAP).
14	Negotiation of the phase 2 method failed (PEAP).
15	Response from the server has timed out.
16	Failed to allocate memory.
17	Failed to start the supplicant task.
18	The driver does not work.
19	The server certificate has expired (EAP-TLS/EAP-TTLS/PEAP).
20	CA verification error of the server certificate (EAP-TLS/EAP-TTLS/PEAP).
21	Server ID verification error of the server certificate (EAP-TLS/EAP-TTLS/PEAP).
22	The CA certificate is not specified (EAP-TLS/EAP-TTLS/PEAP).
23	The server ID is not specified (EAP-TLS/EAP-TTLS/PEAP).
24	The setting combination is correct.
25	Connection and authentication are complete.
26	The server certificate does not have the expected usage (EAP-TLS/EAP-TTLS/PEAP).
27	The server certificate has expired (EAP-TLS/EAP-TTLS/PEAP).
28	Access to the server to check for expiration of the server certificate is rejected (EAP-TLS/EAP-TTLS/PEAP).
29	Access to the server to check for expiration of the server certificate has timed out (EAP-TLS/EAP-TTLS/PEAP).
30	Unable to check for expiration because the CRL size that has been retrieved to check for the expiration of the server certificate exceeds the maximum capacity that can be retained (1MB) (EAP-TLS/EAP-TTLS/PEAP).
31	Incorrect format of the server certificate (EAP-TLS/EAP-TTLS/PEAP).
32	Verification of the server certificate is invalid (EAP-TLS/EAP-TTLS/PEAP).
33	Although the environment is configured to use the HDD, it is unable to perform verification because the HDD path has not been specified (EAP-TLS/PEAP).
34	Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20) (EAP-TLS/EAP-TTLS/PEAP).
35	Parameter error of the certificate (EAP-TLS/EAP-TTLS/PEAP).
36	Internal error of the certificate verification (EAP-TLS/EAP-TTLS/PEAP).

## **7.3 LDAP**

Code	Description
1	An invalid operation occurred.
4	The number of search results has exceeded the maximum number of items allowed.
7	The LDAP server does not support SASL.
10	Unable to trace the link although Referral is specified.
32	Cannot find the search route.
49	- Failed to log in to the LDAP server.
80	An unexpected error occurred.
85	The connection has timed out.
86	The supported SASL does not match the LDAP server side.

Code	Description
88	Cancelled by the user.
90	A memory shortage occurred.
91	Unable to connect to the LDAP server.
92	The supported LDAP version does not match the LDAP server side.
128	Failed to resolve the LDAP server name using the DNS server.
129	The certificate of the LDAP server has expired.
130	Mutual authentication using GSS-SPNEGO (Kerberos v5) failed.
131	The search result remains.
2238	The CN field of the LDAP server certificate does not match the server address.
2239	The LDAP server certificate does not have the expected usage for a server.
2240	The LDAP server certificate is not trusted. To trust the certificate, the certificate must be registered to the system.
2241	The LDAP server certificate has expired.
2242	The CA server rejected the connection.
2243	The connection to the server that checks for expiration of the certificate has timed out.
2244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).
2261	The format of the LDAP server certificate is invalid.
2263	<ul> <li>Although the environment is configured to use the HDD, it is unable to perform verification because the HDD path has not been specified.</li> </ul>
2264	Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).
2266	Internal error of the certificate verification.
2267	The device certificate does not exist.
2268	No certificate is sent from the server.
10000	Failed in authentication using a PKI card (PKI token).
12236	The ticket certificate has expired.
12239	The ticket certificate does not have the expected usage for a server.
12240	The ticket certificate is not trusted. To trust the certificate, the certificate must be registered to the system.
12241	The ticket certificate has expired.
12242	The CA server rejected the connection.
12243	The connection to the server that checks for expiration of the certificate has timed out.
12244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).
12261	The format of the ticket certificate is invalid.
12263	<ul> <li>Although the environment is configured to use the HDD, it is unable to perform verification because the HDD path has not been specified.</li> </ul>
12264	<ul> <li>Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).</li> </ul>
12266	Internal error of the certificate verification/management module.

## 7.4 E-Mail/Internet Fax

Code	Description	
1	Failed to log in to the E-mail server.	i i
2	An internal error occurred.	
3 .	Failed to connect to the server.	
4	The connection has timed out.	9
5	Decoding failed due to invalid MIME format or S/MIME format.	
6	Available free memory is insufficient. Reception is not possible.	
9	Failed to delete an E-mail message.	
10	The mail box is full.	- 8
11	Failed to search the certificate.	
12	Failed to retrieve the device certificate or private key.	
13	An I/O error occurred.     An HDD operation error occurred, or memory capacity of the computer may be insufficient.	
14	The S/MIME function is disabled.	
15	The HDD is disabled.	H
16	The format of the certificate from the E-mail sender is invalid.	
2236	The certificate has expired, or the validity period has not yet started.	L 6
2238	The CN field of the certificate does not match the server address.	4

Code	Description
2239	The certificate does not have the expected usage.
2240	The certificate is not trusted. To trust the certificate, the certificate must be registered to the system.
2241	The certificate has expired.
2242	The CA server rejected the connection.
2243	The connection to the server that checks for expiration of the certificate has timed out.
2244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).
2261	The format of the certificate is invalid.
2263	Falled to initialize the certificate verification.
2264	<ul> <li>Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).</li> </ul>
2266	Internal error of the certificate verification.
2267	The device certificate does not exist.
2268	No certificate is sent from the server.

## 7.5 FTP transmission

Code	Description
22	Parameter error (e.g. the file name is NULL).
27	Parameter is invalid.
42	The specified protocol is unavailable.
52	The process is cancelled by a device reset.
55	A buffer shortage occurred.
56	The FTP connection is already open.
57	Failed to connect to the server.
60	The connection has timed out.
61	The connection has been interrupted.
62	The device is not connected to the network.
70	The network connection is busy.
450	The file has not been deleted.
451	The file transfer failed (e.g. due to insufficient server capacity).
452	The file transfer falled (e.g. due to insufficient server capacity).
501	Syntax error in parameters or arguments.
530	Incorrect login name or password.
550	The spedfied folder does not exist.
552	The file operation falled (e.g. due to insufficient server capacity).

## 7.6 SMB transmission

Code	Description
42	The specified protocol is unavailable.
52	The process is cancelled by a device reset.
55	A buffer shortage occurred.
57	Failed to connect to the server.
62	The device is not connected to the network. The connection has been interrupted.
70	The network connection is busy.
4096	The host name is not specified. The specified host name does not exist on the network.
4097	The user name is not specified.  Unable to log in with the specified user name and password.  The user does not have write permission to the folder.  Failed to log in due to an SMB protocol error.
4098	The folder name is not specified. The specified folder does not exist.
4099	The user name is not specified.  Unable to log in with the specified user name and password.  The user does not have write permission to the folder.  Failed to log in due to an SMB protocol error.
4100	The specified file name is invalid.
4101	The specified file already exists and is write-protected.  The folder and the disk are write-protected.
4102	The specified media to be written is not formatted.

Code	Description
	The file system of the specified media to be written is faulty.
4103	The server capacity is full.
4104	The server capacity has become full while writing data.
4105	Other errors to which an error code is not assigned.
10000	Failed in authentication using a PKI card.
12236	The certificate has expired, or the validity period has not yet started.
12239	The certificate does not have the expected usage.
12240	The certificate is not trusted. To trust the certificate, the certificate must be registered to the system.
12241	The certificate has expired.
12242	The CA server rejected the connection.
12243	The connection to the server that checks for expiration of the certificate has timed out.
12244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).
12263	<ul> <li>Although the environment is configured to use the HDD, it is unable to perform verification because the HDD path has not been specified.</li> </ul>
12264	Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).
12266	• Internal error of the certificate verification.
12267	The device certificate does not exist.
12268	No certificate is sent from the server.

#### 7.7 SMTP transmission

Code	Description
22	Invalid argument.
27	The file size is too large.
28	Insufficient memory of the device.
32	The pipe is broken.
42	The specified protocol is unavailable.
51	Unable to reach the destination network.
52	The connection aborted by the network.
55	A buffer shortage occurred.
57	The socket is not connected.
58	The connection has been interrupted.
60	The operation has timed out.
61	The connection is rejected.
62	The device is not connected to the network.
67	The host is shut down.
70	The operation is expected to be blocked.
421	SMTP server error. Since the service is unavailable, the transfer channel is closed.
432	SMTP server error. The password must be changed.
450	SMTP server error. Unable to access to the mail box.
451	SMTP server error. The requested action has been cancelled because an error occurred while processing a job.
452	SMTP server error. Shortage of the system storage capacity.
453	SMTP server error. No E-mail massage.
454	SMTP server error. Temporary authentication failure.
458	SMTP server error. Unable to queue a message to the node.
459	SMTP server error. The node is not permitted.
499	SMTP server error. An unsupported SMTP error code of 400s is received from the SMTP server.
500	SMTP server error. Syntax error (command unrecognized).
501	SMTP server error. Syntax error in parameters or arguments.
502	SMTP server error. The command is not implemented.
503	SMTP server error. Bad sequence of commands.
504	SMTP server error. The command parameter is not implemented.
521	SMTP server error. The server does not receive E-mail messages.
530	SMTP server error. The access is rejected.
534	SMTP server error. The authentication mechanism is too weak.
535	SMTP server error. Authentication error.
538	SMTP server error. The requested authentication mechanism requires encryption.
550	SMTP server error. The requested action is not executed.

Code	Description
551	SMTP server error. The user is not connected locally.
552	SMTP server error. The requested E-mail action is cancelled.
553	SMTP server error. The requested action is not accepted.
554	An SMTP server error, or an internal error when sending data. The transaction failed.
555	SMTP server error. MAIL/RCPT parameter error.
599	SMTP server error. An unsupported SMTP error code of 500s is received from the SMTP server.
2236	The certificate has expired, or the validity period has not yet started.
2238	The CN field of the certificate does not match the server address.
2239	The certificate does not have the expected usage.
2240	The certificate is not trusted. To trust the certificate, the certificate must be registered to the system.
2241	The certificate has expired.
2242	The CA server rejected the connection.
2243	The connection to the server that checks for expiration of the certificate has timed out.
2244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).
2261	The format of the certificate is invalid.
2263	Failed to initialize the certificate verification.
2264	Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).
2266	Internal error of the certificate verification.
2267	The device certificate does not exist.
2268	No certificate is sent from the server.
3000	An unexpected error occurred.
3001	An unexpected error occurred within the library being used.
3002	An invalid channel is specified.
3003	SMTP server address is invalid.
3004	Parameter error (MIMEBodyHeader).
3005	Parameter eπor (DisplayName).
3006	Parameter eπor (character set).
3007	- Parameter епог (From address).
3008	• Parameter error (To address).
3009	Parameter error (CC address).
3010	Parameter error (BCC address).
3011	• Parameter error (pEmailSet is NULL).
3012	Parameter error (destination certificate is NULL).
3013	Parameter error (E-mail body).
3014	The HDD is disabled.
3015	The S/MIME function is disabled.
3016	The device certificate cannot be used in S/MIME (e.g. self-signed certificate error, the private key type is not RSA).
3018	An invalid encryption algorithm is specified.
3019	An invalid signature algorithm is specified.
3020	The E-mail address included in the destination certificate does not match the destination address (To/Cc/Bcc).
3021	The E-mail address included in the certificate does not match the sender (From) address.
3022	Format error of the certificate.
3023	Parameter error (Disposition-Notification-To).
3024	Message syntax error of the receiver side.
3025	The SMTP server does not support the STARTTLS command.
3026	PKI card access error,

# 7.8 WebDAV transmission

Code	Description
22	The format of the URL of the target resource is invalid. Parameter error.
27	Attempted to send data that exceeds the maximum transferrable size for transfer coding.
42	The specified protocol is unavailable.
52	The process is cancelled by a device reset.
55	A buffer shortage occurred.
56	The connection has already been established.

Code	Description
57	The connection to the WebDAV server failed (including connection time out).
62	The device is not connected to the network.
70	The network connection is busy.
72	The connection has been interrupted with the condition that is insufficient to the specified size.
401	Authentication error.
407	Proxy authentication error.
1001	The server does not support WebDAV.  Unable to upload data to the server.
1002	• The intermediate resource is not a collection (directory) (e.g. the specified folder does not exist).
1003	The target resource is a collection (directory).
1011	· Although "https" is specified for the resource URL, it is unavailable because the SSL library is not included for the modularity.
1012	<ul> <li>Although "https" is specified for the resource URL, the connection is interrupted because the WebDAV server certificate has expired.</li> </ul>
1013	The CONNECT method is issued to the proxy server to establish an SSL connection via a proxy, but it is rejected.
1017	A communication error occurred while sending a request.
1018	A communication error occurred while receiving a response.
1027	nContentLength exceeds the maximum transferable size.
1030	Although use of a proxy has been specified, the proxy setting information is unavailable.
1031	The connection to the proxy server failed (including connection time out).
1098	Failed in chunk TX to SharePoint Server.
1099	Other internal error occurred (e.g. memory shortage).
2236	The certificate has expired, or the validity period has not yet started.
2238	The CN field of the certificate does not match the server address.
2239	The certificate does not have the expected usage.
2240	The certificate is not trusted. To trust the certificate, the certificate must be registered to the system.
2241	The certificate has expired.
2242	The CA server rejected the connection.
2243	The connection to the server that checks for expiration of the certificate has timed out.
2244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).
2261	The format of the certificate is invalid.
2263	Failed to initialize the certificate verification.
2264	Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).
2266	Internal error of the certificate verification.
2267	The device certificate does not exist.
2268	No certificate is sent from the server.

## 7.9 SMB browsing

Code	Description				
32	The connection has been interrupted.				
42	The specified protocol is unavailable.				
57	Failed to connect to the server.				
62	The device is not connected to the network. The internal channel detected an error immediately before establishing communication.				
67	The host is shut down.				
4096	The group name/host name is not specified. The specified group name/host name does not exist on the network.				
4097	The user name is not specified.  Unable to log in with the specified user name and password.  Failed to log in due to an SMB protocol error.				
4098	Administrative shares do not exist.     The shared resource name is not specified.     The shared resource does not exist.				
4099	<ul> <li>The user name is not specified.</li> <li>Unable to log in with the specified user name and password.</li> <li>Failed to log in due to an SMB protocol error.</li> </ul>				
4102	The specified media to be written is not formatted. The file system of the specified media to be written is faulty.				
4105	Other errors to which an error code is not assigned.				
4352	The browser machine (master browser/backup browser) is not found.				

Code	Description				
4353	Unable to log in to the browser machine (master browser/backup browser).				
4354	The sub folder does not exist.				
4355	The request is not accepted due to an invalid call sequence etc.				
4368	The number of groups is too large.				
4369	The number of host PCs is too large.				
4370	The number of shared resources is too large.				
10000	Failed in authentication using a PKI card.				
12236	The certificate has expired, or the validity period has not yet started.				
12239	The certificate does not have the expected usage.				
12240	The certificate is not trusted. To trust the certificate, the certificate must be registered to the system.				
12241	The certificate has expired.				
12242	The CA server rejected the connection.				
12243	The connection to the server that checks for expiration of the certificate has timed out.				
12244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).				
12263	<ul> <li>Although the environment is configured to use the HDD, it is unable to perform verification because the HDD path has not been specified.</li> </ul>				
12264	<ul> <li>Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).</li> </ul>				
12266	Internal error of the certificate verification.				
12267	The device certificate does not exist.				
12268	No certificate is sent from the server.				

## 7.10 User authentication

Code	Description			
1	Invalid parameter (e.g. the number of characters exceeds the limit, blank).     The authentication function setting is disabled.			
2	Falled to resolve the name using the DNS server.			
3	Unable to find the authentication server.			
4	Failed to authenticate.			
5	Failed to allocate memory.     An unexpected error occurred (which does not occur under normal usage conditions).			
6	<ul> <li>An authentication request is received while an internal task of the user authentication client is being performed.</li> </ul>			
7	The connection was interrupted while the user authentication was being performed.			
10000	Falled in authentication using a PKI card.			
12236	The certificate has expired, or the validity period has not yet started.			
12239	The certificate does not have the expected usage.			
12240	The certificate is not trusted. To trust the certificate, the certificate must be registered to the system.			
12241	The certificate has expired.			
12242	The CA server rejected the connection.			
12243	The connection to the server that checks for expiration of the certificate has timed out.			
12244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).			
12261	The format of the certificate is invalid.			
12263	<ul> <li>Although the environment is configured to use the HDD, it is unable to perform verification because the HDD path has not been specified.</li> </ul>			
12264	<ul> <li>Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).</li> </ul>			
12266	Internal error of the certificate verification.			

## 7.11 WebDAV client

Code	Description  The ID of the client that is not opened is specified.			
2				
3	The reception has timed out.			
4	A reception error occurred.     An invalid request URL is specified.			
5	<ul> <li>Content-Length or the received data size exceeds the maximum transferable size.</li> <li>The size of the message body is too large.</li> </ul>			
6	The process is cancelled by a device reset. The size of the message body exceeds the maximum transferable size.			
7	An internal error occurred.     The process is cancelled by an internal reset.			

Code	Description					
8	Failed to connect to the WebDAV server.					
9	An error occurred while sending data to the WebDAV server.					
10	A timeout occurred white sending data to the WebDAV server.					
11	Failed to connect to the proxy server.					
12	The proxy server rejected the connection request.					
13	Although use of a proxy has been specified, the proxy setting in-formation is unavailable.					
14	Failed to authenticate the proxy server.					
15	Other error was returned from the proxy server.					
16	An internal error occurred.					
17	The process is cancelled because MIO_REQBODY_ERROR is specified by the device application.					
2236	The certificate has expired, or the validity period has not yet started.					
2238	The CN field of the certificate does not match the server address.					
2239	The certificate does not have the expected usage.					
2240	The certificate is not trusted. To trust the certificate, the certificate must be registered to the system.					
2241	The certificate has expired.					
2242	The CA server rejected the connection.					
2243	The connection to the server that checks for expiration of the certificate has timed out.					
2244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).					
2261	The format of the certificate is invalid.					
2263	Failed to initialize the certificate verification.					
2264	Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).					
2266	Internal error of the certificate verification.					
2267	The device certificate does not exist.					
2268	No certificate is sent from the server.					

## 7.12 WS scan

Code	Description				
1	The specified client is not registered.				
2	Parameter is invalid.				
3	The Web service or WS scan function is disabled.				
4	The device is not connected to the network.				
5	Waiting for connection from CP.				
6	The certificate of the destination computer is not valid when the validity period of a certificate is checked.				
22	• Invalid argument.				
42	The specified protocol is unavailable.				
52	The connection aborted by the network.				
53	The connection has been interrupted.				
55	A buffer shortage occurred.				
57	The socket is not connected.				
60	The operation has timed out.				
70	The operation is expected to be blocked.				
72	The Retrievelmage waiting period has timed out.				
2236	The certificate has expired, or the validity period has not yet started.				
2238	The CN field of the certificate does not match the server address.				
2239	The certificate does not have the expected usage.				
2240	The certificate is not trusted.  To trust the certificate, the certificate must be registered to the system.				
2241	The certificate has expired.				
2242	The CA server rejected the connection.				
2243	The connection to the server that checks for expiration of the certificate has timed out.				
2244	Unable to check for expiration because the CRL size exceeds the maximum capacity that can be retained (1MB).				
2261	The format of the certificate is invalid.				
2263	<ul> <li>Although the environment is configured to use the HDD, it is unable to perform verification because the HDD path has not been specified.</li> </ul>				
2264	<ul> <li>Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).</li> </ul>				
2265	Parameter of the certificate verification is invalid.				

Code	Description
2266	Internal error of the certificate verification.
2267	The device certificate does not exist.
2268	No certificate is sent from the server.

## 7.13 Scan server transmission

Code	Description	
1	The action is not supported.	
2	Parameter is Invalid.	
3	The operation failed.	
4	A temporary error occurred on the scan server.	
5	An internal error occurred on the scan server.	
6	The scan server returned an error due to operation by an unauthorized user.	
7	The scan server returned an error due to invalid request.	
8	Addresses for secondary distribution are not supported.	
9	The destination address is not included in PSP.	
10	The scan server returned an error due to access by an unauthorized user.	
11	The scan server returned an error due to a request for invalid action.	
12	The scan server returned an error due to transmission of unregistered PSP to the scan server.	
13	The scan server returned an error due to a request for invalid action.	
14	The scan server returned an error due to use of a format that is not supported.	
22	Parameter is invalid.	
42	The Web service or WSD-Scan function is invalid.	
52	The connection aborted by the network.	
53	• The connection has been interrupted.	
55	The I/O buffer capacity is in short.	
57	No connection exists with the client.	
62	The connection has been interrupted.	
70	NICFUM is busy.	
2236	The SSL certificate has expired.	
2238	The CN field of the certificate does not match the server address.	
2239	The certificate does not have the expected usage.	
2240	The certificate is not trusted.  The trust the certificate the certificate the certificate.	
2241	To trust the certificate, the certificate must be registered to the system.     The certificate has expired.	
2242	<u>'</u>	
2243	The CA server rejected the connection.  The connection to the connection for the connection of the connection to th	
2244	<ul> <li>The connection to the server that checks for expiration of the certificate has timed out.</li> <li>The size of the expiration list is too large.</li> </ul>	
2261	The size of the expiration list is too large.     The format of the certificate is invalid.	
2263		
2203	<ul> <li>Although the environment is configured to use the HDD, it is unable to perform verification because the HDD path has not been specified.</li> </ul>	
2264	<ul> <li>Unable to perform verification because there are too many certificates to be verified (the maximum number of certificates that can be verified at a time is 20).</li> </ul>	
2265	Parameter of the certificate verification is invalid.	
2266	Internal error of the certificate verification/management module.	
2267	The device certificate does not exist.	
2268	No certificate is sent from the server.	

## 8. FAX TROUBLE CODE

#### The error in the transmission/reception system

- The error in the Txx/Rxx system may be caused under the effect of line noise, etc. even in usual operating condition.
  If the error arises often, output the activity report, fax setting list, protocol trace list, parameter list, address book list, group address list and program list and obtain detailed information on the error status, conditions which may cause the error, etc. from the user and contact the support center.

#### 8.1 B0-\*\*

Code No.	Category	Contents of error	How to correct
B0-01	FAX board error	FAX board error 1 (FAX ROM check sum error)	Pull out and insert the connector of FAX board to check its installation.
B0-02		FAX board error 2 (DPRAM check error)	If the trouble is not yet corrected, hardware of the FAX board may be defective. Replace the FAX board in such a case.
B0-03		FAX board error 3 (FAX initialization NG)	be delective. Replace the PAX board in such a case.
B0-51		FAX board installation error (Line 1).	<ul> <li>Pull out and insert the connector of FAX board to check its installation.</li> <li>If the trouble is not yet corrected, check if the fax (main) is set to [Unset] on the [System 2] -&gt; [Option board Status] screen in the service mode.</li> <li>If it is set to [Unset], set to [Set].</li> </ul>
B0-52		FAX board installation error (Line 2).	<ul> <li>Puil out and insert the connector of FAX board to check its installation.</li> <li>If the trouble is not yet corrected, check if the fax (Sub) is set to [Unset] on the [System 2] -&gt; [Option board Status] screen in the service mode.</li> <li>If it is set to [Unset], set to [Set].</li> </ul>

#### 8.2 B1-1\*

Code No.	Category	Contents of error	How to correct
B1-10	FAX driver error	Instance generation error or observer registration error	Turn OFF/ON the main power switch.
B1-11		Configuration space initialization NG	
B1-12		Semaphore acquisition, release error	
B1-13		Sequence error among main body tasks	
B1-14		Message queue control error	
B1-15		Main body - sequence error among FAX boards	Pull out and insert the connector of FAX board to check its installation.
B1-16		FAX board nonresponse (Nonresponse after initialization)	
B1-17		ACK waiting timeout error	
B1-18		Receiving undefined frame	Ty .
B1-19		DMA transfer error	

#### 8.3 B1-2\*

Code No.	Category	Contents of error	How to correct
B1-20	JC	Soft error (FAX board side)	Turn OFF/ON the main power switch.
B1-22		Device error (GA LOCAL SRAM)	Turn OFF/ON the main power switch.
B1-23		Device error (DRAM)	If the trouble is not yet corrected, hardware of the FAX board in be defective. Replace the FAX board in such a case.
B1-25		Device error (GA)	
B1-26		Timeout error due to nonresponse from codec control during suspension process	Turn OFF/ON the main power switch.
B1-27		Timeout error due to nonresponse from communication control during suspension process	
B1-28		Timeout error due to nonresponse from LINE control during suspension process	

#### 8.4 B1-3\*

Code No.	Category	Contents of error	How to correct	01
B1-30	Driver error	Driver soft error	Turn OFF/ON the main power switch.	
B1-31	(FAX board	Reception frame length error from main		
B1-32	side)	Reception frame header error from main		
B1-33		232C i/f sequence error		
B1-34		DPRAM i/f sequence error	:	

Code No.	Category	Contents of error	How to correct
B1-35		DPRAM CTL/STS register error	
B1-36		ACK waiting timeout	
B1-37		DPRAM RESET reception	

## 8.5 B1-4\*

Code No.	Category	Contents of error	How to correct	
B1-40	Soft error (FAX board side)	MSG I/F error with job control	Turn OFF/ON the main power switch.	-
B1-41	Soft error	I/F error with driver		
B1-42	I/F error with main	Undefined command reception		
B1-43		main Command frame length error		
B1-44	]	Command parameter length error		
B1-45	1	Undefined parameter		
B1-46	]	Command/response sequence error		

## 8.6 B1-5\*

Code No.	Category	Contents of error	How to correct
B1-50	Line control	External class instance acquisition error	Tum OFF/ON the main power switch.
B1-51		Job start error (starting job parameter error/child job generation error)	
B1-52		Doc access error (report buf access error)	
B1-53	]	Response wait timeout from external task	
B1-54		Internal que table control error (create/ enque/deque)	

## 8.7 B1-6\*

Code No.	Category	Contents of error	How to correct
B1-60	1 destination	Instance generation error	Turn OFF/ON the main power switch.
B1-61	control	Timeout error	_
B1-62	]	Interface error	
B1-63		Message que control error	
B1-64	1	Semaphore acquisition release error	
B1-65		Observer registration error	
B1-66		Reception resource check error	
B1-67		Deployment error of sending Image Information	
B1-68	1	Serialization error of receiving image	
B1-69	1	Access error to quick memory data	

## 8.8 B1-7\*

Code No.	Category	Contents of error	How to correct
B1-70	Page control	Internal que table control error (create/ enque/deque)	Turn OFF/ON the main power switch.
B1-71	1	Instance generation error	-
B1-72		Timeout error	
B1-73	1	Interface error	
B1-74	1	Semaphore acquisition release error	
B1-75	1	Observer registration error	
B1-76		Unable to secure TTI domain	
B1-77	7	Error return from TTI rasterizer	
B1-78	1	Receiving job generation error	_
B1-79	1	Sequence control error (line specification fault, status mismatch, event mismatch)	

## 8.9 B1-8\*

Code No.	Category	Contents of error	How to correct
B1-80	Page control	Access error to quick sending memory data	Turn OFF/ON the main power switch.
B1-81	1	BlockBuff acquisition error	
B1-82	1	Sending block image error (Req, restore)	
B1-83		Receiving block image error (Req, store)	
B1-84	1	Storage error of receiving image information	
B1-85		Receiving data size logic error (Receiving data are not multiples of dotline)	
B1-86		ImageBuf acquisition (alloc) error	
B1-87		Error return from compressor	
B1-88		BandBuf control error (newInstance/get/ free)	

#### 8.10 B1-9\*

Code No.	Category	Contents of error	How to correct
B1-90	USB	USB IF error (OS notifies an error during configuration setting after recovery from the sleep or attach.)	Turn OFF the main power switch, then check the connection of USB, turn ON the main power switch.
B1-91		USB IF error (EndPoint1: Bulk Out (command, transmitted image data)) (error retry 1 min. timeout)	
B1-92		USB IF error (EndPoint2: Bulk In (response, received image data)) (error retry 5 sec. timeout)	
B1-93		USB IF error (EndPoint3: Interrupt In (fax board status)) (error retry 1 min. timeout)	
B1-94		USB IF error (EndPoint4: Bulk Out (main body status)) (error retry 3 sec. timeout)	
B1-95		USB IF error (Attach not detected for 1 min. after recovery from sleep)	
B1-96	ar.	USB IF error (Detach not detected for 1 min. after recovery from sleep)	

## 8.11 T0\*

Code No.	Category	Contents of error	How to correct	
T00	Sending	T1 timeout. no response obtained from the machine on the other end of the line. (35 second)	Check that the address number is correct.	
T01		T1 over after the mode has been changed (35 seconds)	-	
T02		DCN reception in DIS waiting	The remote station may not receive the data due to paper shortage, full memory, etc.	
T03	j	Unexpected command reception in DIS waiting	-	
T04	Not used			
T05	Sending	FIF not matching with the remote station (remote station without the function).	-	
T06	Ţ	DCN reception in CFR/FTT waiting	-	
T07	Not used			
T08	Sending	Training failure at 2400 bps	The line may be in trouble. Check the line noise.	
T09		No response to DCS	The line may be disabled because the user on the remote station disconnected it.	

## 8.12 T1\*

Code No.	Category	Contents of error	How to correct
T10	Not used		
T11	Sending	DCN reception while waiting for post message responses	The remote station may not receive the data due to paper shortage, full memory, etc.
T12		Unexpected command reception while waiting for post message responses	-

Code No.	Category	Contents of error	How to correct
T13		No response while waiting for post message responses	The remote station may not receive the data due to paper shortage, full memory, etc.
T14	Not used		
T15	Not used		
T16	Not used		
T17	Not used		
T18	Sending	No reception ability in a remote station	The remote station may not receive the data due to paper shortage, full memory, etc.
T19	Not used		

## 8.13 T2\*

Code No.	Category	Contents of error	How to correct		
T20	Not used				
T21	Not used				
T22	Not used				
T23	Not used				
T24	Not used				
T25	Not used				
T26	Not used				
T27	Not used				
T28	ECM sending Timeout by RR/RNR (60 seconds) -				
T29	Not used				

## 8.14 T3\*

Code No.	Category	Contents of error	How to correct
T30	Not used		
T31	Not used		
T32	ECM sending	Fall back over by CTC	The line may be in trouble. Check the line noise.
T33	Not used		
T34	Not used		
T35	ECM	No responses to RR	-
T36	transmission	DCN reception to RR	-
T37	Not used		
T38	F code polling TX	SID is received when SEP is received	-
T39	Not used		

## 8.15 T4\*

Code No.	Category	Contents of error	How to correct
T40	Calling	Software error at calling	-
T41	Not used		
T42	Sending	RTN/PIN reception	-
T43		Three continuous CRP signal reception	-
T44	1	Time error between frames at transmission	-
T45	Not used		
T46	Not used		
T47	Not used		
T48	Check Destination	Line disconnected due to no match as a result of CSI check.	Telephone number may not be set on the remote station. Check the CSI signal of the remote station in the protocol trace list.
T49	Not used		a see provide a see most

## 8.16 T5\*

Code No.	Category	Contents of error	How to correct	
T50	FAX-CSRC	Host terminal ID inconsistency	-	
T51	Not used	· · · · · · · · · · · · · · · · · · ·		
T52	Not used			
T53	Not used			

Code No.	Category	Contents of error	How to correct
T54	Not used		
T55	Not used		
T56	Not used		
T57	Not used		
T58	Polling reception	Calling by polling reception, but a remote station does not have polling transmission documents	Polling original may not be set on the remote station.
T59	Not used		

## 8.17 T6\*

Code No.	Category	Contents of error	How to correct
T60	Polling transmission	Received the polling transmission request (DTC), but there are no polling transmission documents	Polling original may not be set on your machine. Polling TX is enabled only when the polling transmission original is registered.
T61	F-code polling transmission	Unsatisfactory conditions for receive polling TX request.	Bulletin board original may not be set. Bulletin board TX is enabled only when the bulletin board transmission original is registered.
T62	F-code polling transmission	Box number specified by SEP is not valid.	Bulletin board box number from the remote station may be incorrect.
T63	Not used		
T64	Not used		
T65	Not used		
T66	Not used		
T67	Not used		
T68	Not used		
T69	Not used		

## 8.18 T7\*

0.10 17						
Code No.	Category	Contents of error	How to correct			
T70	Not used	Not used				
T71	Not used	Not used				
T72	Not used					
T73	Transmission	Modem response waiting T.0 (60 seconds)				
T74	V34	No changes in the V34 modem status	Ç-			
T75		V34 signal sending error	-			
T76		CS2 is not turned to ON	-			
<b>T77</b>	Not used					
T78	Transmission	Codec control soft ware error	-			
T79	7.	Job control soft error at transmission	-			

## 8.19 T8\*

Code No.	Category	Contents of error	How to correct
T80	Call control	LOOP current detection NG when CML is turned ON at calling	The line may not be connected. Check the line connection status.
T81		Dial Tone detection NG when CML is turned ON at calling	
T82		Answer tone (CED/DIS) waiting timeout after dialing at calling	-
T83		Busy tone detection at calling	
T84		Line control dial error	-
T85		Short disconnection was detected after LOOP current detection at calling	-
T86	1	Dial tone continues after dialing	
T87	Not used		
T88	Not used		
T89	Control unit	When the control unit is connected, a communication error is caused due to capacity shortage and communication is finished.	

## 8.20 T9\*

Code No.	Category	Contents of error	How to correct
T90	Not used		
T91	Not used		
T92	Not used		
T93	Not used		<del></del>
T94	Not used		
T95	Call control	When called, short disconnection of LOOP current was detected during a call	-
T96	Not used		
T97	Transfer	Transmission request was received with no FAX board installed. *	-
T98		Transmission request of images that cannot be transmitted were received. (Color images) *	-
T99	Call control	Remote stations number is deleted while walting for abbreviated or one-touch redialing (redial / transmission / polling reception) *	-

<sup>• \*:</sup> The corresponding error code is not displayed on the control panel even if the error occurs.

## 8.21 R0\*

Code No.	Category	Contents of error	How to correct
R00	Reception	DCS was not received within 35 seconds (T1 over)	The dialed telephone number may be incorrect.
R01	]	T1 timeout after EOM sending	-
R02		DCN reception in DCS waiting	The line may be disabled because the user on the remote station disconnected it.
R03		Unexpected command reception in DCS waiting	-
R04	]	FIF error of DCS	-
R05	Not used		
R06	Not used		
R07	Reception	Image information does not come in image information waiting	The line may be disabled because the user on the remote station disconnected it.
R08		CD OFF while receiving image information	
R09	]	DCN reception in post message waiting	1

## 8.22 R1\*

Code No.	Category	Contents of error	How to correct
R10	Reception	Unexpected command reception in post message waiting	-
R11		Command was not received which walting for post message	The line may be disabled because the user on the remote station disconnected it.
R12		Timeout during EOL-EOL	-
R13	Not used	<u> </u>	
R14	Not used		
R15	Not used		<del></del>
R16	Not used		
R17	Not used	<del></del> -	
R18	Reception	Resource check error (line disconnected due to ongoing communication)	Space in the hard disk may become short. Unnecessary data should be deleted to secure the space in the hard disk.
R19	Not used		<u> </u>

## 8.23 R2\*

Code No.	Category	Contents of error	How to correct
R20	Reception	Line disconnection by receive reject function	Call was received from a user who is in the register of addresses to be rejected.
R21	CUG reception	No match of password in the closed network RX setting	Check the password.

Code No.	Category	Contents of error	How to correct
R22		No password received in the closed network RX setting	Check the setting of closed network RX.
R23	Not used		
R24	ECM	RR-RNR repeats for 2 minutes	(-
R25	reception	Command was not received white waiting for responses to RNR	-
R26		Unexpected command was received while waiting for responses to RNR	
R27		DCN reception while waiting for responses to RNR	-
R28		The counter is abnormal of the post messages received (PC/BC).	-
R29		Timeout (35 seconds) between frames occurred	-

## 8.24 R3\*

Code No.	Category	Contents of error	How to correct
R30	Not used		
R31	Not used		
R32	Reception	Line disconnected because there is no appropriate confidential user box while automatic user box generation is inhibited.	Confidential box No. received from the remote station may be incorrect.
R33	1	DIS reception to DTC (German specifications only)	-
R34	F code confidential reception	PWD was received when SUB was received.	-
R35	Not used		
R36	Not used		
R37	V34	CS2 is not turned to ON.	1-
R38		No change in V34 modem and status	-
R39	Not used		

#### 8.25 R4\*

Code No.	Category	Contents of error	How to correct
R40	When called	Soft error when called	-
R41	Not used		
R42	Not used		
R43	Not used		
R44	Not used		
R45	Reception	Phase C timeout (NonECM reception only)	
R46	Not used	2	
R47	Not used		
R48	Not used		
R49	Reception	DCN reception while waiting for image information	The line may be disabled because the user on the remote station disconnected it.

## 8.26 R5\*

Code No.	Category	Contents of error	How to correct
R50	Reception	No. of error lines exceeds.	The line may be in trouble. Check the line noise.
R51	Not used		
R52	Not used		
R53	Not used		
R54	Not used		
R55	Not used		
R56	Not used		
R57	Not used		
R58	Not used		

Code No.	Category	Contents of error	How to correct
R59	Not used		

## 8.27 R6\*

Code No.	Category	Contents of error	How to correct
R60	Reception	Reception image error (RTN/PIN sending)	The line may be in trouble. Check the line noise.
R61	Not used		
R62	Not used		
R63	Reception	Three continuous CRP signal reception	
R64	Not used		
R65	Not used		
R66	SEP polling	SEP polling transmission request was received without SEP polling transmission ability	-
R67	SUB reception	SUB was directed without SUB reception ability	-
R68	Not used		
R69	ECM reception	Communications are cut when EOR is received.	The line may be in trouble. Check the line noise.

#### 8.28 R7\*

Code No.	Category	Contents of error	How to correct
R70	ECM reception	Decode error occurred in ECM	-
R71	Reception	RTC detection error (No. of EOL is smaller than FP.)	-
R72		Long original larger than the allowable value is received.	Longer original than specified is received from the remote station.
R73		Modern response waiting T.0 (60 seconds)	-
R74	]	Reception byte size error	
R75	V34	V34 signal sending error	-
R <b>76</b>		Unexpected command was received in V34 mode phase C reception	-
R77	Reception	Codec control middle ware error	-
R78		Codec control software error	-
R79		Job control soft error during reception	-

## 8.29 R8\*

Code No.	Category	Contents of error	How to correct
R80	Not used		
R81	Not used		
R82	Not used		
R83	Not used		
R84	Not used		
R85	-	R-ISW request received when a machine is running in case of either reserved job exists, image exists in memory, or jam happened.	-
R86	Not used		
R87	Not used		
R88	Not used		
R89	Not used		

## 8.30 R9\*

Code No.	Category	Contents of error	How to correct
R90	Not used		
R91	Not used		

Code No.	Category	Contents of error	How to correct
R92	Turnaround	When the turnaround function is not provided, the line is disconnected if a turnaround order (DTC) is received.	
R93	F-code reception	Unsatisfactory conditions for confidential RX request	Check the Confidential password.
R94		Unsatisfactory conditions for relay request	Check the Relay password.
R95		Unsatisfactory conditions for forwarding request	-
R96		Confidential box number specified by SUB is not valid.	Confidential box No. received from the remote station may be incorrect.
R97		Unsatisfactory conditions for PC-FAX RX request (Function, PW unmatching)	-
R98	Not used		
R99	Others	Reception command was received from the whole control side before reception signals were detected.	-

#### 8.31 Others

Code No.	Category	Contents of error	How to correct
	Others	Despite the FAX board is installed in line 2, FAX (circuit2) of [Service Mode] -> [System 2] -> [Option Board Status] is "Unset", if it is set to When the main body is in the sleep mode, line 1 can not receive faxes.	When using the line 2, make sure that the FAX (system) for line 2 is set up correctly. When not using the line 2, remove all wirings of the FAX board for line 2.
-		When the main body recovers from the sleep mode while receiving a fax, the ring tone is generated more than the set number of times. (2 to 3 times)	This error is avoidable with any one of the following settings.  • Set [Administrator Settings] -> [System Settings] -> [Power Supply/Power Save Settings] -> [Power Consumption in Sleep Mode] to "Disabled".  • Set [Administrator Settings] -> [Fax Settings] -> [Line Parameter Setting] -> [Number of RX Call Rings] to "0 x".