

#### Computer Organization and Design

The Hardware/Software Interface



## Chapter 6

Parallel Processors from Client to Cloud

### Introduction

- Goal: connecting multiple computers to get higher performance
  - Multiprocessors
  - Scalability, availability, power efficiency
- Task-level (process-level) parallelism
  - High throughput for independent jobs
- Parallel processing program
  - Single program run on multiple processors
- Multicore microprocessors
  - Chips with multiple processors (cores)

### Hardware and Software

- Hardware
  - Serial: e.g., Pentium 4
  - Parallel: e.g., quad-core Xeon e5345
- Software
  - Sequential: e.g., matrix multiplication
  - Concurrent: e.g., operating system
- Sequential/concurrent software can run on serial/parallel hardware
  - Challenge: making effective use of parallel hardware

## What We've Already Covered

- §2.11: Parallelism and Instructions
  - Synchronization
- §3.6: Parallelism and Computer Arithmetic
  - Subword Parallelism
- §4.10: Parallelism and Advanced Instruction-Level Parallelism
- \$5.10: Parallelism and Memory Hierarchies
  - Cache Coherence

## Parallel Programming

- Parallel software is the problem
- Need to get significant performance improvement
  - Otherwise, just use a faster uniprocessor, since it's easier!
- Difficulties
  - Partitioning
  - Coordination
  - Communications overhead

### Pop Quiz

- Recall Amdahl's Law: S = 1/((1-p)+p/s)
- If we have 100 processors, how much must be parallelizable for 90x speedup?

- A: .9
- B: .99
- C: .999
- D: .9999

## Amdahl's Law

- Sequential part can limit speedup
- Example: 100 processors, 90× speedup?
  - $T_{\text{new}} = T_{\text{parallelizable}}/100 + T_{\text{sequential}}$

• Speedup=
$$\frac{1}{(1-F_{\text{parallelizable}})+F_{\text{parallelizable}}/100}=90$$

- Solving: F<sub>parallelizable</sub> = 0.999
- Need sequential part to be 0.1% of original time

## Scaling Example

- Workload: sum of 10 scalars, and 10 × 10 matrix sum
  - Speed up from 10 to 100 processors
- Single processor: Time =  $(10 + 100) \times t_{add}$
- 10 processors
  - Time =  $10 \times t_{add} + 100/10 \times t_{add} = 20 \times t_{add}$
  - Speedup = 110/20 = 5.5 (55% of potential)
- 100 processors
  - Time =  $10 \times t_{add} + 100/100 \times t_{add} = 11 \times t_{add}$
  - Speedup = 110/11 = 10 (10% of potential)
- Assumes load can be balanced across processors

## Scaling Example (cont)

- What if matrix size is 100 × 100?
- Single processor: Time =  $(10 + 10000) \times t_{add}$
- 10 processors
  - Time =  $10 \times t_{add} + 10000/10 \times t_{add} = 1010 \times t_{add}$
  - Speedup = 10010/1010 = 9.9 (99% of potential)
- 100 processors
  - Time =  $10 \times t_{add} + 10000/100 \times t_{add} = 110 \times t_{add}$
  - Speedup = 10010/110 = 91 (91% of potential)
- Assuming load balanced

### Strong vs Weak Scaling

- Strong scaling: problem size fixed
  - As in example
- Weak scaling: problem size proportional to number of processors
  - 10 processors, 10 × 10 matrix
    - Time =  $20 \times t_{add}$
  - 100 processors, 32 × 32 matrix
    - Time =  $10 \times t_{add} + 1000/100 \times t_{add} = 20 \times t_{add}$
  - Constant performance in this example

#### Instruction and Data Streams

An alternate classification

		Data Streams	
		Single	Multiple
Instruction Streams	Single	SISD: Intel Pentium 4	SIMD: SSE instructions of x86
	Multiple	MISD: No examples today	MIMD: Intel Xeon e5345

- SPMD: Single Program Multiple Data
  - A parallel program on a MIMD computer
  - Conditional code for different processors

### Example: DAXPY $(Y = a \times X + Y)$

Conventional MIPS code

```
1.d $f0,a($sp)
                          :load scalar a
     addiu r4,$s0,#512
                          ;upper bound of what to load
loop: l.d $f2,0($s0)
                          ; load x(i)
     mul.d(f2)f2,f0 ; a × x(i)
     1.d $f4,0($s1)
                          ; load y(i)
      add.d($f4)$f4($f2)
                          ;a \times x(i) + y(i)
      s.d ($f4.0($s1)
                          ;store into y(i)
      addiu $50,$s0,#8
                          ;increment index to x
      addiu $s1,$s1,#8
                          ;increment index to y
      subu $t0,r4,$s0 ;compute bound
      bne $t0,$zero,loop; check if done
```

Vector MIPS code

```
1.d $f0,a($sp) ;load scalar a
1v $v1,0($s0) ;load vector x
mulvs.d $v2,$v1,$f0 ;vector-scalar multiply
1v $v3,0($s1) ;load vector y
addv.d $v4,$v2,$v3 ;add y to product
sv $v4,0($s1) ;store the result
```

### Pop Quiz

 In the DAXPY code, the vector version has improved performance because...

- A: There are no hazards in the vector version
- B: Vector code is always faster
- C: Fewer instructions are fetched and executed
- D: All of the above
- E: None of the above

#### **Vector Processors**

- Highly pipelined function units
- Stream data from/to vector registers to units
  - Data collected from memory into registers
  - Results stored from registers to memory
- Example: Vector extension to MIPS
  - 32 × 64-element registers (64-bit elements)
  - Vector instructions
    - Iv, sv: load/store vector
    - addv.d: add vectors of double
    - addvs.d: add scalar to each element of vector of double
- Significantly reduces instruction-fetch bandwidth Chapter 6 — Parallel Processors from Client to Cloud — 14

#### Vector vs. Scalar


- Vector architectures and compilers
  - Simplify data-parallel programming
  - Explicit statement of absence of loopcarried dependences
    - Reduced checking in hardware
  - Regular access patterns benefit from interleaved and burst memory
  - Avoid control hazards by avoiding loops
- More general than ad-hoc media extensions (such as MMX, SSE)
  - Better match with compiler technology

#### SIMD

- Operate elementwise on vectors of data
  - E.g., MMX and SSE instructions in x86
    - Multiple data elements in 128-bit wide registers
- All processors execute the same instruction at the same time
  - Each with different data address, etc.
- Simplifies synchronization
- Reduced instruction control hardware
- Works best for highly data-parallel applications

#### Vector vs. Multimedia Extensions

- Vector instructions have a variable vector width, multimedia extensions have a fixed width
- Vector instructions support strided access, multimedia extensions do not
- Vector units can be combination of pipelined and arrayed functional units:



Chapter 6 — Parallel Processors from Client to Cloud — 17


## Multithreading

- Performing multiple threads of execution in parallel
  - Replicate registers, PC, etc.
  - Fast switching between threads
- Fine-grain multithreading
  - Switch threads after each cycle
  - Interleave instruction execution
  - If one thread stalls, others are executed
- Coarse-grain multithreading
  - Only switch on long stall (e.g., L2-cache miss)
  - Simplifies hardware, but doesn't hide short stalls (eg, data hazards)

## Simultaneous Multithreading

- In multiple-issue dynamically scheduled processor
  - Schedule instructions from multiple threads
  - Instructions from independent threads execute when function units are available
  - Within threads, dependencies handled by scheduling and register renaming
- Example: Intel Pentium-4 HT
  - Two threads: duplicated registers, shared function units and caches

# Multithreading Example




### Future of Multithreading

- Will it survive? In what form?
- Power considerations ⇒ simplified microarchitectures
  - Simpler forms of multithreading
- Tolerating cache-miss latency
  - Thread switch may be most effective
- Multiple simple cores might share resources more effectively

## Shared Memory

- SMP: shared memory multiprocessor
  - Hardware provides single physical address space for all processors
  - Synchronize shared variables using locks
  - Memory access time
    - UMA (uniform) vs. NUMA (nonuniform)



### Example: Sum Reduction

- Sum 100,000 numbers on 100 processor UMA
  - Each processor has ID: 0 ≤ Pn ≤ 99
  - Partition 1000 numbers per processor
  - Initial summation on each processor

```
sum[Pn] = 0;
for (i = 1000*Pn;
    i < 1000*(Pn+1); i = i + 1)
    sum[Pn] = sum[Pn] + A[i];</pre>
```

- Now need to add these partial sums
  - Reduction: divide and conquer
  - Half the processors add pairs, then quarter, ...
  - Need to synchronize between reduction steps


## Example: Sum Reduction

```
(half = 1) | 0
                            (half = 2) | 0 | 1 | 2 |
half = 100;
                            (half = 4) 0 1 2 3 4 5
repeat
  synch();
  if (half%2 != 0 && Pn == 0)
    sum[0] = sum[0] + sum[ha]f-1];
    /* Conditional sum needed when half is odd;
       Processor0 gets missing element */
  half = half/2; /* dividing line on who sums */
  if (Pn < half) sum[Pn] = sum[Pn] + sum[Pn+half];
until (half == 1);
```

## History of GPUs

- Early video cards
  - Frame buffer memory with address generation for video output
- 3D graphics processing
  - Originally high-end computers (e.g., SGI)
  - Moore's Law ⇒ lower cost, higher density
  - 3D graphics cards for PCs and game consoles
- Graphics Processing Units
  - Processors oriented to 3D graphics tasks
  - Vertex/pixel processing, shading, texture mapping, rasterization

# Graphics in the System




Chapter 6 — Parallel Processors from Client to Cloud — 27

#### GPU Architectures

- Processing is highly data-parallel
  - GPUs are highly multithreaded
  - Use thread switching to hide memory latency
    - Less reliance on multi-level caches
  - Graphics memory is wide and high-bandwidth
- Trend toward general purpose GPUs
  - Heterogeneous CPU/GPU systems
  - CPU for sequential code, GPU for parallel code
- Programming languages/APIs
  - DirectX, OpenGL
  - C for Graphics (Cg), High Level Shader Language (HLSL)
  - Compute Unified Device Architecture (CUDA)

# GPU Memory Structures



## Putting GPUs into Perspective

Feature	Multicore with SIMD	GPU
SIMD processors	4 to 8	8 to 16
SIMD lanes/processor	2 to 4	8 to 16
Multithreading hardware support for SIMD threads	2 to 4	16 to 32
Typical ratio of single precision to double-precision performance	2:1	2:1
Largest cache size	8 MB	0.75 MB
Size of memory address	64-bit	64-bit
Size of main memory	8 GB to 256 GB	4 GB to 6 GB
Memory protection at level of page	Yes	Yes
Demand paging	Yes	No
Integrated scalar processor/SIMD processor	Yes	No
Cache coherent	Yes	No