

meross

User Manual

English

Safety Information

The device is recommended for use indoors and in a dry location only.

The device shall be used within its published power rating on the instructions.

Please contact seller for replacement if there is any damage caused by transportation.

Please plug in the socket in proper condition and away from children.

Please plug in the socket fully while using for safety concern.

Please do not disassemble or install the device, otherwise there may cause product damaged or security risks.

Installation Guide


1. Download the Meross app. You will need it to set up, manage, and upgrade your smart device.





2. Plug the smart plug into an outlet with strong 2.4GHz Wi-Fi. You can check it with your smart phone near the outlet.

3. Set up the device.



(1) For Android user. Open Meross app and tap + on the top right. Just follow the instructions in Meross app and you will set it up in minutes. If you want to use HomeKit with an iOS device after setup on Android. Just launch your Home app and scan or input the code printed on the device or user manual. No reset or extra configuration needed.




- (2) For iOS user. Please follow instructions below.
- Please ensure that your iPhone or iPad is connecting to a 2.4GHz Wi-Fi. Or you may not be able to set it up.
 - Please make sure you are having iOS 13 or above. We recommend you to upgrade to iOS 14 to have better HomeKit user experience.
 - Use Apple Home app instead of Meross app to set it up. Just launch your Home app and tap “Add Accessory” or + on the top right and follow the instructions. It may take a few minutes and then you’ll be all set. The setup code and QR code are printed on the device and the user manual.



- d. If the QR code won't work, please tap “Don't Have a Code or Can't Scan” and choose the smart plug model. Input the code on the label and wait. You should be able to set it up in a minute.



- e. After that, if you'd like to manage your device in Meross app, please connect to your home Wi-Fi and launch your Meross app and tap + on the top right. It will help you find devices in the same Wi-Fi network. Just tap add and you'll be able to manage your device in Meross app. For example, upgrading firmware and binding to Amazon or Google voice assistants.




Note:

1. According to Apple HomeKit, the only way to set up HomeKit accessory with iOS is by Home app. If you don't want to set up with Home app, you will have to use an Android device.
2. If you can't setup the device with Home app. It might be that the iOS is having cache issue with Homekit device. Please try to a. Reset the device and kill the Home app and retry.
b. Restart your iOS and retry. (This is important.)
c. Ensure that your iOS is connecting to 2.4G of your home Wi-Fi.
d. Have your iOS to forget all other Wi-Fi in your home.

**You can also contact us at support@meross.com.
We are always happy to help.**

LED and Button Rules



Red LED

Flashing red slowly (once/sec):
Configuration mode.

Flashing red rapidly (twice/sec):

Initialization/ Wi-Fi connecting mode/ Reset/ Firmware upgrading mode.

Solid red: Successfully connected. To avoid disturbing, LED will be OFF after 30 seconds in this mode.

Blue LED

ON: The socket is at ON status.

OFF: The socket is at OFF status.


Button

Press to turn the socket ON or OFF.

Press and hold (for 5 seconds) until red LED flashes rapidly to initiate factory reset process.

How to Use

1. General Settings



Device name:

Change device name.

LED:

Turn on/off LED indicator.

User manual:

Check user manual.

2. Voice Control



Amazon Alexa & Google Assistant:

Check how to pair Amazon alexa and Google assistant on

Account->Integration.

3. Apple HomeKit with Siri and remote control (iOS only)

After you finish the setup process. You can control your device with Siri when your iOS is connected to your home Wi-Fi. Learn more at <https://support.apple.com/en-us/HT208280>

You can share control of your home to your family by inviting them. Learn more at <https://support.apple.com/en-us/HT208709>

Please be noted that Home app can NOT control your device remotely unless you set up a home hub in your home. Apple requires this hub to fulfil remote control. Learn more at <https://support.apple.com/en-us/HT207057>

4. Widgets

Widgets are the quick access to your Meross devices and Scenes. To enable it, please go to **Account -> Widget** to add shortcuts first. And then follow below steps on your smartphones to activate them.



For iPhones:

1. Swipe to the right on your Home or Lock screen.
2. Scroll down to the bottom of your widget list and then tap edit.
3. Scroll down to find Meross and add it.

For Android smartphones:

1. On the home screen, tap and hold on an available space.
2. Tap Widgets, find Meross widget and then add it.

FAQ

At Meross we strive to assure your satisfaction. We are happy to assist at support@meross.com.

1. What devices can I control with the Meross Smart Plug?

You can control lights, fans, humidifiers, portable heaters, and any small appliances in accordance with the Meross Smart Plug's specifications (up to 13A/16A/10A/16A output for UK/EU/AU/FR version respectively).

2. What should I do when the LED is lit a solid red?

You can troubleshoot the following:

- Check the main Wi-Fi's Internet connection.
- Make sure that main Wi-Fi's password hasn't been changed.
- Make sure your Meross Smart Plug is not too far from the main Wi-Fi.
- Factory reset Meross Smart Plug and try to add it again.

3. How do I pair my Meross devices with Amazon Alexa or Google Assistant?

Visit Account->Amazon Alexa or Google Assistant page within Meross app for pairing instructions.

4. Why my iOS will require me to use Home app when setting it up?

This is required by Apple iOS. If you want manage your device in Meross app, please launch your Meross app after the setup and tap + on the top right. Meross app will find devices in the same Wi-Fi network.

5. My Home app can't add the device by scanning the QR code.

You can tap “Don't Have a Code or Can't Scan” and input the code manually.

6. I can't pair my device with HomeKit anyhow.

Please make sure your iOS is connecting to the 2.4GHz of your home Wi-Fi and you are having iOS13 or above. Restart your iOS will help due to some system cache issue.

Warranty

Meross products are covered by a 24 months limited warranty from the date of its original purchase. If any problems occur, please contact support@meross.com for help.

We can only provide aftersales service for products that are sold by Meross or Meross authorized retailers and distributors.

Disclaimer

1. The function of this smart plug is tested under a typical circumstance described in our specification. Meross does NOT guarantee that under all circumstances will the smart plug perform the same way as described.
2. By using any third-party services such as Amazon Alexa, Google Assistant, Apple HomeKit. Consumer acknowledge that all data and privacy collected by such third parties are not covered by Meross, nor Meross would take any legal responsibility. Meross only take responsibility for what's covered by Meross Privacy Policy. Consumer acknowledge understanding this clearly by reading this document.
3. Any damage caused by ignoring WARNING is not covered by Meross aftersales and Meross will take NO legal responsibility. Consumer acknowledge understanding this clearly by reading this document.

Information sur la sécurité —

L'appareil est recommandé pour une utilisation à l'intérieur et dans un endroit sec uniquement.

La multiprise doit être utilisée dans les limites de sa valeur nominale de multiprise publiée sur les instructions.

Veuillez contacter le vendeur pour le remplacement s'il y a des dommages causés par le transport.

Veuillez brancher la multiprise en bon état et hors de portée des enfants.

Veuillez brancher complètement la multiprise lors de l'utilisation pour des raisons de sécurité.

Veuillez ne pas démonter ou installer la multiprise, sinon cela pourrait endommager le produit ou causer des risques pour la sécurité.

Guida di installazione

1. Scarica l'app Meross. È necessaria per configurare, gestire e aggiornare il dispositivo intelligente.





2. Inserisci la spina intelligente in una presa con Wi-Fi potente da 2,4GHz. Puoi controllarlo con lo smartphone vicino alla presa.
3. Configura il dispositivo.
 - (1) Per utenti Android. Apri l'app Meross e tocca + in alto a destra. Segui le istruzioni nell'app Meross e configurerai in pochi minuti. Se desideri utilizzare HomeKit con un dispositivo iOS dopo l'installazione su Android. Avvia l'app Home e scansiona o inserisci il codice stampato sul dispositivo o sul manuale d'uso. Non occorre alcun reset o configurazione aggiuntiva.




(2) Per utenti iOS. Segui le istruzioni riportate di seguito.

- a. Assicurati che l'iPhone o iPad sia connesso a rete Wi-Fi da 2,4GHz. Altrimenti non puoi riuscire a configurare.
- b. Assicurati di avere iOS 13 o versioni successive. Si consiglia di eseguire l'aggiornamento a iOS 14 per una migliore esperienza utente dell'HomeKit.


- c. Usa l'app Apple Home anziché l'app Meross per configurare. Avvia l'app Home e tocca “Add Accessory” o + in alto a destra e segui le istruzioni. Potrebbero essere necessari alcuni minuti e poi sarai pronto. Il codice di configurazione e il codice QR sono stampati sul dispositivo e sul manuale d’uso.



- d. Se il codice QR non funziona, tocca "Don't Have a Code or Can't Scan " e scegli MSS210. Inserisci il codice sull'etichetta e attendi. Dovresti riuscire a configurare in un minuto.



- e. Dopodiché, se vuoi gestire la spina intelligente con l'app Meross, connetti alla rete Wi-Fi domestica, avvia l'app Meross e tocca + in alto a destra. Ti aiuterà a trovare i dispositivi nella stessa rete Wi-Fi. Basta toccare Aggiungi e potrai gestire MSS210 nell'app Meross. Ad esempio, aggiornare il firmware e associare gli assistenti vocali Amazon o Google.




Nota:

1. In conformità ad Apple HomeKit, l'unico modo per configurare l'HomeKit con iOS è l'app Home. Se non vuoi configurare con l'app Home, dovrai utilizzare un dispositivo Android.
2. Se non riesci a configurare il dispositivo con l'app Home. È possibile che iOS abbia problemi di cache con il dispositivo Homekit. Prova a:
 - a. Ripristinare il dispositivo intelligente, chiudere l'app Home e riprovare.
 - b. Riavviare l'iOS e riprovare (Questo è importante).
 - c. Assicurarsi che l'iOS si connetta al Wi-Fi 2.4G domestico.
 - d. Fare in modo che l'iOS escluda tutte le altre reti Wi-Fi domestiche.

Puoi anche contattarci tramite support@meross.com. Siamo sempre felici di prestare assistenza.

Regole LED e Bottone



① Led Rosso

Rosso lampeggiante lentamente (uno/sec):
Modalità di configurazione.

Rosso lampeggiante velocemente (due/sec):
Inizializzazione/Modalità connessione Wi-Fi/Reset/Modalità aggiornamento firmware.

Rosso fisso: Connesso con successo. Per evitare fastidi il Led si spegnerà dopo 30 secondi in questa modalità

② Led Blu

Acceso: la presa è sulla modalità accesa.

Spento: la presa è sulla modalità spenta.


③ Pulsante

Premere per accendere e spegnere la presa.

Premere e tenere premuto (per 5 secondi) finchè il led rosso lampeggia rapidamente per iniziare il processo di reset alla modalità fabbrica.

Come usare

1. Impostazioni generali



Nome del dispositivo:

Cambia il nome del dispositivo.

LED:

Accensione / spegnimento del LED.

Manuale d'uso:

Consultare il manuale d'uso.

2. Controllo vocale



Amazon Alexa e Google Assistant:

Controlla come associare Amazon Alexa e Google Assistant su Account->Integration.

3. HomeKit Apple con Siri e telecomando (solo iOS)

Dopo aver completato il processo di installazione. Puoi controllare il dispositivo con Siri quando l'iOS è connesso al Wi-Fi domestico. Ulteriori informazioni su

<https://support.apple.com/en-us/HT208280>

Puoi condividere il controllo della casa con i familiari invitandoli. Ulteriori informazioni su

<https://support.apple.com/en-us/HT208709>

Nota che l'app Home NON può controllare il dispositivo in remoto a meno che non si configuri un hub domestico in casa. Apple richiede questo hub per il controllo remoto. Ulteriori informazioni su

<https://support.apple.com/en-us/HT207057>

4. Widget

I widget consentono il rapido accesso a dispositivi e Scenari Meross. Per abilitarli, vai su **Account -> Widget** per aggiungere prima le scorciatoie. Poi sugli smartphone segui i passaggi seguenti per attivarli.



Per iPhone:

1. Scorri verso destra sulla schermata Home o Blocco.
2. Scorri verso il basso fino alla fine dell'elenco dei widget, quindi tocca Modifica.
3. Scorri verso il basso per trovare Meross e aggiungerlo.

Per smartphone Android:

1. Nella schermata principale, tocca e tieni premuto su uno spazio libero.
2. Tocca Widgets, trova il widget Meross e poi aggiungilo.

Domande frequenti

Alla Meross lavoriamo per assicurare la vostra soddisfazione. Ci scusiamo per ogni inconveniente con l'installazione o il funzionamento della Presa Smart Meross e siamo felici di potervi fornire assistenza su support@meross.com.

1. Che dispositivi posso controllare con la Presa Smart Meross?

Puoi controllare luci, ventilatori, umidificatori, riscaldatori portatili e qualunque piccolo apparecchio nel rispetto delle specifiche della Presa Smart Meross (fino a 16A in uscita).

2. Cosa dovrei fare se l'app Meross non fosse in grado di controllare la Presa Smart aggiunta?

Per favore, controlla i seguenti passaggi:

- Controlla che il Wi-Fi principale sia connesso ad internet;
- Assicurati che la password del Wi-Fi principale non sia stata cambiata;
- Usa il reset di fabbrica e prova ad aggiungerla di nuovo.

3. Come faccio ad associare il mio dispositivo Meross con Amazon Alexa o Google Assistant?

Vai su Account->pagina Amazon Alexa o Google Assistant con app Meross per le istruzioni di abbinamento.

4. Perché l'iOS richiede di utilizzare l'app Home durante le impostazioni?

Esclusione di responsabilità

1. Le funzioni di questa spina intelligente sono testate in una situazione tipica descritta nelle nostre specifiche. Meross NON garantisce che in ogni situazione la spina intelligente funzioni come descritto.
2. Utilizzando servizi di terze parti come quelli di Amazon Alexa, Google Assistant, Apple HomeKit. L'utilizzatore riconosce e dà atto che dati personali e privacy raccolti da queste terze parti non sono coperti da Meross e che Meross non ha alcuna responsabilità legale al riguardo. Meross è responsabile solo per ciò che è coperto dall'Informativa sulla privacy di Meross. Leggendo questo documento l'utilizzatore riconosce di aver ben compreso quanto sopra.
3. Eventuali danni causati ignorando le AVVERTENZE non sono coperti dall'assistenza post-vendita di Meross e Meross non assume alcuna responsabilità legale al riguardo. Leggendo questo documento l'utilizzatore riconosce di aver ben compreso quanto sopra.

Questo è richiesto da Apple iOS. Se desideri gestire il dispositivo con l'app Meross, avvia l'app Meross dopo l'installazione e tocca + in alto a destra. L'app Meross troverà i dispositivi nella stessa rete Wi-Fi.

5. L'app My Home non riesce ad aggiungere il dispositivo scansionando il codice QR.

Puoi toccare “Don’t Have a Code or Can’t Scan” e inserire il codice manualmente.

6. Non riesco comunque ad associare il dispositivo a HomeKit.

Assicurati che l'iOS sia connesso al Wi-Fi domestico da 2.4GHz e di disporre di iOS 12 o versioni successive. Riavviare l'iOS aiuterà a risolvere qualche problema con la cache di sistema.

Garanzia

I prodotti Meross sono coperti da una garanzia limitata di 24 mesi dalla data dell'acquisto originale. Se ci sono alcuni problemi, contattare support@meross.com per assistenza.

Possiamo fornire solo il servizio post-vendita per i prodotti venduti da Meross oppure i rivenditori e distributori autorizzati Meross.

SIMPLE DEVICE SIMPLIFY YOUR LIFE

Email: support@meross.com
Website: www.meross.com

Designed in California. Made in China

Supervisor: MRTECH USA Limited

Address: 8825 53 Ave, Elmhurst, NY 11373, USA

Manufacturer: Chengdu Meross Technology Co., Ltd.

Address: No. 1312, Building E6-1, Tianfu Software Park, Chengdu, China



Product Ident GmbH (for Prodsg authorities only)
Hoferstraße 9B, 71636 Ludwigsburg,
Baden-Württemberg, Deutschland

Made in China

