

Technical Service Information

ACURA 4 SPEED HARSH SHIFT INFORMATION

Use the Figures below to insure that you have the spring washer (Cushion Plate) installed into the housing properly, as they go in different directions on the four speed Honda units, depending on model.

85-87 HONDA PI	
2ND CLUTCH = GOES IN THIS DIRECTION (IT IS 2ND CLUTCH 3RD CLUTCH = GOES IN THIS DIRECTION	
4TH CLUTCH	

Figure 1

88-UP	HONDA PRELUDE A	AND ACURA LEGEND
1ST CLUTO 3RD CLUTO 4TH CLUTO	H = GOES IN THIS DIRECTION	
2ND CLUTC	H - GOES IN THIS DIRECTION	

Figure 2

1ST CLUTCH	88-UP ACURA INTEGRA
2ND CLUTCH 3RD CLUTCH 4TH CLUTCH	= GOES IN THIS DIRECTION

Figure 3

Copyright © 2000 ATSG