

PASSAGE ID / AIR CHECK INTRODUCTION

This manual covers passage identification for the purpose of air checking the bands and clutches of many domestic and foreign transmissions and transaxles. Not all passages are easily checked with out the assistance of a test plate but the passages are identified for informational purposes.

No part of any ATSG publication may be reproduced, stored in any retrieval system or transmitted in any form or by any means, including but not limited to electronic, mechanical, photocopying, recording or otherwise, without *written* permission of Automatic Transmission Service Group. This includes all text illustrations, tables and charts.

The information contained in this booklet has been carefully compiled from industry sources known for their reliability, but ATSG does not guarantee its accuracy.

Copyright © ATSG 2011

WAYNE COLONNA TECHNICAL CONSULTANT

PETER LUBAN TECHNICAL CONSULTANT

GERALD CAMPBELL TECHNICAL CONSULTANT

JON GLATSTEIN TECHNICAL CONSULTANT

GREG CATANZARO
TECHNICAL CONSULTANT

DALE ENGLAND TECHNICAL CONSULTANT

JIM DIAL TECHNICAL CONSULTANT

ED KRUSE TECHNICAL CONSULTANT

GREGORY LIPNICK TECHNICAL CONSULTANT

DAVID CHALKER TECHNICAL CONSULTANT

AUTOMATIC TRANSMISSION SERVICE GROUP 18635 S.W. 107 AVENUE CUTLER BAY, FLORIDA 33157 (305) 670-4161



AIR CHECK BOOK

INDEX

CHRYSLER

43RFE / 343RFE	
42RE / 44RE / 46RE / 47RE / 48RE / A500 / A518 / A618	
62TE	
68RFE	8
404-413-470-670	9
727-904	
AW4	
<i>JF011E</i>	
FORD	
4F20E	
4F27E/FNR5	
4R-5R55E	
4R100/E4OD	
5R55N	
5R55S/W	
5R110W	
6R60 / 6R80	
6R140	
A4LD	
AF40-6/FORD 500	
AOD	
AODE/4R70W/4R75E	
ATX	
AX4N / 4F50N	27
AXOD	
AXODE / AX4S.	
<i>C</i> 3	
C4/C5	
C6	
CD4E	
F4EAT / F4AEL / F4EIII	
GF4AEL/G4AEL/G4AHL/GF4EAT	

AUTOMATIC TRANSMISSION SERVICE GROUP 18635 S.W. 107 AVENUE CUTLER BAY, FLORIDA 33157 (305) 670-4161

Copyright © ATSG 2011



AIR CHECK BOOK

INDEX

GENERAL MOTORS

3L30 / 180	
<i>3L80 / 400</i>	37
<i>3T40 / 125C</i>	38
4L30E	39
4L60/65/70E	40
4L80E	4
4T40E	42
4T60E	43
4T65E	44
4T80E	45
<i>5L40E</i>	40
6L80	47
200-4R	48
200C	49
325	50
<i>325-4L</i>	5
350C	52
<i>440-T4 / 4T60.</i>	53
700-R4	54
AF33-5 / AW55-50	55
ALLISON 1000/2000	50
<i>MX-17</i>	57
SATURN 1st DESIGN TAAT.	58
SATURN 2nd DESIGN TAAT.	59
IMPORT	
<i>4HP18</i>	60
4HP22 / 4HP24	61
5HP19	62
5HP19-FL	63
5HP24	64
<i>5HP30</i>	63
6HP26	60
722.6	
722.8	68
722.9	69
AW450-43LE	70
AW81-40LE	7
HONDA HYBRID SZCA	72
HONDA M4VA	73

AUTOMATIC TRANSMISSION SERVICE GROUP 18635 S.W. 107 AVENUE CUTLER BAY, FLORIDA 33157 (305) 670-4161

Copyright © ATSG 2011



AIR CHECK BOOK


INDEX

HYUNDAI A5HF1/F5A5A	74
<i>JF506E</i>	75
<i>JR710E</i>	76
KF100 / F3A	. 77
KIA A4CF2	78
MAZDA RC4A-EL	79
MITSUBISHI AS68RC	
MITSUBISHI F4A20 / F4A30 / KM170 / KM171 / KM175 / KM176 / KM177	. 81
MITSUBISHI JF011E / F1CJA	. 82
MITSUBISHI F4A51	83
MITSUBISHI R4A51 / R5A51	84
<i>NISSAN L3N71B</i>	. 85
<i>NISSAN L4N71B</i>	. 86
NISSAN N4AEL	87
NISSAN RE4FO2A	88
NISSAN RE5RO5A	89
NISSAN RL3FO1A	. 90
NISSAN RL4FO2A	. 91
NISSAN RL4FO3A/V	. 92
NISSAN RL4RO1A / RE4RO1A / JR403E / RE4RO3A / R4A-EL	93
SUBARU 3 SPEED	. 94
SUBARU 4 SPEED	. 95
SUBARU PHASE II	
SUBARU PHASE II VERSION II	
<i>TOYOTA A40</i>	98
<i>TOYOTA A140</i>	99
<i>TOYOTA A340</i>	100
<i>TOYOTA A761E</i>	. 101
TOYOTA U140/U240	
<i>TOYOTA U150/250</i>	.103
<i>TOYOTA U660E</i>	104
VOLVO 50-42LE	.105
VW 010-003	106
VW 01M	. 107
VW 09D	108
VW 09G	110
VW 096	111
VWDSCD2F	112


AUTOMATIC TRANSMISSION SERVICE GROUP 18635 S.W. 107 AVENUE CUTLER BAY, FLORIDA 33157 (305) 670-4161

Copyright © ATSG 2011







CHRYSLER 42 / 44 / 46 / 47 / 48RE / A500 / A518 / A618



Copyright © 2011 ATSG











CHRYSLER 404 / 413 / 470 / 670




Copyright © 2011 ATSG





CHRYSLER 727 / 904





Copyright © 2011 ATSG






































































































































































































































HYUNDAI A5HF1 / F5A5A





Copyright © 2011 ATSG






































































NISSAN RL4RO1A/RE4RO1A/JR403E/RE4RO3A/R4A-EL




Copyright © 2011 ATSG











































VOLVO 50-42LE C1 PORT 1 **B4 SERVO** AND ACCUMULATOR **C2 CLUTCH B1 BRAKE** C1 CLUTCH **AND ACCUMULATOR PASSAGE B2 BRAKE-C1 PORT 2 B3 BRAKE** C3 CLUTCH NOTE: When air checking the C1 clutch thru C1 port 1, you must cover C1 port 2 and vice-versa. Copyright © 2011 ATSG



