

Technical Service Information

RENAULT MB1/MJ3 DRAGS IN REVERSE AND HIGH GEAR

COMPLAINT: Feels like brake is on in reverse and high gear only.

CAUSE: E1-E2 plates, and F2 plates not splined into sun gear shell properly.

CORRECTION: 1. Assemble E1-E2 drum on work bench.

2- Install bearing, planetary carrier, and washer.
3. Install sun gear shell onto E1-E2 plates insuring that all plates are in the same slots (See Figure 1).

4. Using snap ring pliers in the spline of the E1-E2 drum, install complete assembly into the F2 plates, insuring that the inside tangs of the lined F2 plates are in the same slots in

the sun shell (See Figure 1).




Figure 1

Copyright © 2000 ATSG